

# **PROGRAMMING MANUAL**

# **Power Sensors**

# **PWR Series**



testsolutions@minicircuits.com | www.minicircuits.com

# Contents

1. Overview	7
1.1. Control Methods	
1.2. Programming Examples	
1 3 Support Contacts	7
2 USD Control ADI for Microsoft Mindows	
2. USB CONTROLAPTION MICROSOFT WINDOWS	δ
2.1. DLL API Options	8
2.1.1NET Framework 4.5 DLL (Recommended)	
2.1.2NET Framework 2.0 DLL (Legacy Support)	
2.1.3. ActiveX COM Object DLL (Legacy Support)	
2.2. Referencing the DLL	
2.3. Additional DLL Considerations	
2.3.1. Mini-Circuits' DLL Use in Python / MatLab	
2.3.2. Mini-Circuits' DLL Use in LabWindows / CVI	
2.4. DLL – Properties	
2.4.1. Compensation Frequency	
2.4.2. Averaging Mode	
2.4.3. Average Count	
2.4.4. Power Format	
2.4.5. Offset Value	
2.4.6. Offset Mode	
2.5. DLL - General Functions	
2.5.1. Open Power Sensor Connection	
2.5.2. Close Power Sensor Connection	
2.5.3. Read Model Name of Power Sensor	
2.5.4. Read Serial Number of Power Sensor	
2.5.5. Get List of Connected Serial Numbers	
2.5.0. Get Status	
2.5.7. CHECK CONNECTION	
2.5.0. Get Temperature of Fower Sensor	
2.5.10 Get Firmware	23
2.5.11. Get Firmware Version (Antiquated)	24
2.5.12. Get USB Device Name	
2.5.13. Get USB Device Handle	
2.5.14. Open Any Power Sensor (Antiquated)	
2.5.15. Open Any Power Sensor (Antiquated)	
2.5.16. Close Power Sensor Connection (Antiquated)	
2.6. DLL – Average Power Sensor Measurements	
2.6.1. Set Measurement Mode	
2.6.2. Set Sample Time	
2.6.3. Get Sample Time	
2.6.4. Set Power Range	
2.6.5. Read Power	
2.6.6. Read Immediate Power	
2.6.7. Read Voltage	
2.6.8. Get Offset Values	
2.6.9. Set Offset Values	
2.7. DLL - Peak Power Sensor Measurements	

2.7.1. Set Sample Time	
2.7.2. Get Sample Time	
2.7.3. Set Trigger Mode	
2.7.4. Get Trigger Mode	
2.7.5. Read Average Power	
2.7.6. Read Peak Power	
2.7.7. Read Power Array	
2.8 DLL - Ethernet Configuration Eunctions	39
2.8.1 Get Ethernet Configuration	40
2.8.2 Get DHCP Status	
2.8.2. Use DHCP	
2.8.4 Get IP Address	
2.8.5. Save IP Δddress	45
2.8.6 Get MAC Address	
2.8.7 Get Network Cateway	43
2.8.8. Savo Notwork Catoway	
2.0.0. Save Network Galeway	
2.8.10 Savo Subnot Mask	
2.0.10. Save Sublict Mask	
2.0.11. Get TCF/IF FOIL	
2.0.12. Save TCF/IF FULL	
2.6.13. Get Password Requirement	
2.0.14. Set Password	
2.0.15. Get Password	
2.0.10. SEL PASSWOLD	
2.0.17. Get Litternet Status	
2.0.10. ETIADIE / DISADIE ETITET	
3. USB Control Via Direct Programming (Linux)	
3.1. USB Interrupt Code Concept	
3.2. Interrupts - General Functions	
3.2.1. Get Device Model Name	59
3.2.2. Get Device Serial Number	60
3.2.3. Set Measurement Mode	61
3.2.4. Read Power	
3.2.5. Get Internal Temperature	
3.2.6. Get Firmware	66
3.2.7. Send SCPI Command	
3.2.8. Read Initial Power Array	
3.2.9. Read Subsequent Power Arrays	
3.3 Interrupts - Ethernet Configuration Euloctions (RC Models Only)	73
2.2.1. Set Static ID Address	73 ،
2.2.2. Set Static Subpet Mask	
2.2.2. Set Static Notwork Catoway	
2.2.4 Set HTTP Dort	70 רר
2.2.5 Uso Dassword	<i>11</i>
3.3.J. USE FASSWULU	۸/۵۲ مح
3.3.0. JET LOS WULU	
2.2.9 Cat Static ID Addrass	
2.2.0. Cat Static Subpat Mack	ואאו רס
2.2.10 Cat Static Natwork Cataway	
2.2.11 Cot UTTD Dort	రచ
	84

	3.3.12. Get Password Status	85
	3.3.13. Get Password	86
	3.3.14. Get DHCP Status	87
	3.3.15. Get Dynamic Ethernet Configuration	88
	3.3.16. Get MAC Address	90
	3.3.17. Enable / Disable Ethernet	91
	3.3.18. Reset Ethernet Configuration	92
4	Ethernet Control API (RC Models Only)	93
	4.1. Supported Models	. 93
	4.2. Enabling Ethernet Control	. 93
	4.3. Configuring Ethernet Settings	93
	A A Default Ethernet Configuration	9/
	4.5. Default Link Local / Auto ID Addross	. 7 <del>-</del> 0 1
	4.5. Deradit Elik-Eocal / Adto II Address	. 74
	4.6. Direct Ethernet Cable Connection to PC	. 94
	4. /. Discovering Connected Devices Using UDP	. 95
	4.8. SSH Communication	. 96
	4.9. HTTP Communication	. 96
	4.10. Telnet Communication	. 97
5	SCPI Commands for Power Sensor Control	98
	5.1. SCPL - General Functions	.98
	5.1.1. Get Model Name	98
	5.1.2. Get Serial Number	99
	5.1.3. Get Firmware	99
	5.1.4. Get Temperature Units	100
	5.1.5. Set Temperature Units	100
	5.1.6. Get Internal Temperature	101
	5.1.7. Get Compensation Frequency	102
	5.1.8. Set Compensation Frequency	102
	5.2. SCPI - Average Power Sensor Measurements	103
	5.2.1. Get Measurement Mode	103
	5.2.2. Set Measurement Mode	104
	5.2.3. Get Sample Time	105
	5.2.4. Set Sample Time	105
	5.2.5. Read Average Power	106
	5.2.0. Read Voltage	100
	5.3. SCPT – IviedSurement Averaging	107
	5.3.1. Get Averaging Mode	107
	5.3.2. Set Average Count	107
	5.3.4 Set Average Count	108
	5.4 SCPL- Buffered Power Measurements	109
	5.4.1 Get Ruffer Mode	109
	5.4.2. Set Buffer Mode	110
	5.4.3. Get Buffer Size	111
	5.4.4. Set Buffer Size	111
	5.4.5. Read Buffered Power Measurements	112
	5.5. SCPI – Trigger Settings	113
	5.5.1. Get Trigger Mode	114
	55	

	5.5.2. Set Trigger Mode	. 1	15
	5.5.3. Get External Trigger Edge	. 1	16
	5.5.4. Set External Trigger Edge	. 1	17
	5.5.5. Get Internal Trigger Edge	. 1	18
	5.5.6. Set Internal Trigger Edge	. 1	19
	5.5.7. Get Internal Trigger Level Threshold	. 1:	20
	5.5.8. Set Internal Trigger Level Threshold	. 1:	20
	5.5.9. Get Internal Trigger Width Criteria	. 1:	21
	5.5.10. Set Internal Trigger Width Criteria	. 1:	22
	5.5.11. Get Internal Trigger Width Threshold	. 1:	23
	5.5.12. Set Internal Trigger Width Threshold	. 1:	24
	5.5.13. Get Trigger Delay	. 1:	25
	5.5.14. Set Trigger Delay	. 1:	25
	5.5.15. Get Trigger Timeout	. 1:	26
	5.5.16. Set Trigger Timeout	. 1:	27
	5.5.17. Get Trigger or Video Out Function	. 1:	28
	5.5.18. Set Trigger or Video Out Function	. 1:	28
	5.5.19. Get Trigger Output Mode	. 1:	29
	5.5.20. Set Trigger Output Mode	. 1:	30
5	.6. SCPI – Peak Power Sensor Measurements	13	31
	5.6.1. Get Sample Time	. 1:	32
	5.6.2. Set Sample Time	. 1:	33
	5.6.3. Get Video Filter Bandwidth	. 1:	34
	5.6.4. Set Video Filter Bandwidth	. 1:	35
	5.6.5. Read Peak & Average Power	. 1:	36
	5.6.6. Read Initial Power Array (Ethernet Control)	. 1:	37
	5.6.7. Read Subsequent Power Arrays (Ethernet Control)	. 1:	38
	5.6.8. Real Time Peak Power - Return Power	. 1:	39
	5.6.9. Real Time Peak Power – Reset Register	. 1:	39
5	.7. SCPI – LCD Functions	14	10
	5.7.1. Get LCD Status	. 1.	40
	5.7.2. Set LCD Status	. 1.	41
	5.7.3. Get LCD Orientation	. 1.	42
	5.7.4. Set LCD Orientation	. 1.	42
5	.8. SCPI - Ethernet Configuration	14	13
	5.8.1. Get Current Ethernet Configuration	. 1.	43
	5.8.2. Get MAC Address	. 1.	43
	5.8.3. Get DHCP Status.	. 1.	44
	5.8.4. Use DHCP	. 1.	44
	5.8.5. Get Static IP Address	. 1.	45
	5.8.6. Set Static IP Address	. 1.	45
	5.8.7. Get Static Network Gateway	. 1.	46
	5.8.8. Set Static Network Gateway	. 1.	46
	5.8.9. Get Static Subnet Mask	. 1.	47
	5.8.10. Set Static Subnet Mask	. 1.	47
	5.8.11. Get HTTP Port	. 1.	48
	5.8.12. Set HTTP Port & Enable / Disable HTTP	. 1.	48
	5.8.13. Get Telnet Port	. 1.	49
	5.8.14. Set Telnet Port & Enable / Disable Telnet	. 1.	49
	5.8.15. Get SSH Port	. 1!	50
	5.8.16. Set SSH Port	. 1!	50
	5.8.17. Save SSH Login Name	. 1!	51

5.8.18. Set Password Requirement	
5.8.19. Set Password	
5.8.20. Enable / Disable Ethernet	
5.8.21. Update Ethernet Settings	
6. Contact	

# 1. Overview

This Programming Manual is intended for customers wishing to create their own interface for Mini-Circuits' USB and Ethernet controlled power sensors. The contents apply to:

- PWR series CW power sensors
- PWR series RMS power sensors
- PWR series peak & average power sensors

The full software and documentation package including a GUI program, DLL files, user guide and programming examples is available for download from the Mini-Circuits website at:

https://www.minicircuits.com/softwaredownload/pm.html

For details and specifications of individual models please see:

https://www.minicircuits.com/WebStore/RF-Smart-Power-Sensors.html

Files made available for download from the Mini-Circuits website are subject to Mini-Circuits' terms of use which are available on the website

# 1.1. Control Methods

Communication with the device can use any of the following methods:

- 1. For Ethernet connected models, using HTTP or Telnet communication over an Ethernet TCP / IP connection (see Ethernet Control API), which is largely independent of the operating system.
- 2. Using the provided API DLL files (.Net or ActiveX COM objects) for USB control on Microsoft Windows operating systems (see USB Control API for Microsoft Windows)
- 3. Using USB interrupt codes for direct programming on Linux operating systems (see USB Control via Direct Programming (Linux))

In all cases the full functionality of the system is accessible using a command set based on SCPI (see SCPI Commands for Power Sensor Control).

# 1.2. Programming Examples

Mini-Circuits provides examples for a range of programming environments and connection methods, these can be downloaded from our website at:

https://www.minicircuits.com/WebStore/pte\_example\_download.html

Mini-Circuits' Ethernet & USB controlled devices are designed to implement similar control interfaces, so it is usually the case that an example written for one product family can be adapted easily for use with another.

Please contact Mini-Circuit's application support team if an example is not available for the environment of interest.

# 1.3. Support Contacts

We are here to support you every step of the way. For technical support and assistance, please contact us at the email address below or refer to our website for your local support:

#### testsolutions@minicircuits.com

www.minicircuits.com/contact/worldwide\_tech\_support.html

# 2. USB Control API for Microsoft Windows

### Mini-Circuits' API for USB control from a computer running Microsoft Windows is provided in the form of a DLL

file. 3 DLL options are provided to offer the widest possible support, with the same functionality in each case.

- 1) .Net Framework 4.5 DLL This is the recommended API for most modern operating systems
- 2) .Net Framework 2.0 DLL Provided for legacy support of older computers / operating systems, with an installed version of the .Net framework prior to 4.5
- 3) ActiveX com object Provided for legacy support of older environments which do not support .Net

The latest version of each DLL file can be downloaded from the Mini-Circuits website at:

https://www.minicircuits.com/softwaredownload/pm.html

# 2.1. DLL API Options

## 2.1.1. .NET FRAMEWORK 4.5 DLL (RECOMMENDED)

The recommended API option for USB control from most modern programming environments running on Windows.

Filename: mcl\_pm\_NET45.dll

#### Requirements

- 1) Microsoft Windows with .Net framework 4.5 or later
- 2) Programming environment with ability to support .Net components

#### Installation

- 1) Download the latest DLL file from the Mini-Circuits website
- 2) Copy the .dll file to the preferred directory (the recommendation is to use the same folder as the programming project, or C:\WINDOWS\SysWOW64
- 3) Right-click on the DLL file in the save location and select Properties to check that Windows has not blocked access to the file (check "Unblock" if the option is shown)
- 4) No registration or further installation action is required

### 2.1.2. .NET FRAMEWORK 2.0 DLL (LEGACY SUPPORT)

Provided for support of systems with an older version of the .Net framework installed (prior to 4.5).

#### Filename: mcl\_pm64.dll

#### Requirements

- 1) Microsoft Windows with .Net framework 2.0 or later
- 2) Programming environment with ability to support .Net components

#### Installation

- 1) Download the latest DLL file from the Mini-Circuits website:
- 2) Copy the .dll file to the preferred directory (the recommendation is to use the same folder as the programming project, or C:\WINDOWS\SysWOW64
- 3) Right-click on the DLL file in the save location and select Properties to check that Windows has not blocked access to the file (check "Unblock" if the option is shown)
- 4) No registration or further installation action is required

## 2.1.3. ACTIVEX COM OBJECT DLL (LEGACY SUPPORT)

Provided for support of programming environments which do not support .Net components.

#### Filename: mcl\_pm.dll

#### Requirements

- 1) Microsoft Windows
- 2) Programming environment with support for ActiveX components

#### Installation

- Copy the DLL file to the correct directory: For 32-bit Windows operating systems: C:\WINDOWS\System32 For 64-bit Windows operating systems: C:\WINDOWS\SysWOW64
- 2. Open the Command Prompt in "Elevated" mode:
  - a. Open the Start Menu/Start Screen and type "Command Prompt"
  - b. Right-click on the shortcut for the Command Prompt
  - c. Select "Run as Administrator"
  - d. You may be prompted to enter the log in details for an Administrator account if the current user does not have Administrator privileges on the local PC
- 3. Use regsvr32 to register the DLL:
  - a. 32-bit PC: \WINDOWS\System32\Regsvr32 \WINDOWS\System32\mcl\_pm.dll
  - b. 64-bit PC: \WINDOWS\SysWOW64\Regsvr32 \WINDOWS\SysWOW64\mcl\_pm.dll
- 4. Hit enter to confirm and a message box will appear to advise of successful registration.



Fig 2.1-a: Opening the Command Prompt in Windows 7 (left), Windows 8 (middle) and Windows 10 (right)



Fig 2.1-b: Registering the DLL in a 64-bit environment

# 2.2. Referencing the DLL

Most programming environments require a reference to be set to the relevant DLL file, either in the IDE menu or within the program. Multiple instances of the DLL control class can then be created (referred to as MyPTE1 and MyPTE2 below) in order to connect to as many devices as needed

Example Declarations Using the .NET 4.5 DLL (mcl\_pm\_NET45.dll)

(For operation with the .Net 2.0 DLL, replace "mcl\_pm\_NET45" with "mcl\_pm64")

	<pre>import clr # Import the pythonnet CLR library</pre>	
Python	<pre>clr.AddReference('mcl_pm_NET45')</pre>	
	<pre>from mcl_pm_NET45 import usb_pm</pre>	
	MyPTE1 = usb_pm()	
	MyPTE2 = usb_pm()	
	Public MyPTE1 As New mcl_pm_NET45.usb_pm	
VISUAI BASIC	Public MyPTE2 As New mcl_pm_NET45.usb_pm	
	<pre>mcl_pm_NET45::usb_pm ^MyPTE1 = gcnew mcl_pm_NET45::usb_pm();</pre>	
VISUALC++	<pre>mcl_pm_NET45::usb_pm ^MyPTE2 = gcnew mcl_pm_NET45::usb_pm();</pre>	
	<pre>mcl_pm_NET45.usb_pm MyPTE1 = new mcl_pm_NET45.usb_pm();</pre>	
VISUALC#	<pre>mcl_pm_NET45.usb_pm MyPTE2 = new mcl_pm_NET45.usb_pm();</pre>	
	<pre>MCL_ATT = NET.addAssembly('C:\Windows\SysWOW64\mcl_pm_NET45.dll')</pre>	
MatLab	MyPTE1 = mcl_pm_NET45.usb_pm	
	MyPTE2 = mcl_pm_NET45.usb_pm	
Example Declarations using the ActiveX DLL (mcl_pm.dll)		

	Public MyPTE1 As New mcl_pm.USB_PM
VISUAI DASIC	Public MyPTE2 As New mcl_pm.USB_PM
Visual C	<pre>mcl_pm::USB_pm ^MyPTE1 = gcnew mcl_pm::USB_pm();</pre>
VISUALC++	<pre>mcl_pm::USB_pm ^MyPTE2 = gcnew mcl_pm::USB_pm();</pre>
Vieual C#	<pre>public mcl_pm.USB_PM MyPTE1 = new mcl_pm.USB_PM();</pre>
VISUALC#	<pre>public mcl_pm.USB_PM MyPTE2 = new mcl_pm.USB_PM();</pre>
MatLab	MyPTE1 = actxserver(mcl pm.USB PM)
	MyPTE2 = actxserver(mcl pm.USB PM)

Mini-Circuits

# 2.3. Additional DLL Considerations

Mini-Circuits' DLL API options are intended to support the widest possible range of modern programming environments, with the typical summaries and examples below applying in most cases. There are a few additional considerations to bear in mind for specific programming manuals, as summarized below.

# 2.3.1. MINI-CIRCUITS' DLL USE IN PYTHON / MATLAB

Some functions are defined within Mini-Circuits' DLL files with arguments to be passed by reference. This allows the variables (with their updated values) to be used later within the program, after the DLL function has executed. This methodology fits with many programming environments (including C#, C++ and VB) but is interpreted slightly differently by Python and MatLab:

- Typical operation (C#, C++, VB):
  - The function has an integer return value to indicate success / failure (1 or 0)
  - One or more variables are passed to the function by reference so that the updated values are available to the program once function execution has completed
- Python implementation:
  - Any parameters passed by reference to a function can be ignored (an empty string can be provided in place of the variable)
  - The return value from the function will change from the single integer value as defined in this manual, to a tuple
  - The tuple format will be [function\_return\_value, function\_parameter]
- MatLab implementation:
  - Any parameters passed by reference to a function can be ignored (an empty string can be provided in place of the variable)
  - The return value from the function will change from the single integer value as defined in this manual to an array of values
  - The function must be assigned to an array variable of the correct size, in the format [function\_return\_value, function\_parameter]

The examples below illustrate how a function of this type is defined in the DLL and how that same function is implemented in C#, Python and MatLab.

Definition	Short Send_SCPI(String SndSTR, ByRef String RetSTR)
Visual C#	<pre>status = MyPTE1.Send_SCPI(":SN?", ref(RetSTR));</pre>
	if(status > 0)
	{
	<pre>MessageBox.Show("The connected device is " + RetSTR);</pre>
	}
	<pre>status = MyPTE1.Send_SCPI(":SN?", "")</pre>
Duthon	<pre>if status[0] &gt; 0:</pre>
Python	RetSTR = str(status[1])
	print('The connected device is ', RetSTR)
MatLab	<pre>[status, RetSTR] = MyPTE1.Send_SCPI(':SN?', '')</pre>
	if status > 0
	<pre>h = msgbox('The connected device is ', RetSTR)</pre>
	end

## 2.3.2. MINI-CIRCUITS' DLL USE IN LABWINDOWS / CVI

It is recommended to use one of the .Net DLL files for USB control of Mini-Circuits devices from CVI. The initial steps to set up the instrument driver in the CVI project are as below (note: there may be slight variations between CVI versions):

- 1. It is recommended to place the DLL into the CVI project folder (refer to the instructions above, to download the .Net DLL and ensure that Windows has not blocked it)
- 2. Open CVI:
  - a. From the menu select Tools > Create .NET controller
  - b. Check the option to specify the assembly by path and filename
  - c. Browse to the working directory and select the DLL file
  - d. Under the target instrument enter the working directory path
  - e. CVI should now compile and create the instrument driver (.fp) file
  - f. Under Instrument files on the left of the CVI screen there should now be an object for the DLL file
  - g. Clicking on the object provides access to all methods and properties within the DLL.

The process above creates an instrument driver in CVI which has the effect of a "wrapper" around the Mini-Circuits DLL. This "wrapper" provides a set of definitions for each of the DLL functions which allow them to be used within CVI. The new definitions contain some additional CVI specific content which make them appear slightly different to the DLL definitions summarized in this manual, but the arguments and return values remain the same.

The example below demonstrates how the DLL definitions in this manual convert to the form used within the CVI "wrapper":

Mini-Circuits' DLL Definition	<pre>short Open_Sensor(string [SN_Request])</pre>	
Implementation in CVI instrument driver	<pre>int CVIFUNC mcl_pm64_usb_pm_Open_Sensor(</pre>	
	<pre>mcl_pm64_usb_pminstance,</pre>	
	char ** SN_Request,	
	short *returnValue,	
	CDotNetHandle *exception);	
Explanation	The CVI function definition contains the following arguments:	
	1. An instance of the Mini-Circuits DLL class	
	2. The argument(s) defined in the Mini-Circuits DLL function	
	3. The return value from the Mini-Circuits DLL function	
	4. An error indicator object (part of the CVI / .Net instrument driver)	

# 2.4. DLL - Properties

Function	Syntax
Compensation Frequency	double Freq
Averaging Mode	short AVG
Average Count	short AvgCount
Power Format	bool Format_mw
Offset Value	single OffsetValue
Offset Mode	short OffsetValue_Enable

# 2.4.1. COMPENSATION FREQUENCY

### double Freq

Sets the power sensor frequency compensation to the correct frequency in MHz for the expected input signal. This parameter needs to be set in order to achieve the specified power measurement accuracy.

Note: PWR series power sensors do not have frequency selectivity.

#### Parameters

Value	Description	
Frequency	Frequency value (MHz) within the power sensor's specifie	<b>d</b> input range
Examples		
Duthon	MyPTE1.Freq = 1000	
Python	Frequency = MyPTE1.Freq	
	MyPTE1.Freq = 1000	
VISUAI Basic Frequency	Frequency = MyPTE1.Freq	
	MyPTE1->Freq = 1000;	
VISUALC++	<pre>Frequency = MyPTE1-&gt;Freq;</pre>	
Visual C#	MyPTE1.Freq = 1000;	
	<pre>Frequency = MyPTE1.Freq;</pre>	
MatLab	MyPTE1.Freq = 1000;	
	<pre>Frequency = MyPTE1.Freq;</pre>	

# 2.4.2. AVERAGING MODE

### short AVG

Enables the "averaging" mode of the power sensor so that power readings will be averaged over a number of measurements (defined by the AvgCount property). The default value is 0 (averaging disabled).

Parameters

Value	Description
0	Disable averaging mode
1	Enable averaging mode
Examples	
Duthers	MyPTE1.Avg = 1
Python	Avg_on = MyPTE1.Avg
Vieual Dacia	MyPTE1.Avg = 1
VISUAI BASIC	Avg_on = MyPTE1.Avg
Michael Car	MyPTE1->Avg = 1;
VISUALC++	Avg_on = MyPTE1->Avg;
Visual C#	MyPTE1.Avg = 1;
	Avg_on = MyPTE1.Avg;
MatLab	MyPTE1.Avg = 1;
	Avg_on = MyPTE1.Avg;

### 2.4.3. AVERAGE COUNT

### short AvgCount

Defines the number of power readings over which to average the measurement when averaging mode is enabled (defined by the AVG property). The default value is 1 (average the reading over 1 measurement).

Parameters

Value	Description	
Count	The number of measurements to average (1 to 16)	
Examples		
Duthern	MyPTE1.AvgCount = 10	
Python	Count = MyPTE1.AvgCount	
	MyPTE1.AvgCount = 10	
VISUAI BASIC	Count = MyPTE1.AvgCount	
	MyPTE1->AvgCount = 10;	
VISUALC++	Count = MyPTE1->AvgCount;	
Michael C#	MyPTE1.AvgCount = 10;	
VISUALC#	Count = MyPTE1.AvgCount;	
Matlab	MyPTE1.AvgCount = 10;	
IVIALLAD	Count = MyPTE1.AvgCount;	

# 2.4.4. POWER FORMAT

### bool Format\_mW

Sets the power measurement units to between mW and dBm. The default is power measurements in dBm. Parameters

Value	Description	
False	Power reading in dBm	
True	Power reading in mW	
Examples		
Python	MyPTE1.Format_mW = True Format = MyPTE1.Format_mw	
Visual Basic	MyPTE1.Format_mW = True Format = MyPTE1.Format_mw	
Visual C++	MyPTE1->Format_mW = True; Format = MyPTE1->Format_mw;	
Visual C#	MyPTE1.Format_mW = True; Format = MyPTE1.Format_mw;	
MatLab	MyPTE1.Format_mW = True; Format = MyPTE1.Format_mw;	

# 2.4.5. OFFSET VALUE

### single OffsetValue

Sets a single offset value to be used for power readings. The power meter offset mode **must be set to "1"** (single value).

Parameters

Value	Description	
Offset	The power measurement offset in dB	
Examples		
Duther	MyPTE1.OffsetValue_Enable = 1	
Python	MyPTE1.OffsetValue = 5.4	
	MyPTE1.OffsetValue_Enable = 1	
VISUAI BASIC	MyPTE1.OffsetValue = 5.4	
	<pre>MyPTE1-&gt;OffsetValue_Enable = 1;</pre>	
VISUALC++	<pre>MyPTE1-&gt;OffsetValue = 5.4;</pre>	
Marial C#	<pre>MyPTE1.OffsetValue_Enable = 1;</pre>	
VISUALC#	<pre>MyPTE1.0ffsetValue = 5.4;</pre>	
Mattala	<pre>MyPTE1.OffsetValue_Enable = 1;</pre>	
IVIALLAD	MyPTE1.OffsetValue = 5.4;	

See Also

Offset Mode

# 2.4.6. OFFSET MODE

## short OffsetValue\_Enable

Defines whether an offset is used for the power readings. The power sensor can use either a single offset value (set using the Set Offset Value property) or an array of offset values (set by the Set Offset Values function).

#### Parameters

Value	Description
0	Offset disabled
1	Use single value offset
2	Use array of offset values

#### Examples

Duthon	MyPTE1.OffsetValue_Enable = 1
Python	MyPTE1.OffsetValue = 5.4
	MyPTE1.OffsetValue_Enable = 1
VISUAI BASIC	MyPTE1.OffsetValue = 5.4
Minutel Com	<pre>MyPTE1-&gt;OffsetValue_Enable = 1;</pre>
VISUALC++	<pre>MyPTE1-&gt;OffsetValue = 5.4;</pre>
Minuted C#	<pre>MyPTE1.OffsetValue_Enable = 1;</pre>
VISUALC#	<pre>MyPTE1.OffsetValue = 5.4;</pre>
Matlab	<pre>MyPTE1.OffsetValue_Enable = 1;</pre>
Matlap	<pre>MyPTE1.OffsetValue = 5.4;</pre>

See Also

Offset Value

Set Offset Values

# 2.5. DLL - General Functions

Function	Syntax
Open Power Sensor Connection	<pre>short Open_Sensor(Optional ByRef string SN_Request)</pre>
Close Power Sensor Connection	<pre>void Close_Sensor()</pre>
Read Model Name of Power Sensor	<pre>string GetSensorModelName()</pre>
Read Serial Number of Power Sensor	<pre>string GetSensorSN()</pre>
Get List of Connected Serial Numbers	<pre>short Get_Available_SN_List(ByRef string SN_List)</pre>
Get Status	short GetStatus()
Check Connection	<pre>short Check_Connection()</pre>
Get Temperature of Power Sensor	<pre>float GetDeviceTemperature(Optional ByRef string Temp_Unit)</pre>
Send SCPI Command	Short Send_SCPI(String SndSTR, ByRef String RetSTR)
Get Firmware	short GetFirmwareInfo(ByRef short FirmwareID,
	ByRef string FirmwareRev, ByRef short FirmwareNo)
Get USB Device Name	<pre>string GetUSBDeviceName()</pre>
Get USB Device Handle	<pre>string GetUSBDeviceHandle()</pre>

## 2.5.1. OPEN POWER SENSOR CONNECTION

### short Open\_Sensor(Optional ByRef string SN) (.Net)

## short Open\_Sensor(Optional string SN) (ActiveX)

Initializes the connection to a USB power sensor. If multiple sensors are connected to the same computer, then the serial number should be included, otherwise this can be omitted. The connection process can take a few seconds so it is recommended that the connection be made once at the beginning of the routine and left open until the sensor is no longer needed. The sensor should be disconnected on completion of the program using the Close\_Sensor function.

#### Parameters

Variable	Description
SN	Optional string containing the serial number of the USB power sensor. Can be omitted if only
	one sensor is connected but must be included otherwise.

#### **Return Values**

Value	Description
0	No connection was possible
1	Connection successfully established
2	Device already connected
3	Requested serial number is not available
Examples	
Python	<pre>status = MyPTE1.Open_Sensor(SN)</pre>
Visual Basic	<pre>status = MyPTE1.Open_Sensor(SN)</pre>
Visual C++	<pre>status = MyPTE1-&gt;Open_Sensor(SN);</pre>
Visual C#	<pre>status = MyPTE1.0pen_Sensor(ref(SN));</pre>
MatLab	<pre>status = MyPTE1.Open_Sensor(SN);</pre>

## 2.5.2. CLOSE POWER SENSOR CONNECTION

### void Close\_Sensor()

Closes the connection to the power sensor.

Examples

Python	<pre>status = MyPTE1.Close_Sensor()</pre>
Visual Basic	<pre>status = MyPTE1.Close_Sensor()</pre>
Visual C++	<pre>status = MyPTE1-&gt;Close_Sensor();</pre>
Visual C#	<pre>status = MyPTE1.Close_Sensor();</pre>
MatLab	<pre>status = MyPTE1.Close_Sensor();</pre>

# 2.5.3. READ MODEL NAME OF POWER SENSOR

### string GetSensorModeLName()

Returns the Mini-Circuits part number of the connected power sensor.

#### **Return Values**

Value	Description
Model	Mini-Circuits model name of the connected sensor
<u> </u>	

#### Examples

Python	<pre>ModelName = MyPTE1.GetSensorModelName()</pre>
	<pre>print('The connected device is ', ModelName)</pre>
Visual Basic	<pre>ModelName = MyPTE1.GetSensorModelName()</pre>
	MsgBox ("The connected device is " & ModelName)
Visual C++	<pre>ModelName = MyPTE1-&gt;GetSensorModelName();</pre>
	<pre>MessageBox::Show("The connected device is " + ModelName);</pre>
Visual C#	<pre>ModelName = MyPTE1.GetSensorModelName();</pre>
	<pre>MessageBox.Show("The connected device is " + ModelName);</pre>
MatLab	<pre>ModelName = MyPTE1.GetSensorModelName();</pre>
	h = msgbox('The connected device is ', ModelName)

## 2.5.4. READ SERIAL NUMBER OF POWER SENSOR

### string GetSensorSN()

Returns the serial number of the connected power sensor.

**Return Values** 

Value	Description	
SN	Serial number of the connected sensor	
Examples		
Python	SerialNo = MyPTE1.GetSensorSN()	
	<pre>print('The connected device is ', SerialNo)</pre>	
	<pre>SerialNo = MyPTE1.GetSensorSN()</pre>	
VISUAI BASIC	MsgBox ("The connected device is " & SerialNo)	
Vieual C.	<pre>SerialNo = MyPTE1-&gt;GetSensorSN();</pre>	
VISUALC++	<pre>MessageBox::Show("The connected device is " + SerialNo);</pre>	
Visual C#	<pre>SerialNo = MyPTE1.GetSensorSN();</pre>	
	<pre>MessageBox.Show("The connected device is " + SerialNo);</pre>	
MatLab	<pre>SerialNo = MyPTE1.GetSensorSN();</pre>	
	h = msgbox('The connected device is ', SerialNo)	

## 2.5.5. GET LIST OF CONNECTED SERIAL NUMBERS

### short Get\_Available\_SN\_List(ByRef string SN\_List)

Provides a list of serial numbers for all available (currently connected) power sensors.

#### Parameters

Variable	Description
SN_List	String variable which the function will update with a list of all available serial numbers, separated by a single space character, for example "11508280079 11508280080 11508280081".

#### **Return Values**

Value	Description
0	Command failed
>1	Command completed successfully

#### Examples

Python	<pre>status = MyPTE1.Get_Available_SN_List("")</pre>
	if status[0] > 0:
	<pre>SN_List = str(status[1])</pre>
	<pre>print("Connected devices:", SN_List)</pre>
	<pre>If MyPTE1.Get_Available_SN_List(SN_List) &gt; 0 Then</pre>
Visual Basic	<pre>MsgBox ("Connected devices: " &amp; SN_List)</pre>
	End If
	<pre>if (MyPTE1-&gt;Get_Available_SN_List(SN_List) &gt; 0 )</pre>
	{
VISUALC++	<pre>MessageBox::Show("Connected devices: " + SN_List);</pre>
	}
	<pre>if (MyPTE1.Get_Available_SN_List(ref(SN_List)) &gt; 0 )</pre>
	{
Visual C#	<pre>MessageBox.Show("Connected devices: " + SN_List);</pre>
	}
MatLab	<pre>[status, SN_List] = MyPTE1.Get_Available_SN_List('')</pre>
	if status > 0
	<pre>h = msgbox('Connected devices: ', SN_List)</pre>
	end

#### See Also

Read Serial Number of Power Sensor

**Open Power Sensor Connection** 

# 2.5.6. GET STATUS

### short GetStatus()

Checks whether the USB connection to the power sensor is still active.

#### **Return Values**

Value	Description
0	No connection
1	USB connection to power sensor is active
Examples	

Python	<pre>status = MyPTE1.GetStatus()</pre>
Visual Basic	<pre>status = MyPTE1.GetStatus()</pre>
Visual C++	<pre>status = MyPTE1-&gt;GetStatus();</pre>
Visual C#	<pre>status = MyPTE1.GetStatus();</pre>
MatLab	<pre>status = MyPTE1.GetStatus();</pre>

See Also

**Open Power Sensor Connection** 

# 2.5.7. CHECK CONNECTION

### short Check\_Connection()

Checks whether the USB connection to the power sensor is still active.

#### **Return Values**

Value	Description
0	No connection
1	USB connection to power sensor is active
Examples	
Python	<pre>status = MyPTE1.Check_Connection()</pre>
Visual Basic	<pre>status = MyPTE1.Check_Connection()</pre>
Visual C++	<pre>status = MyPTE1-&gt;Check_Connection();</pre>
Visual C#	<pre>status = MyPTE1.Check_Connection();</pre>
MatLab	<pre>status = MyPTE1.Check_Connection();</pre>

See Also

**Open Power Sensor Connection** 

# 2.5.8. GET TEMPERATURE OF POWER SENSOR

### float GetDeviceTemperature(Optional ByRef string Temp\_Unit) (.Net)

### float GetDeviceTemperature(Optional string Temp\_Unit) (ActiveX)

Returns the internal temperature of the power sensor. Note: The reading provides an indication but is not calibrated.

#### Parameters

Variable	Value	Description
Temp_Unit	С	Return temperature in Celsius (this is the default if omitted)
	F	Return temperature in Fahrenheit

#### **Return Values**

Value	Description
Temperature	The device internal temperature in the specified units
Examples	
Duthon	<pre>Temp = MyPTE1. GetDeviceTemperature('C')</pre>
Python	<pre>print('Temperature:', Temp[0])</pre>
	<pre>Temp = MyPTE1.GetSensorModelName('C')</pre>
VISUAI BASIC	MsgBox ("Temperature: " & Temp)
Minuted Com	<pre>Temp = MyPTE1-&gt;GetSensorModelName('C');</pre>
VISUAI C++	<pre>MessageBox::Show("Temperature:" + Temp);</pre>
	Temp_Format = 'C'
Visual C#	<pre>Temp = MyPTE1.GetSensorModelName(ref(Temp_Format));</pre>
	<pre>MessageBox.Show("Temperature:" + Temp);</pre>
Matlah	<pre>[Temp, Temp_Format] = MyPTE1.GetSensorModelName('C');</pre>
IVIALLAD	h = msgbox(' Temperature:', Temp)

## 2.5.9. SEND SCPI COMMAND

### Short Send\_SCPI(String SndSTR, ByRef String RetSTR)

Sends a SCPI (Standard Commands for Programmable Instruments) command to the power sensor and collects the response. This function only applies to Mini-**Circuits'** RC series power sensors, using the ASCII / SCPI commands detailed in SCPI Commands for Power Sensor Control.

#### Applies To

RC series power sensors

#### Parameters

Variable	Description
SndSTR	The SCPI command / query to send
RetSTR	String variable passed by reference, to <b>be updated with the power sensor's response to the</b> command / guery

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

Python	<pre>status = MyPTE1.Send_SCPI(":MN?", "")</pre>
	<pre>response = str(status[1])</pre>
Visual Basic	<pre>status = MyPTE1.Send_SCPI(":MN?", response)</pre>
Visual C++	<pre>status = MyPTE1-&gt;Send_SCPI(":MN?", response);</pre>
Visual C#	<pre>status = MyPTE1.Send_SCPI(":MN?", ref(response));</pre>
MatLab	<pre>[status, response] = MyPTE1.Send_SCPI(":MN?", response)</pre>

See Also

SCPI Commands for Power Sensor Control

# 2.5.10. GET FIRMWARE

short GetFirmwareInfo(ByRef short FirmwareID, ByRef string FirmwareRev, ByRef short FirmwareNo)
Returns the internal firmware version of the power sensor.

#### Parameters

Variable	Description
FirmwareID	Required. String variable passed by reference (no user significance).
FirmwareRev	Required. String variable passed by reference, to be updated with the current firmware version, for example "B3".
FirmwareNo	Required. String variable passed by reference (no user significance).

#### **Return Values**

Value	Description	
0	Command failed	
1	Command completed successfully	

#### Examples

	<pre>status = MyPTE1.GetFirmwareInfo(FirmwareID, Firmware, FirmwareNo)</pre>
Python	<pre>if status[0] &gt; 0:</pre>
	Firmware = str(status[2])
	<pre>print("Firmware Version:", Firmware)</pre>
	If MyPTE1.GetFirmwareInfo(FirmwareID, Firmware, FirmwareNo) > 0 Then
Visual Basic	MsgBox ("Firmware Version: " & Firmware)
	End If
Visual C++	if (MyPTE1->GetFirmwareInfo(FirmwareID, Firmware, FirmwareNo) > 0)
	{
	<pre>MessageBox::Show("Firmware Version: " + Firmware);</pre>
	}
	<pre>if(MyPTE1.GetFirmwareInfo(ref(FirmwareID), ref(Firmware), ref(FirmwareNo)) &gt; 0)</pre>
Visual C#	{
	<pre>MessageBox.Show("Firmware Version: " + Firmware);</pre>
	}
MatLab	<pre>[status, FirmwareID, Firmware, FirmwareNo] = MyPTE1.GetFirmwareInfo('', '', '')</pre>
	if status > 0
	h = msgbox('Firmware Version: ', Firmware)
	end

## 2.5.11. GET FIRMWARE VERSION (ANTIQUATED)

### short GetFirmwareVer(ByRef short FirmwareVer)

This function is antiquated, GetFirmwareInfo should be used instead.

# 2.5.12. GET USB DEVICE NAME

## string GetUSBDeviceName()

Returns the USB device name of the sensor for direct communication.

#### **Return Values**

Value	Description	
DeviceName	Device name of the power sensor	
Examples		
Python	<pre>status = MyPTE1.GetUSBDeviceName()</pre>	
Visual Basic	<pre>status = MyPTE1.GetUSBDeviceName()</pre>	
Visual C++	<pre>status = MyPTE1-&gt;GetUSBDeviceName();</pre>	
Visual C#	<pre>status = MyPTE1.GetUSBDeviceName();</pre>	
MatLab	<pre>status = MyPTE1.GetUSBDeviceName();</pre>	

### 2.5.13. GET USB DEVICE HANDLE

### string GetUSBDeviceHandle()

Returns the handle to the USB sensor for direct communication.

#### Return Values

Value	Description
HandleToUSB	USB handle of the power sensor head

#### Examples

Python	<pre>status = MyPTE1.GetUSBDeviceHandle()</pre>
Visual Basic	<pre>status = MyPTE1.GetUSBDeviceHandle()</pre>
Visual C++	<pre>status = MyPTE1-&gt;GetUSBDeviceHandle();</pre>
Visual C#	<pre>status = MyPTE1.GetUSBDeviceHandle();</pre>
MatLab	<pre>status = MyPTE1.GetUSBDeviceHandle();</pre>

# 2.5.14. OPEN ANY POWER SENSOR (ANTIQUATED)

### short Open\_AnySensor()

This function should not be used and is included only for compatibility with early models, Open\_Sensor is the recommended method to connect to a power sensor.

## 2.5.15. OPEN ANY POWER SENSOR (ANTIQUATED)

### void Init\_PM()

This function should not be used and is included only for compatibility with early models, Open\_Sensor is the recommended method to connect to a power sensor.

## 2.5.16. CLOSE POWER SENSOR CONNECTION (ANTIQUATED)

### void CLoseConnection()

This function should not be used and is included only for compatibility with early models, Close\_Sensor is the recommended method to disconnect from a power sensor.

# 2.6. DLL – Average Power Sensor Measurements

Function	Syntax
Set Measurement Mode	<pre>void SetFasterMode(ByRef short S_A)</pre>
Set Sample Time	<pre>short PeakPS_SetSampleTime(long ST)</pre>
Get Sample Time	<pre>long PeakPS_GetSampleTime()</pre>
Set Power Range	void SetRange(short Range)
Read Power	float ReadPower()
Read Immediate Power	<pre>float ReadImmediatePower()</pre>
Read Voltage	<pre>float ReadVoltage()</pre>
Get Offset Values	<pre>short GetOffsetValues(ByRef int NoOfPoints,                               ByRef double FreqArray(), ByRef single LossArray())</pre>
Set Offset Values	<pre>int SetOffsetValues(int NoOfPoints, ByRef double FreqArray(),</pre>
	ByRef single LossArray())

## 2.6.1. SET MEASUREMENT MODE

### void SetFasterMode(ByRef short S\_A) (.Net)

### void SetFasterMode(short S\_A)

Sets the measurement mode of the power sensor between "low noise" and "fast sampling" modes. An additional "fastest sampling" mode is also available for PWR-8FS. The specifications for these modes are defined in the individual model datasheets. The default is "low noise" mode.

(ActiveX)

Applies To

- PWR-xGHS Series (CW average power sensors)
- PWR-6RMS-RC (true RMS power sensor)
- PWR-6LRMS-RC (true RMS power sensor)

#### Parameters

Variable	Value	Description	
	0	Low noise mode (default)	
S_A	1	Fast sampling mode	
	2	Fastest sampling mode (only available for PWR-8FS)	

Examples

Python	<pre>status = MyPTE1.SetFasterMode(S_A)</pre>
Visual Basic	<pre>status = MyPTE1.SetFasterMode(S_A)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SetFasterMode(S_A);</pre>
Visual C#	<pre>status = MyPTE1.SetFasterMode(ref(S_A));</pre>
MatLab	<pre>status = MyPTE1.SetFasterMode(S_A);</pre>

# 2.6.2. SET SAMPLE TIME

### short PeakPS\_SetSampleTime(long ST)

Sets the time period to be captured by the power sensor, from 10  $\mu s$  to 1 s.

Applies To

- PWR-xP Series (peak & average power sensors)
- PWR-18RMS-RC (true RMS power sensor)

#### Parameters

Variable	Description
ST	Sample time (µs), from 10 to 1,000,000 µs

**Return Values** 

Value	Description	
0	Command failed	
1	Command completed successfully	
Examples		
Python	<pre>status = MyPTE1.PeakPS_SetSampleTime(100)</pre>	
Visual Basic	<pre>status = MyPTE1.PeakPS_SetSampleTime(100)</pre>	
Visual C++	<pre>status = MyPTE1-&gt;PeakPS_SetSampleTime(100);</pre>	
Visual C#	<pre>status = MyPTE1.PeakPS SetSampleTime(100);</pre>	

status = MyPTE1.PeakPS\_SetSampleTime(100);

# 2.6.3. GET SAMPLE TIME

### Long PeakPS\_GetSampleTime()

Returns the time period to be captured by the power sensor, from 10  $\mu$ s to 1 s.

Applies To

MatLab

- PWR-xP Series (peak & average power sensors)
- PWR-18RMS-RC (true RMS power sensor)

#### Return Values

Variable	Description	
ST	Sample time (µs), from 10 to 1,000,000 µs	
Examples		
Python	<pre>time = MyPTE1.PeakPS_GetSampleTime()</pre>	
Visual Basic	<pre>time = MyPTE1.PeakPS_GetSampleTime</pre>	
Visual C++	<pre>time = MyPTE1-&gt;PeakPS_GetSampleTime();</pre>	
Visual C#	<pre>time = MyPTE1.PeakPS_GetSampleTime();</pre>	
MatLab	<pre>time = MyPTE1.PeakPS_GetSampleTime();</pre>	

# 2.6.4. SET POWER RANGE

### void SetRange(short Range)

Optimizes the power sensor measurement for the expected input power range. It is recommended that the sensor be left in the default "Auto" mode.

#### Parameters

Variable	Value	Description
Range	0	Auto
	1	Low power
	2	High power

#### Examples

Python	<pre>status = MyPTE1.SetRange(Range)</pre>
Visual Basic	<pre>status = MyPTE1.SetRange(Range)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SetRange(Range);</pre>
Visual C#	<pre>status = MyPTE1.SetRange(Range);</pre>
MatLab	<pre>status = MyPTE1.SetRange(Range);</pre>

### 2.6.5. READ POWER

### float ReadPower()

Returns the sensor power measurement.

Applies To

- PWR-xGHS Series (CW average power sensors)
- PWR-xRMS Series (true RMS power sensors)

#### **Return Values**

Value	Description
	The power reading in either mW or dBm.
Power	Note: A power value below -900 dBm indicates that the input signal level is below the sensor's useable range.

#### Examples

Python	<pre>status = MyPTE1.ReadPower</pre>
Visual Basic	<pre>status = MyPTE1.ReadPower()</pre>
Visual C++	<pre>status = MyPTE1-&gt;ReadPower();</pre>
Visual C#	<pre>status = MyPTE1.ReadPower();</pre>
MatLab	<pre>status = MyPTE1.ReadPower();</pre>

See Also

#### **Power Format**

# 2.6.6. READ IMMEDIATE POWER

### float ReadImmediatePower()

Returns the sensor power measurement with a faster response but reduced accuracy compared to ReadPower. This function does not account for the **sensor's internal** temperature so compensation is based on the last recorded reading (taken when the ReadPower or GetDeviceTemperature functions were last called).

Applies To

- PWR-xGHS Series (CW average power sensors)
- PWR-xRMS Series (true RMS power sensors)

**Return Values** 

Value	Description	
Power	Current power measurement	
Examples		
Python	<pre>status = MyPTE1.ReadImmediatePower</pre>	
Visual Basic	<pre>status = MyPTE1.ReadImmediatePower()</pre>	
Visual C++	<pre>status = MyPTE1-&gt;ReadImmediatePower();</pre>	
Visual C#	<pre>status = MyPTE1.ReadImmediatePower();</pre>	
MatLab	<pre>status = MyPTE1.ReadImmediatePower();</pre>	

See Also

ReadPower

## 2.6.7. READ VOLTAGE

### float ReadVoltage()

Returns the raw voltage detected at the power sensor head. There is no calibration for temperature or frequency.

Applies To

- PWR-xGHS Series (CW average power sensors)
- PWR-xRMS Series (true RMS power sensors)

#### **Return Values**

Value	Description	
Voltage	Voltage detected at the sensor head	
Examples		
Python	<pre>status = MyPTE1.ReadVoltage</pre>	
Visual Basic	<pre>status = MyPTE1.ReadVoltage()</pre>	
Visual C++	<pre>status = MyPTE1-&gt;ReadVoltage();</pre>	
Visual C#	<pre>status = MyPTE1.ReadVoltage();</pre>	
MatLab	<pre>status = MyPTE1.ReadVoltage();</pre>	

See Also

ReadPower

# 2.6.8. GET OFFSET VALUES

# 

Returns the offset array values used which will be applied in "array offset" mode.

#### Parameters

Variable	Description	
NoOfPoints	Integer passed by reference, to be updated with the number of offset points set	
FreqArray	Array passed by reference, to be updated with the frequency offset values (MHz)	
LossArray	Array passed by reference, to be updated with the corresponding loss values (dB) for each frequency point	

#### **Return Values**

Value	Description	
0	Command failed	
1	Command completed successfully	

#### Examples

	response = MyPTE1.GetOffsetValues(pts, freq, loss)
Python	<pre>pts = response[1]</pre>
	<pre>freq = response[2]</pre>
	<pre>loss = response[3]</pre>
	for i in range(pts):
	<pre>print(str(i), str(freq[i]), str(loss[i]))</pre>
	MyPTE1.GetOffsetValues(pts, freq, loss)
Visual Pasic	For i=0 To pts - 1
visual Dasic	MsgBox (i & ": " & freq(i) & "MHz, " & loss(i) & "dB")
	Next
	<pre>MyPTE1-&gt;GetOffsetValues(pts, freq, loss);</pre>
Visual Cur	for (i = 0; i < pts; i++) {
VISUAI C++	<pre>MessageBox::Show(i + ": " + freq[i] + "MHz, " + loss[i] + "dB");</pre>
	}
	<pre>MyPTE1.GetOffsetValues(ref(pts), ref(freq), ref(loss));</pre>
Vieual C#	for (i = 0; i < pts; i++) {
visual C#	<pre>MessageBox.Show(i +": " + freq[i] + "MHz, " + loss[i] + "dB");</pre>
	}
	<pre>[status, pts, freq, loss]=MyPTE1.GetOffsetValues(pts, freq, loss)</pre>
MatLab	maxi=pts-1
	for i=0:maxi
	<pre>h = msgbox(i,': ',freq(i),'MHz ',loss(i),'dB')</pre>
	end

See Also

Offset Mode

# 2.6.9. SET OFFSET VALUES

#### 

#### 

Sets the array of offset values which will be applied for **"array offset" mode**.

#### Parameters

Variable	Description
NoOfPoints	The number of offset points to be defined in the array
FreqArray	Array of frequency (MHz) values for the offset points
LossArray	Array of loss values (dB) values for the offset points.
LossArray	Array of loss values (dB) values for the offset points.

#### **Return Values**

Value	Description	
0	Command failed	
1	Command completed successfully	

Examples

	pts = 4
Python	freq = [1000, 2000, 3000, 4000]
	loss = [0, 0.5, 1, 1.5]
	MyPTE1.SetOffsetValues(pts, freq, loss)
	# Set 4 offset values: 0dB @ 1000MHz; 0.5dB @ 2000MHz; 1dB @ 3000MHz; 1.5dB @ 4000MHz
	Dim pts As Integer = 4
	Dim freq(1000, 2000, 3000, 4000) As double
Visual Basic	Dim loss(0, 0.5, 1, 1.5) As float
	MyPTE1.SetOffsetValues(pts, freq, loss)
	' Set 4 offset values: 0dB @ 1000MHz; 0.5dB @ 2000MHz; 1dB @ 3000MHz; 1.5dB @ 4000MHz
	<pre>int pts = 4;</pre>
	double freq [pts] = {1000, 2000, 3000, 4000};
Visual C++	float loss [pts] = {0, 0.5, 1, 1.5};
	<pre>MyPTE1-&gt;SetOffsetValues(pts, freq, loss);</pre>
	// Set 4 offset values: 0dB @ 1000MHz; 0.5dB @ 2000MHz; 1dB @ 3000MHz; 1.5dB @ 4000MHz
	<pre>int pts = 4;</pre>
	double[] freq = {1000, 2000, 3000, 4000};
Visual C#	float[] loss = {0, 0.5, 1, 1.5};
	<pre>MyPTE1.SetOffsetValues(pts, freq, loss);</pre>
	// Set 4 offset values: 0dB @ 1000MHz; 0.5dB @ 2000MHz; 1dB @ 3000MHz; 1.5dB @ 4000MHz
	pts=4
MatLab	freq=[1000,2000,3000,4000]
	loss=[0,0.5,1,1.5]
	<pre>[status, freq]=MyPTE1.SetOffsetValues(pts, freq, loss)</pre>
	% Set 4 offset values: 0dB @ 1000MHz; 0.5dB @ 2000MHz; 1dB @ 3000MHz; 1.5dB @ 4000MHz

See Also

Offset Mode

Mini-Circuits

# 2.7. DLL - Peak Power Sensor Measurements

Function	Syntax
Set Sample Time	<pre>short PeakPS_SetSampleTime(long ST)</pre>
Get Sample Time	<pre>long PeakPS_GetSampleTime()</pre>
Set Trigger Mode	<pre>short PeakPS_SetTriggerMode(int TM)</pre>
Get Trigger Mode	<pre>short PeakPS_GetTriggerMode()</pre>
Read Average Power	<pre>float PeakPS_GetAvgPower()</pre>
Read Peak Power	<pre>float PeakPS_GetPeakPower()</pre>
Read Peak & Average Power Array	<pre>short PeakPS_GetPower(int NoOfPoints, float PowerArray(),</pre>
Read Feak & Average Fower Array	float PeakPower)

© 2025 Mini-Circuits

Mini-Circuits

# 2.7.1. SET SAMPLE TIME

### short PeakPS\_SetSampleTime(long ST)

Sets the time period to be captured by the power sensor, from 10  $\mu s$  to 1 s.

#### Parameters

Variable	Description
ST	Sample time (µs), from 10 to 1,000,000 µs

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully
<b>E</b>	

#### Examples

Python	<pre>status = MyPTE1.PeakPS_SetSampleTime(100)</pre>
Visual Basic	<pre>status = MyPTE1.PeakPS_SetSampleTime(100)</pre>
Visual C++	<pre>status = MyPTE1-&gt;PeakPS_SetSampleTime(100);</pre>
Visual C#	<pre>status = MyPTE1.PeakPS_SetSampleTime(100);</pre>
MatLab	<pre>status = MyPTE1.PeakPS_SetSampleTime(100);</pre>

# 2.7.2. GET SAMPLE TIME

### Long PeakPS\_GetSampleTime()

Returns the time period to be captured by the power sensor, from 10  $\mu$ s to 1 s.

**Return Values** 

Variable	Description
ST	Sample time (µs), from 10 to 1,000,000 µs
Examples	
Python	<pre>time = MyPTE1.PeakPS_GetSampleTime()</pre>
Visual Basic	<pre>time = MyPTE1.PeakPS_GetSampleTime</pre>
Visual C++	<pre>time = MyPTE1-&gt;PeakPS_GetSampleTime();</pre>
Visual C#	<pre>time = MyPTE1.PeakPS_GetSampleTime();</pre>
MatLab	<pre>time = MyPTE1.PeakPS_GetSampleTime();</pre>

# 2.7.3. SET TRIGGER MODE

### short PeakPS\_SetTriggerMode(int TM)

#### Sets the event which triggers the start of the power sensor's sample period.

#### Parameters

Variable	Value	Description
ТМ	0	No trigger, power sampling will start on request
	1	Internal trigger, power sampling will start on the rising edge of the first pulse detected at the RF input. The read power activity will timeout after 0.5s in internal trigger mode and return the last power measurement if no trigger is detected. To capture pulse sequences with longer periods the read power command can be repeated, or the external trigger mode can be used.
	2	External trigger, power sampling will start when an external trigger input signal is detected

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully
Examples	
Python	<pre>status = MyPTE1.PeakPS_SetTriggerMode(1)</pre>
Visual Basic	<pre>status = MyPTE1.PeakPS_SetTriggerMode(1)</pre>
Visual C++	<pre>status = MyPTE1-&gt;PeakPS_SetTriggerMode(1);</pre>
Visual C#	<pre>status = MyPTE1.PeakPS_SetTriggerMode(1);</pre>
MatLab	<pre>status = MyPTE1.PeakPS_SetTriggerMode(1);</pre>

# 2.7.4. GET TRIGGER MODE

### short PeakPS\_GetTriggerMode()

Indicates the event which triggers the start of the power sensor's sample period.

#### **Return Values**

Value	Description
0	No trigger, power sampling will start on request
1	Internal trigger, power sampling will start on the rising edge of the first pulse detected at the RF input
2	External trigger, power sampling will start when an external trigger input signal is detected
Examples	

#### Examples

Python	<pre>mode = MyPTE1.PeakPS_GetTriggerMode()</pre>
Visual Basic	<pre>mode = MyPTE1.PeakPS_GetTriggerMode</pre>
Visual C++	<pre>mode = MyPTE1-&gt;PeakPS_GetTriggerMode();</pre>
Visual C#	<pre>mode = MyPTE1.PeakPS_GetTriggerMode();</pre>
MatLab	<pre>mode = MyPTE1.PeakPS_GetTriggerMode();</pre>
# 2.7.5. READ AVERAGE POWER

## float PeakPS\_GetAvgPower()

Returns the average power measurement in dBm for the complete sample period of the sensor. The compensation frequency must be set prior to reading power in order to achieve the specified accuracy.

**Return Values** 

Value	Description
Power	Average power of the sampled signal
Examples	
Python	<pre>power = MyPTE1.PeakPS_GetAvgPower()</pre>
Visual Basic	<pre>power = MyPTE1.PeakPS_GetAvgPower</pre>
Visual C++	<pre>power = MyPTE1-&gt;PeakPS_GetAvgPower();</pre>
Visual C#	<pre>power = MyPTE1.PeakPS_GetAvgPower();</pre>
MatLab	<pre>power = MyPTE1.PeakPS_GetAvgPower();</pre>

See Also

**Compensation Frequency** 

## 2.7.6. READ PEAK POWER

### float PeakPS\_GetPeakPower()

Returns the peak power measurement in dBm for the complete sample period of the sensor. The compensation frequency must be set prior to reading power in order to achieve the specified accuracy.

Note: Download the latest DLL version from the Mini-Circuits website to access the SampleTime and TriggerDelay parameters.

**Return Values** 

Value	Description	
Power	Peak power of the sampled signal	
Examples		
Python	<pre>power = MyPTE1.PeakPS_GetPeakPower()</pre>	
Visual Basic	<pre>power = MyPTE1.PeakPS_GetPeakPower</pre>	
Visual C++	<pre>power = MyPTE1-&gt;PeakPS_GetPeakPower();</pre>	
Visual C#	<pre>power = MyPTE1.PeakPS_GetPeakPower();</pre>	
MatLab	<pre>power = MyPTE1.PeakPS_GetPeakPower();</pre>	

See Also

**Compensation Frequency** 

**Read Power Array** 

# 2.7.7. READ POWER ARRAY

# 

**Captures a series of power measurements over the sensor's sample time** to enable statistical analysis of the sampled signal. The number of discrete measurements taken is variable but approximately equally spaced in the time domain so that the total sample time / number of measurements = approximate time per measurement. The series of power measurements is returned as an array.

Note: Download the latest DLL version from the Mini-Circuits website to access the SampleTime and TriggerDelay parameters.

#### Parameters

Variable	Description
NoOfPoints	Integer variable passed by reference, to be updated with the number of power measurements taken (the array size of PowerArray)
PowerArray()	Float array passed by reference, to be updated with the array of discrete power measurements (dBm), equally spaced over the sensor's sample time
PeakPower	Float variable passed by reference, to be updated with the peak power (dBm) detected during the sensor's sample time
SampleTime	Integer value to specify the sample time (µs) to be captured by the power sensor, from 10 to 1,000,000 $\mu s$
TriggerDelay	Integer value to specify the delay time in microseconds ( $\mu$ S) to be applied between detection of a trigger signal and the start of power sampling

#### Return Values

Value	Description
Power	Peak power of the sampled signal

#### Examples

Python	response = MyPTE1.PeakPS_GetPower(NoOfPoints, PowerArray, PeakPower)	
	NoOfPoints = response[1]	
	PowerArray = response[2]	
	<pre>PeakPower = response[3]</pre>	
Visual Basic	<pre>power = MyPTE1.PeakPS_GetPower(NoOfPoints, PowerArray(), PeakPower)</pre>	
Visual C++	<pre>power = MyPTE1-&gt;PeakPS_GetPower(NoOfPoints, PowerArray(), PeakPower);</pre>	
Visual C#	<pre>power = MyPTE1.PeakPS_GetPower(ref(NoOfPoints),ref(PowerArray()),ref(PeakPower));</pre>	
MatLab	[power, NoOfPoints, PowerArray(), PeakPower]	
	<pre>= MvPTE1.PeakPS GetPower(NoOfPoints. PowerArray(). PeakPower):</pre>	

#### See Also

**Compensation Frequency** 

Read Average Power

Read Peak Power

# 2.8. DLL - Ethernet Configuration Functions

These functions provide a method of configuring the **device's** Ethernet IP settings, they can only be sent using the USB connection. The controller must be reset after updating Ethernet parameters in order to load the new configuration, this can be achieved with a power cycle or by using the ResetDevice command.

Refer to Ethernet Control API for additional details on the Ethernet configuration and default behavior.

Function	Syntax
Get Ethernet Configuration	<pre>int GetEthernet_CurrentConfig( ByRef int IP1, ByRef int IP2, ByRef int IP3, ByRef int IP4, ByRef int Mask1, ByRef int Mask2, ByRef int Mask3, ByRef int Mask4, ByRef int GW1, ByRef int GW2, ByRef int GW3, ByRef int GW4)</pre>
Get DHCP Status	<pre>int GetEthernet_UseDHCP()</pre>
Use DHCP	<pre>int SaveEthernet_UseDHCP(int UseDHCP)</pre>
Get IP Address	<pre>int GetEthernet_IPAddress(ByRef int b1, b2, b3, b4)</pre>
Save IP Address	<pre>int SaveEthernet_IPAddress(int b1, int b2, int b3, int b4)</pre>
Get MAC Address	<pre>int GetEthernet_MACAddress(ByRef int m1, m2, m3, m4, m5, m6)</pre>
Get Network Gateway	<pre>int GetEthernet_NetworkGateway(ByRef int b1, b2, b3, b4)</pre>
Save Network Gateway	<pre>int SaveEthernet_NetworkGateway(int b1, int b2, int b3, int b4)</pre>
Get Subnet Mask	<pre>int GetEthernet_SubNetMask(ByRef int b1, b2, b3, b4)</pre>
Save Subnet Mask	<pre>int SaveEthernet_SubnetMask(int b1, int b2, int b3, int b4)</pre>
Get TCP/IP Port	<pre>int GetEthernet_TCPIPPort(ByRef int port)</pre>
Save TCP/IP Port	<pre>int SaveEthernet_TCPIPPort(int port)</pre>
Get Password Requirement	<pre>int GetEthernet_UsePWD()</pre>
Set Password Requirement	<pre>int SaveEthernet_UsePWD(int UsePwd)</pre>
Get Password	<pre>int GetEthernet_PWD(ByRef string Pwd)</pre>
Set Password	<pre>int SaveEthernet_PWD(string Pwd)</pre>
Get Ethernet Status	<pre>int GetEthernet_EnableEthernet()</pre>
Enable / Disable Ethernet	<pre>int SaveEthernet_EnableEthernet(short Enable)</pre>
Reset Device	<pre>byte ResetDevice()</pre>

# 2.8.1. GET ETHERNET CONFIGURATION

### int GetEthernet\_CurrentConfig

### (ByRef int IP1, ByRef int IP2, ByRef int IP3, ByRef int IP4, ByRef int Mask1, ByRef int Mask2, ByRef int Mask3, ByRef int Mask4, ByRef int Gateway1, ByRef int Gateway2, ByRef int Gateway3, ByRef int Gateway4)

Returns the IP configuration that is currently use, either the static IP entered by the user, or the server assigned dynamic IP configuration when DHCP is enabled.

### Parameters

Variable	Description
IP1	Required. Integer variable which will be updated with the first (highest order) octet of the IP address.
IP2	Required. Integer variable which will be updated with the second octet of the IP address.
IP2	Required. Integer variable which will be updated with the third octet of the IP address.
IP4	Required. Integer variable which will be updated with the last (lowest order) octet of the IP address.
Mask1	Required. Integer variable which will be updated with the first (highest order) octet of the subnet mask.
Mask2	Required. Integer variable which will be updated with the second octet of the subnet mask.
Mask3	Required. Integer variable which will be updated with the third octet of the subnet mask.
Mask4	Required. Integer variable which will be updated with the last (lowest order) octet of the subnet mask.
Gateway1	Required. Integer variable which will be updated with the first (highest order) octet of the subnet mask.
Gateway2	Required. Integer variable which will be updated with the second octet of the network gateway.
Gateway3	Required. Integer variable which will be updated with the third octet of the network gateway.
Gateway4	Required. Integer variable which will be updated with the last (lowest order) octet of the network gateway.

### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

Python	status = MyPTE1.GetEthernet_CurrentConfig("", "", "", "", "", "", "", "", "", "",
	<pre>if status[0] &gt; 0:</pre>
	<pre>print("IP:", str(status[1]), str(status[2]), str(status[3]), str(status[4]))</pre>
	<pre>print("Mask:", str(status[1]), str(status[2]), str(status[3]), str(status[4]))</pre>
	<pre>print("Gateway:", str(status[1]), str(status[2]), str(status[3]), str(status[4]))</pre>
	If MyPTE1.GetEthernet_CurrentConfig(IP1, IP2, IP3, IP4, M1, M2, M3, M4,
	G1, G2, G3, G4) > 0 Then
	MsgBox ("IP: " & IP1 & "." & IP2 & "." & IP3 & "." & IP4)
Visual Basic	MsgBox ("Mask: " & M1 & "." & M2 & "." & M3 & "." & M4)
	MsgBox ("Gateway: " & G1 & "." & G2 & "." & G3 & "." & G4)
	End If
	if (MyPTE1->GetEthernet CurrentConfig(IP1, IP2, IP3, IP4, M1, M2, M3, M4,
	GW1, GW2, GW3, GW4) > 0)
	{
Visual C++	<pre>MessageBox::Show("IP: " + IP1 + "." + IP2 + "." + IP3 + "." + IP4);</pre>
	MessageBox::Show("Mask: " + M1 + "." + M2 + "." + M3 + "." + M4);
	MessageBox::Show("Gateway: " + GW1 + "." + GW2 + "." + GW3 + "." + GW4);
	}
	<pre>if (MyPTE1.GetEthernet_CurrentConfig(ref(IP1), ref(IP2), ref(IP3), ref(IP4),</pre>
	ref(M1), ref(M2), ref(M3), ref(M4), ref(GW1), ref(GW2), ref(GW3), ref(GW4)) > 0)
	{
Visual C#	MessageBox.Show("IP: " + IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	MessageBox.Show("Mask: " + M1 + "." + M2 + "." + M3+ "." + M4);
	MessageBox.Show("Gateway: " + GW1 + "." + GW2 + "." + GW3 + "." + GW4);
	}
	[status, IP1, IP2, IP3, IP4, M1, M2, M3, M4, GW1, GW2, GW3, GW4]
MatLab	<pre>= MyPTE1.GetEthernet_CurrentConfig('', '', '', '', '', '', '', '', '', '',</pre>
	if status > 0
	h = msgbox("IP: ", IP1, ".", IP2, ".", IP3, ".", IP4)
	h = msgbox("Mask: ", M1, ".", M2, ".", M3, ".", M4)
	h = msgbox("Gateway: ", M1, ".", M2, ".", M3, ".", M4)
	end

See Also

Get DHCP Status Get IP Address Get Network Gateway Get Subnet Mask

Mini-Circuits

# 2.8.2. GET DHCP STATUS

## int GetEthernet\_UseDHCP()

Indicates whether DHCP (dynamic host control protocol) is currently enabled. When disabled, the device will attempt to connect using the user-entered static IP parameters.

#### **Return Values**

Value	Description
0	DHCP not in use (IP settings are static and manually configured)
1	DHCP in use (IP settings are assigned automatically by the network)

#### Examples

Python	<pre>response = MyPTE1.GetEthernet_UseDHCP()</pre>
Visual Basic	<pre>response = MyPTE1.GetEthernet_UseDHCP()</pre>
Visual C++	<pre>response = MyPTE1-&gt;GetEthernet_UseDHCP();</pre>
Visual C#	<pre>response = MyPTE1.GetEthernet_UseDHCP();</pre>
MatLab	<pre>response = MyPTE1.GetEthernet_UseDHCP()</pre>

See Also

Get Ethernet Configuration

### 2.8.3. USE DHCP

### int SaveEthernet\_UseDHCP(int UseDHCP)

Enables or disables DHCP (dynamic host control protocol). When disabled, the device will attempt to connect using the user-entered static IP parameters. By default, DHCP is enabled.

Parameters

Variable	Description
UseDHCP	Required. Integer value to set the DHCP mode:
	0 - DHCP disabled (static IP settings used)
	1 - DHCP enabled (IP setting assigned by network)

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

### Examples

Python	<pre>status = MyPTE1.SaveEthernet_UseDHCP(1)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_UseDHCP(1)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_UseDHCP(1);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_UseDHCP(1);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_UseDHCP(1);</pre>

# 2.8.4. GET IP ADDRESS

### int GetEthernet\_IPAddress(ByRef int b1, ByRef int b2, ByRef int b3, ByRef int b4)

Returns the user-entered static IP address.

### Parameters

Variable	Description
IP1	Required. Integer variable which will be updated with the first (highest order) octet of the IP address (for example "192" for the IP address "192.168.1.0").
IP2	Required. Integer variable which will be updated with the second octet of the IP address (for example "168" for the IP address "192.168.1.0").
IP2	Required. Integer variable which will be updated with the third octet of the IP address (for example "1" for the IP address "192.168.1.0").
IP4	Required. Integer variable which will be updated with the last (lowest order) octet of the IP address (for example "0" for the IP address "192.168.1.0").

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

Python	<pre>status = MyPTE1.GetEthernet_IPAddress("", "", "", "")</pre>
	if status[0] > 0:
	<pre>print("IP:", str(status[1]), str(status[2]), str(status[3]), str(status[4]))</pre>
	If MyPTE1.GetEthernet_IPAddress(IP1, IP2, IP3, IP4) > 0 Then
Visual Basic	MsgBox ("IP: " & IP1 & "." & IP2 & "." & IP3 & "." & IP4)
	End If
	if (MyPTE1->GetEthernet_IPAddress(IP1, IP2, IP3, IP4) > 0)
Visual C++	{
Visual of t	MessageBox::Show("IP: " + IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	}
	<pre>if (MyPTE1.GetEthernet_IPAddress(ref(IP1), ref(IP2), ref(IP3), ref(IP4)) &gt; 0)</pre>
Visual C#	{
	MessageBox.Show("IP: " + IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	}
MatLab	<pre>[status, IP1, IP2, IP3, IP4] = MyPTE1.GetEthernet_IPAddress('', '', '', '')</pre>
	if status > 0
	h = msgbox("IP: ", IP1, ".", IP2, ".", IP3, ".", IP4)
	end

See Also

Get Ethernet Configuration Get DHCP Status

# 2.8.5. SAVE IP ADDRESS

# int SaveEthernet\_IPAddress(int b1, int b2, int b3, int b4)

Sets the static IP address to be used when DHCP is disabled.

#### Parameters

Variable	Description
IP1	Required. First (highest order) octet of the IP address to set (for example "192" for the IP address "192.168.1.0").
IP2	Required. Second octet of the IP address to set (for example "168" for the IP address "192.168.1.0").
IP2	Required. Third octet of the IP address to set (for example "1" for the IP address "192.168.1.0").
IP4	Required. Last (lowest order) octet of the IP address to set (for example "0" for the IP address "192.168.1.0").

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

### Examples

Python	<pre>status = MyPTE1.SaveEthernet_IPAddress(192, 168, 1, 0)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_IPAddress(192, 168, 1, 0)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_IPAddress(192, 168, 1, 0);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_IPAddress(192, 168, 1, 0);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_IPAddress(192, 168, 1, 0);</pre>

See Also

Use DHCP

# 2.8.6. GET MAC ADDRESS

### 

Returns the physical MAC (media access control) address of the device.

#### Parameters

Variable	Description
MAC1	Required. Integer variable which will be updated with the decimal value of the first numeric group of the MAC address.
	For example:
	MAC address =11:47:165:103:137:171
	MAC1=11
	Required. Integer variable which will be updated with the decimal value of the second numeric group of the MAC address.
MAC2	For example:
	MAC address =11:47:165:103:137:171
	MAC2=47
	Required. Integer variable which will be updated with the decimal value of the third numeric group of the MAC address.
MAC3	For example:
	MAC address =11:47:165:103:137:171
	MAC3=165
	Required. Integer variable which will be updated with the decimal value of the fourth numeric group of the MAC address.
MAC4	For example:
	MAC address =11:47:165:103:137:171
	MAC4=103
	Required. Integer variable which will be updated with the decimal value of the fifth numeric group of the MAC address.
MAC5	For example:
	MAC address =11:47:165:103:137:171
	MAC5=137
MAC6	Required. Integer variable which will be updated with the decimal value of the last numeric group of the MAC address.
	For example:
	MAC address =11:47:165:103:137:171
	MAC6=171

### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

Examples

Python	<pre>status = MyPTE1.GetEthernet_MACAddress("", "", "", "", "", "")</pre>
	if status[0] > 0:
	<pre>print("MAC:", str(status[1]), str(status[2]), str(status[3]),</pre>
	<pre>str(status[4]), str(status[5]), str(status[6]))</pre>
	If MyPTE1.GetEthernet_MACAddress(M1, M2, M3, M4, M5, M6) > 0 Then
Visual Basic	MsgBox ("MAC: " & M1 & "." & M2 & "." & M3 & "." & M4 & "." & M5 & "." & M6)
	End If
	if (MyPTE1->GetEthernet_MACAddress(M1, M2, M3, M4, M5, M6) > 0)
	{
Visual C++	MessageBox::Show("Mask: " + M1 + "." + M2 + "." + M3
	+ "." + M4 + "." + M5 + "." + M6);
	}
	if (MyPTE1.GetEthernet_MACAddress(ref(M1), ref(M2), ref(M3), ref(M4),
	ref(M5), ref(M6)) > 0)
Visual C#	{
VISUAI C#	MessageBox.Show("Mask: " + M1 + "." + M2 + "." + M3
	+ "." + M4 + "." + M5 + "." + M6);
	}
MatLab	[status, M1, M2, M3, M4, M5, M6]
	<pre>= MyPTE1.GetEthernet_MACAddress('', '', '', '', '', '')</pre>
	if status > 0
	h = msgbox("Mask: ", M1, ".", M2, ".", M3, ".", M4, ".", M5, ".", M6)
	end

# 2.8.7. GET NETWORK GATEWAY

### int GetEthernet\_NetworkGateway(ByRef int b1, ByRef int b2, ByRef int b3, ByRef int b4)

Returns the user-entered network gateway IP address.

#### Parameters

Variable	Description
IP1	Required. Integer variable which will be updated with the first (highest order) octet of the IP address (for example "192" for the IP address "192.168.1.0").
IP2	Required. Integer variable which will be updated with the second octet of the IP address (for example "168" for the IP address "192.168.1.0").
IP2	Required. Integer variable which will be updated with the third octet of the IP address (for example "1" for the IP address "192.168.1.0").
IP4	Required. Integer variable which will be updated with the last (lowest order) octet of the IP address (for example "0" for the IP address "192.168.1.0").

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

	<pre>status = MyPTE1.GetEthernet_NetworkGateway("", "", "", "")</pre>
Python	<pre>if status[0] &gt; 0:</pre>
	<pre>print("IP:", str(status[1]), str(status[2]), str(status[3]), str(status[4]))</pre>
Visual Basic	If MyPTE1.GetEthernet_NetworkGateway(IP1, IP2, IP3, IP4) > 0 Then
	MsgBox ("IP: " & IP1 & "." & IP2 & "." & IP3 & "." & IP4)
	End If
	if (MyPTE1->GetEthernet_NetworkGateway(IP1, IP2, IP3, IP4) > 0)
	{
VISUALC++	MessageBox::Show("IP: " + IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	}
	<pre>if (MyPTE1.GetEthernet_NetworkGateway(ref(IP1), ref(IP2), ref(IP3),ref(IP4)) &gt; 0)</pre>
	{
VISUAI C#	MessageBox.Show("IP: " + IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	}
MatLab	<pre>[status, IP1, IP2, IP3, IP4] = MyPTE1.GetEthernet_NetworkGateway('', '', '', '')</pre>
	if status > 0
	h = msgbox("IP: ", IP1, ".", IP2, ".", IP3, ".", IP4)
	end

See Also

Get Ethernet Configuration Get DHCP Status

# 2.8.8. SAVE NETWORK GATEWAY

# int SaveEthernet\_NetworkGateway(int b1, int b2, int b3, int b4)

Sets the IP address of the network gateway to be used when DHCP is disabled.

### Parameters

Variable	Description
IP1	Required. First (highest order) octet of <b>the network gateway IP address (for example "192" for the IP address "192.168.1.0").</b>
IP2	Required. Second octet of the network gateway IP address (for example "168" for the IP address "192.168.1.0").
IP2	Required. Third octet of the network gateway IP address (for example "1" for the IP address "192.168.1.0").
IP4	Required. Last (lowest order) octet of the network gateway IP address (for example "0" for the IP address "192.168.1.0").

Return Values

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

Python	<pre>status = MyPTE1.SaveEthernet_NetworkGateway(192, 168, 1, 0)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_NetworkGateway(192, 168, 1, 0)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_NetworkGateway(192, 168, 1, 0);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_NetworkGateway(192, 168, 1, 0);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_NetworkGateway(192, 168, 1, 0);</pre>

See Also

Use DHCP

# 2.8.9. GET SUBNET MASK

### int GetEthernet\_SubNetMask(ByRef int b1, ByRef int b2, ByRef int b3, ByRef int b4)

Returns the user-entered subnet mask.

### Parameters

Variable	Description
b1	Required. Integer variable which will be updated with the first (highest order) octet of the subnet mask (for example "255" for the subnet mask "255.255.255.0").
b2	Required. Integer variable which will be updated with the second octet of the subnet mask (for example "255" for the subnet mask "255.255.255.0").
b2	Required. Integer variable which will be updated with the third octet of the subnet mask (for example "255" for the subnet mask "255.255.255.0").
b4	Required. Integer variable which will be updated with the last (lowest order) octet of the subnet mask (for example "0" for the subnet mask "255.255.255.0").

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

	<pre>status = MyPTE1.GetEthernet_SubNetMask("", "", "", "")</pre>
Python	if status[0] > 0:
	<pre>print(str(status[1]), str(status[2]), str(status[3]), str(status[4]))</pre>
Visual Basic	If MyPTE1.GetEthernet_SubNetMask(IP1, IP2, IP3, IP4) > 0 Then
	MsgBox (IP1 & "." & IP2 & "." & IP3 & "." & IP4)
	End If
	if (MyPTE1->GetEthernet_SubNetMask(IP1, IP2, IP3, IP4) > 0)
Manal C.	{
VISUALC++	MessageBox::Show(IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	}
	<pre>if (MyPTE1.GetEthernet_SubNetMask(ref(IP1), ref(IP2), ref(IP3), ref(IP4)) &gt; 0)</pre>
Micual C#	{
VISUAI C#	MessageBox.Show(IP1 + "." + IP2 + "." + IP3 + "." + IP4);
	}
MatLab	<pre>[status, IP1, IP2, IP3, IP4] = MyPTE1.GetEthernet_SubNetMask('', '', '', '')</pre>
	if status > 0
	h = msgbox(IP1, ".", IP2, ".", IP3, ".", IP4)
	end

See Also

Get Ethernet Configuration Get DHCP Status

# 2.8.10. SAVE SUBNET MASK

# int SaveEthernet\_SubnetMask(int b1, int b2, int b3, int b4)

Sets the subnet mask to be used when DHCP is disabled.

### Parameters

Variable	Description
IP1	Required. First (highest order) octet of the subnet mask (for example "255" for the subnet mask "255.255.255.0").
IP2	Required. Second octet of the subnet mask (for example "255" for the subnet mask "255.255.255.0").
IP2	Required. Third octet of the subnet mask (for example "255" for the subnet mask "255.255.255.0").
IP4	Required. Last (lowest order) octet of the subnet mask (for example "0" for the subnet mask "255.255.255.0").

**Return Values** 

Value	Description
0	Command failed
1	Command completed successfully

Examples

Python	<pre>status = MyPTE1.SaveEthernet_SubnetMask(255, 255, 255, 0)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_SubnetMask(255, 255, 255, 0)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_SubnetMask(255, 255, 255, 0);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_SubnetMask(255, 255, 255, 0);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_SubnetMask(255, 255, 255, 0);</pre>

See Also

Use DHCP

# 2.8.11. GET TCP/IP PORT

# int GetEthernet\_TCPIPPort(ByRef int port)

Returns the TCP/IP port in use for HTTP communication. The default is port 80.

Note: Port 23 is reserved for Telnet communication and cannot be set for HTTP.

### Parameters

Variable	Description
port	Required. Integer variable which will be updated with the TCP/IP port.

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully
Examples	
	<pre>status = MyPTE1.GetEthernet_TCPIPPort("")</pre>
Duthon	if status[0] > 0:
Python	<pre>port = str(status[1])</pre>
	print(port)
	<pre>If MyPTE1.GetEthernet_TCPIPPort(port) &gt; 0 Then</pre>
Visual Basic	MsgBox (port)
	End If
	<pre>if (MyPTE1-&gt;GetEthernet_TCPIPPort(port) &gt; 0)</pre>
	{
VISUAI C++	<pre>MessageBox::Show(port);</pre>
	}
Visual C#	<pre>if (MyPTE1.GetEthernet_TCPIPPort(ref(port)) &gt; 0)</pre>
	{
	MessageBox.Show(port);
	}
	<pre>[status, port] = MyPTE1.GetEthernet_TCPIPPort('')</pre>
	if status > 0
IVIALLAD	h = msgbox(port)
	end

# 2.8.12. SAVE TCP/IP PORT

# int SaveEthernet\_TCPIPPort(int port)

Sets the TCP / IP port to be used for HTTP communication. The default is port 80.

Note: Port 23 is reserved for Telnet communication and cannot be set as the HTTP port.

### Parameters

Variable	Description
port	Required. Numeric value of the TCP/IP port.

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully
Examples	
Python	<pre>status = MyPTE1.SaveEthernet_TCPIPPort(70)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_TCPIPPort(70)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_TCPIPPort(70);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_TCPIPPort(70);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_TCPIPPort(70);</pre>

# 2.8.13. GET PASSWORD REQUIREMENT

## int GetEthernet\_UsePWD()

Indicates whether the password is currently enabled for HTTP / Telnet (the password is always required for SSH).

### **Return Values**

Value	Description
0	Password not required
1	Password required
Examples	
Python	<pre>response = MyPTE1.GetEthernet_UsePWD()</pre>
Visual Basic	response = MyPTE1.GetEthernet_UsePWD()

Visual C++	response = MyPTE1->GetEthernet_UsePWD();
Visual C#	<pre>response = MyPTE1.GetEthernet_UsePWD();</pre>
MatLab	<pre>response = MyPTE1.GetEthernet_UsePWD()</pre>

See Also

```
Get Password
```

## 2.8.14. SET PASSWORD REQUIREMENT

### int SaveEthernet\_UsePWD(int UsePwd)

Enables or disables the password requirement for HTTP / Telnet (the password is always required for SSH).

Parameters

Variable	Description
UseDHCP	Required. Integer value to set the password mode:
	0 – Password not required
	1 – Password required

**Return Values** 

Value	Description
0	Command failed
1	Command completed successfully
Examples	
Python	<pre>status = MyPTE1.SaveEthernet_UsePWD(1)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_UsePWD(1)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_UsePWD(1);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_UsePWD(1);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_UsePWD(1);</pre>

See Also

Set Password

# 2.8.15. GET PASSWORD

# int GetEthernet\_PWD(ByRef string Pwd)

Returns the current password for HTTP / Telnet communication. The password will be returned even if the device is not currently configured to require a password.

#### Parameters

Variable	Description
Pwd	Required. string variable which will be updated with the password.

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully
Examples	
	<pre>status = MyPTE1.GetEthernet_PWD("")</pre>
Duthon	<pre>if status[0] &gt; 0:</pre>
Python	<pre>pwd = str(status[1])</pre>
	print(pwd)
	<pre>If MyPTE1.GetEthernet_PWD(pwd) &gt; 0 Then</pre>
Visual Basic	MsgBox (pwd)
	End If
Visual C++	if (MyPTE1->GetEthernet_PWD(pwd) > 0)
	{
	<pre>MessageBox::Show(pwd);</pre>
	}
	<pre>if (MyPTE1.GetEthernet_PWD(ref(pwd)) &gt; 0)</pre>
	{

Visual C#	1 MessageBox.Show(pwd);
	}
	<pre>[status, pwd] = MyPTE1.GetEthernet_PWD('')</pre>
MatLab	if status > 0
	h = msgbox(pwd)
	end

See Also

Get Password Requirement

# 2.8.16. SET PASSWORD

# int SaveEthernet\_PWD(string Pwd)

Sets the password used for HTTP / Telnet communication. The password will not affect operation unless Use Password is also enabled.

#### Parameters

Variable	Description
Pwd	Required. The password to set (20 characters maximum).

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully

### Examples

Python	<pre>status = MyPTE1.SaveEthernet_PWD("123")</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_PWD("123")</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_PWD("123");</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_PWD("123");</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_PWD("123");</pre>

See Also

Set Password Requirement

# 2.8.17. GET ETHERNET STATUS

# int GetEthernet\_EnableEthernet()

Indicates whether Ethernet communication is enabled or disabled. Disabling Ethernet control is recommended when not needed, in order to reduce current consumption.

#### **Return Values**

Value	Description
0	Ethernet control is disabled
1	Ethernet control is enabled

#### Examples

Python	<pre>response = MyPTE1.GetEthernet_EnableEthernet()</pre>
Visual Basic	<pre>response = MyPTE1.GetEthernet_EnableEthernet()</pre>
Visual C++	<pre>response = MyPTE1-&gt;GetEthernet_EnableEthernet();</pre>
Visual C#	<pre>response = MyPTE1.GetEthernet_EnableEthernet();</pre>
MatLab	<pre>response = MyPTE1.GetEthernet_EnableEthernet()</pre>

# 2.8.18. ENABLE / DISABLE ETHERNET

### int SaveEthernet\_EnableEthernet(short Enable)

Enable or disable Ethernet communication. Disabling Ethernet control is recommended when not needed, in order to reduce current consumption.

#### Parameters

Variable	Description
	Required. Integer value to enable / disable Ethernet control:
Enable	0 – Ethernet control disabled
	1 – Ethernet control enabled

#### **Return Values**

Value	Description
0	Command failed
1	Command completed successfully
Examples	

Python	<pre>status = MyPTE1.SaveEthernet_EnableEthernet(1)</pre>
Visual Basic	<pre>status = MyPTE1.SaveEthernet_EnableEthernet(1)</pre>
Visual C++	<pre>status = MyPTE1-&gt;SaveEthernet_EnableEthernet(1);</pre>
Visual C#	<pre>status = MyPTE1.SaveEthernet_EnableEthernet(1);</pre>
MatLab	<pre>status = MyPTE1.SaveEthernet_EnableEthernet(1);</pre>

# 2.8.19. RESET DEVICE

# byte ResetDevice()

Called after updating Ethernet parameters, to reset the controller and reload with the updated Ethernet configuration.

**Return Values** 

Value	Description	
0	Command failed	
1	Command completed successfully	
Examples		
Python	MyPTE1.ResetDevice()	
Visual Basic	MyPTE1.ResetDevice()	
Visual C++	<pre>MyPTE1-&gt;ResetDevice();</pre>	
Visual C#	<pre>MyPTE1.ResetDevice();</pre>	
MatLab	MyPTE1.ResetDevice();	

Mini-Circuits

# 3. USB Control via Direct Programming (Linux)

Mini-Circuits' API DLL files require a programming environment which supports either .NET or ActiveX. Where this is not available (for example on a Linux operating system) the alternative method is "direct" USB programming using USB interrupts.

# 3.1. USB Interrupt Code Concept

To open a connection to Mini-Circuits programmable attenuators, the Vendor ID and Product ID are required:

- Mini-Circuits Vendor ID: 0x20CE
- Power Sensor Product ID: 0x11

Communication with the attenuator is carried out by way of USB Interrupt. The transmitted and received buffer sizes are 64 bytes each:

- Transmit Array = [Byte 0][Byte1][Byte2]...[Byte 63]
- Returned Array = [Byte 0][Byte1][Byte2]...[Byte 63]

In most cases, the full 64 byte buffer size is not needed so any unused bytes become "don't care" bytes; they can take on any value without affecting the operation of the attenuator.

Worked examples can be found in the Programming Examples & Troubleshooting Guide, downloadable from the Mini-Circuits website. The examples use the libhid and libusb libraries to interface with the programmable attenuator as a USB HID (Human Interface Device).

# 3.2. Interrupts - General Functions

Description	Command Code
Get Device Model Name	104
Get Device Serial Number	105
Set Measurement Mode	15
Read Power	102
Get Internal Temperature	103
Get Firmware	99
Send SCPI Command	42 or 121
Read Initial Power Array	98
Read Subsequent Power Arrays	108

# 3.2.1. GET DEVICE MODEL NAME

### Description

Returns the full Mini-Circuits part number of the connected power sensor.

#### Transmit Array

Byte	Data	Description
0	104	Interrupt code for Get Device Model Name
1-63	Not significant	"Don't care" bytes, can be any value

#### **Returned Array**

Byte	Data	Description
О	104	Interrupt code for Get Device Model Name
1 to (n-1)	Model Name	Series of bytes containing the ASCII code for each character in the model name
n	0	Zero value byte to indicate the end of the model name
(n+1) to 63	Not significant	"Don't care" bytes, can be any value

### Example

The following array would be returned for Mini-Circuits' PWR-8FS power sensor.

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Description	Code	Char 1	Char 2	Char 3	Char 4	Char 5
Value	104	80	87	82	45	56
ASCII Character	N/A	Р	W	R	-	8

Byte	Byte 6	Byte 7	Byte 8
Description	Char 6	Char 7	End Marker
Value	70	83	0
ASCII Character	F	S	N/A

See Also

Get Device Serial Number

# 3.2.2. GET DEVICE SERIAL NUMBER

### Description

Returns the serial number of the connected power sensor.

#### Transmit Array

Byte	Data	Description
0	105	Interrupt code for Get Device Serial Number
1- 63	Not significant	"Don't care" bytes, can be any value

### Returned Array

Byte	Data	Description
0	105	Interrupt code for Get Device Serial Number
1 to (n-1)	Serial Number	Series of bytes containing the ASCII code for each character in the serial number
n	0	Zero value byte to indicate the end of the serial number
(n+1) to 63	Not significant	"Don't care" bytes, can be any value

### Example

The following example indicates that the current power sensor has serial number 1100040023. See Appendix A for conversions between decimal, binary and ASCII characters.

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Description	Code	Char 1	Char 2	Char 3	Char 4	Char 5
Value	105	49	49	48	48	48
ASCII Character	N/A	1	1	0	0	0

Byte	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11
Description	Char 6	Char 7	Char 8	Char 9	Char 10	End Marker
Value	52	48	48	50	51	0
ASCII Character	4	0	0	2	3	N/A

See Also

Get Device Model Name

# 3.2.3. SET MEASUREMENT MODE

### Description

Sets the measurement mode of an average power sensor between "low noise" and "fast sampling" modes; the default is "low noise" mode. Additionally, "fastest sampling" mode is also available for PWR-8FS. See the individual model datasheets for specifications.

Note: Does not apply to PWR-xP series of peak & average power sensors.

Applies To

- PWR-xGHS Series (CW average power sensors)
- PWR-6RMS-RC (true RMS power sensor)
- PWR-6LRMS-RC (true RMS power sensor)

Transmit Array

Byte	Data	Description
0	15	Interrupt code for Set Measurement Mode
1	Mode	Integer value to set the required mode: 0 = Low noise mode 1 = Fast sampling mode 2 = Fastest sampling mode (PWR-8FS only)
2 - 63	Not significant	"Don't care" bytes, can be any value

#### Returned Array

Byte	Data	Description
0	15	Interrupt code for Set Measurement Mode
1 to 63	Not significant	"Don't care" bytes, can be any value

Example

Byte	Data	Description
0	15	Interrupt code for Set Measurement Mode
1	1	Set power sensor to "fast sampling" mode
2 - 63	Not significant	"Don't care" bytes, can be any value

# 3.2.4. READ POWER

### Description

Returns the sensor power measurement based on a user specified compensation frequency.

The power value (in dBm) is represented in BYTE1 to BYTE6 of the returned array as a series of ASCII character codes in the format "+00.00".

### Transmit Array

Byte	Data	Description
0	102	Interrupt code for Read Power
1	Frequency_1	The compensation frequency to be used for the power reading, split
		over 2 bytes:
		Frequency_1 = INT (FREQUENCY / 256)
2	Frequency_2	The compensation frequency to be used for the power reading, split
		over 2 bytes:
		Frequency_2 = FREQUENCY - (Frequency_1 * 256)
3	Freq_Units	ASCII character code representing the units for the compensation
		frequency, the 2 options are:
		75 = ASCII code for "K" (frequency units are KHz)
		77 = ASCII code for "M" (frequency units are MHz)
4 - 63	Not significant	"Don't care" bytes, can be any value

### Returned Array

Byte	Data	Description
0	102	Interrupt code for Read Power
1	Power_1	ASCII character code for the first character of the power reading
2	Power_2	ASCII character code for the second character of the power reading
3	Power_3	ASCII character code for the third character of the power reading
4	Power_4	ASCII character code for the fourth character of the power reading
5	Power_5	ASCII character code for the fifth character of the power reading
6	Power_6	ASCII character code for the sixth character of the power reading
7 - 63	Not significant	"Don't care" bytes, can be any value

### Example

The following transmit array would be sent to read the power for an expected signal at 1250 MHz:

Byte	Data	Description
0	102	Interrupt code for Read Power
1	4	Frequency_1 = INT (1250 / 256)
2	226	Frequency_2 = 1250 - (4 * 256)
3	77	ASCII code for "M" (frequency units are MHz)
4-63	Not significant	"Don't care" bytes, can be any value

The following array would be returned to indicate a power reading of -10.65dBm:

Byte	Data	Description
0	102	Interrupt code for Read Power
1	45	ASCII character code for "-"
2	49	ASCII character code for "1"
3	48	ASCII character code for "0"
4	46	ASCII character code for "."
5	54	ASCII character code for "6"
6	53	ASCII character code for "5"
7 to 63	Not significant	"Don't care" bytes, can be any value

# 3.2.5. GET INTERNAL TEMPERATURE

### Description

This function returns the internal temperature of the power sensor in degrees Celsius, to two decimal places.

Transmit Array

Byte	Data	Description
0	103	Interrupt code for Get Internal Temperature
1-63	Not significant	"Don't care" bytes, can be any value

#### **Returned Array**

Byte	Data	Description
0	103	Interrupt code for Get Internal Temperature
1	Temp_1	ASCII character code for the first character of the temperature reading
2	Temp_2	ASCII character code for the second character of the temperature reading
3	Temp_3	ASCII character code for the third character of the temperature reading
4	Temp_4	ASCII character code for the fourth character of the temperature reading
5	Temp_5	ASCII character code for the fifth character of the temperature reading
6	Temp_6	ASCII character code for the sixth character of the temperature reading
7-63	Not significant	"Don't care" bytes, can be any value

### Example

Byte	Data	Description
0	103	Interrupt code for Get Internal Temperature
1	43	ASCII character code for "+"
2	50	ASCII character code for "2"
3	56	ASCII character code for "8"
4	46	ASCII character code for "."
5	52	ASCII character code for "4"
6	51	ASCII character code for "3"
7 - 63	Not significant	"Don't care" bytes, can be any value

The below returned array would indicate a temperature of +28.43°C:

# 3.2.6. GET FIRMWARE

### Description

Returns the internal firmware version of the power sensor.

### Transmit Array

Byte	Data	Description
0	99	Interrupt code for Get Firmware
1 - 63	Not significant	"Don't care" bytes, can be any value

### Returned Array

Byte	Data	Description
0	99	Interrupt code for Get Firmware
1	Reserved	Internal code for factory use only
2	Reserved	Internal code for factory use only
3	Firmware Letter	ASCII code for the first character in the firmware revision identifier
4	Firmware Number	ASCII code for the second character in the firmware revision identifier
5 - 63	Not significant	"Don't care" bytes, could be any value

### Example

The following returned array indicates that the power sensor has firmware version C3:

Byte	Data	Description
0	99	Interrupt code for Get Firmware
1	1	Internal code for factory use only
2	12	Internal code for factory use only
3	65	ASCII code for the letter "A"
4	51	ASCII code for the number 3
5 - 63	Not significant	"Don't care" bytes, could be any value

## 3.2.7. SEND SCPI COMMAND

Sends a SCPI (Standard Commands for Programmable Instruments) command to the power sensor and collects the response. This function only applies to Mini-**Circuits'** RC series power sensors, using the ASCII / SCPI commands detailed in SCPI Commands for Power Sensor Control.

### Transmit Array

Byte	Data	Description
0	42 or 121	Interrupt code for Send SCPI Command
1 to 63	SCPI Command	The SCPI command represented as a series of ASCII character codes, one character code per byte

### Returned Array

Byte	Data	Description
0	42 or 121	Interrupt code for Send SCPI Command
1 to 7	Not significant	No meaningful information contained
8 to (n-1)	SCPI Response	The SCPI return string, one character per byte, represented as ASCII character codes
n	0	Zero value byte to indicate the end of the SCPI return string
(n+1) to 63	Not significant	No meaningful information contained

### Example

The SCPI command to request the model name is :MN? (see Get Model Name)

The ASCII character codes representing the 4 characters in this command should be sent in bytes 2 to 5 of the transmit array as follows:

Byte	Data	Description
0	42	Interrupt code for Send SCPI Command
1	49	ASCII character code for :
2	77	ASCII character code for M
3	78	ASCII character code for N
4	63	ASCII character code for ?

See Also

SCPI Commands for Power Sensor Control

# 3.2.8. READ INITIAL POWER ARRAY

Carries out a power measurement and stores the series of discrete measurements values into internal memory, grouped into packages of 160 measurements.

The query returns the number of packages (p) and the first set of measured values. The compensation frequency must be set prior to reading power in order to achieve the specified accuracy.

The number of discrete measurements taken is variable but approximately equally spaced in time so that the number of measurements / total sample time = approximate time per measurement.

If p is greater than 1 then the Read Subsequent Power Arrays method should be used to iteratively return each subsequent package of measurement values.

Once all packages have been obtained, the full array of discrete power measurement values can be used for calculated analysis of the measured input signal, including pulse width, crest factor, rise / fall time and duty cycle for example.

Note: In the event of a trigger timeout (no valid trigger detected within the specified timeout period), the measurement cycle will end and the last buffered result will be returned from memory. Consider adding a timer in the automation program to monitor the response time to a measurement request and then discard the returned result if it is unchanged and the elapsed time is equal to the timeout period.

#### Applies To

PWR-xP Series - Peak & average power sensors

#### Transmit Array

Byte	Data	Description
0	98	Read initial power array
1	Computer 1	Sample time (µs), split over 4 bytes:
I	Sample_1	Sample_1 = INT (Sample_Time / 256 <sup>3</sup> )
2		Remainder_1 = Sample_Time - Sample_1 * (256 <sup>3</sup> )
2	Sample_2	Sample_2 = INT (Remainder_1 / 256 <sup>2</sup> )
2	Sample_3	Remainder_2 = Remainder_1 - Sample_2 * (256 <sup>2</sup> )
3		Sample_3 = INT (Remainder_2 / 256)
4	Sample_4	Sample_4 = INT (Remainder_2 - Sample_3 * 256)
F	Delay_1	Trigger delay (μs), split over 4 bytes:
5		Delay_1 = INT (Trigger_Delay / 256 <sup>3</sup> )
6	Delay_2	Remainder_1 = Trigger_Delay - Delay_1 * (256 <sup>3</sup> )
		Delay_2 = INT (Remainder_1 / 256 <sup>2</sup> )
7		Remainder_2 = Remainder_1 - Delay_2 * (256 <sup>2</sup> )
	Deidy_3	Delay_3 = INT (Remainder_2 / 256)
8	Delay_4	Delay_4 = INT (Remainder_2 - Delay_3 * 256)

### Returned Array

Byte	Data	Description
0	98	Read initial power array
1	р	Total number of packages (p) containing the measured data
2		Total number of measurements (n) contained across all packages:
3	n	n = Byte3 * 256 + Byte2 - 2
		The first discrete power measurement, split across 2 bytes.
4		Integer = Byte5 * 256 + Byte4
	Douver	If (Integer > 32767) {
	Power	Integer = -1 * (65535 – Integer)
5		}
		Power = Integer / 100
		The next discrete power measurement, split across 2 bytes.
62		Integer = Byte63 * 256 + Byte62
		If (Integer > 32767) {
	Power	Integer = -1 * (65535 – Integer)
63		}
		Power = Integer / 100

### Example

Refer to the complete example in Read Subsequent Power Arrays

# 3.2.9. READ SUBSEQUENT POWER ARRAYS

Follows on from Read Initial Power Array which carries out a power measurement and stores a series of discrete measurements in internal memory, grouped in multiple packages. The initial query returns the number of packages (p) and the first set of measured values.

If p is greater than 1 then this Read Subsequent Power Arrays query should be used to iteratively return each subsequent package of measurement values.

Once all packages have been obtained, the full array of discrete power measurement values can be used for calculated analysis of the measured input signal, including pulse width, crest factor, rise / fall time and duty cycle for example.

Applies To

PWR-xP Series - Peak & average power sensors

Transmit Array

Byte	Data	Description
0	108	Read subsequent power array
1	n	Package number from 1 to p - 1

#### Returned Array

Byte	Data	Description
0	108	Read subsequent power array
1	N/A	Ignore this data point
		The next discrete power measurement, split across 2 bytes.
2		Integer = Byte3 * 256 + Byte2
	Dower	If (Integer > 32767) {
	Power	Integer = -1 * (65535 – Integer)
3		}
		Power = Integer / 100
	Power	The next discrete power measurement, split across 2 bytes.
62		Integer = Byte63 * 256 + Byte62
		If (Integer > 32767) {
63		Integer = -1 * (65535 – Integer)
		}
		Power = Integer / 100

### Example

1.a - Set sample time of 1000  $\mu$ s, trigger delay of 250  $\mu$ s, initiate the power measurement and retrieve the first package of discrete power measurements:

Byte	Data	Description
0	98	Read initial power array
1	0	- Sample period of 1000 μs over 4 bytes
2	0	
3	3	
4	232	
5	0	- - Trigger delay of 250 μs over 4 bytes -
6	0	
7	0	
8	250	

### 1.b - The initial array returned from the sensor is:

Byte	Data	Description
0	98	Read initial power array
1	3	Total of 3 packages containing measured data
2	92	Total of 92 discrete measurement values contained across all 3
3	0	packages
4	232	— Power = -61.38 dBm
5	5	
6	233	— Power = -56.85 dBm
7	202	
8	233	— Power = -57.02 dBm
9	185	
•••		
62	2	— Power = +5.68 dBm
63	56	

2.a - Iterate to request the subsequent power arrays; package numbers 1 to 2 in this case:

Byte	Data	Description
0	108	Read subsequent power array
1	1 or 2	Request the second or third package

2.b - The array returned from the sensor is:

Byte	Data	Description
0	108	Read subsequent power array
1	N/A	N/A
2	232	— Power = -61.38 dBm
3	5	
4	233	
5	202	— Power = -56.85 dBm
6	233	— Power = -57.02 dBm
7	185	
62	2	Power = +5.68 dBm
63	56	

The complete series of discrete power samples can be assembled in order, using the power values from packages 1 to 3 (92 values in total in this example). That array can be plotted to trace and analyze the pulse profile graphically. The max value from the array is the peak power level detected over the selected sample period.
# 3.3. Interrupts - Ethernet Configuration Functions (RC Models Only)

Description	Command Code	
	Byte 0	Byte 1
Set Static IP Address	250	201
Set Static Subnet Mask	250	202
Set Static Network Gateway	250	203
Set HTTP Port	250	204
Use Password	250	205
Set Password	250	206
Use DHCP	250	207
Get Static IP Address	251	201
Get Static Subnet Mask	251	202
Get Static Network Gateway	251	203
Get HTTP Port	251	204
Get Password Status	251	205
Get Password	251	206
Get DHCP Status	251	207
Get Dynamic Ethernet Configuration	253	
Get MAC Address	252	
Enable / Disable Ethernet	250	208
Reset Ethernet Configuration	101	101

© 2025 Mini-Circuits

Mini-Circuits

## 3.3.1. SET STATIC IP ADDRESS

### Description

Sets the static IP address to be used when DHCP (dynamic host control protocol) is disabled. Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	201	Interrupt code for Set IP Address
2	IP_Byte0	First byte of IP address
3	IP_Byte1	Second byte of IP address
4	IP_Byte2	Third byte of IP address
5	IP_Byte3	Fourth byte of IP address
6 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To set the static IP address to 192.168.100.100, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	201	Interrupt code for Set IP Address
2	192	First byte of IP address
3	168	Second byte of IP address
4	100	Third byte of IP address
5	100	Fourth byte of IP address

### See Also

Use DHCP

Get Static IP Address

## 3.3.2. SET STATIC SUBNET MASK

### Description

Sets the static subnet mask to be used when DHCP (dynamic host control protocol) is disabled. Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	202	Interrupt code for Set Subnet Mask
2	IP_Byte0	First byte of subnet mask
3	IP_Byte1	Second byte of subnet mask
4	IP_Byte2	Third byte of subnet mask
5	IP_Byte3	Fourth byte of subnet mask
6 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To set the static subnet mask to 255.255.255.0, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	202	Interrupt code for Set Subnet Mask
2	255	First byte of subnet mask
3	255	Second byte of subnet mask
4	255	Third byte of subnet mask
5	0	Fourth byte of subnet mask

### See Also

Use DHCP

Get Static Subnet Mask

## 3.3.3. SET STATIC NETWORK GATEWAY

### Description

Sets the network gateway IP address to be used when DHCP (dynamic host control protocol) is disabled.

### Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	203	Interrupt code for Set Network Gateway
2	IP_Byte0	First byte of network gateway IP address
3	IP_Byte1	Second byte of network gateway IP address
4	IP_Byte2	Third byte of network gateway IP address
5	IP_Byte3	Fourth byte of network gateway IP address
6 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To set the static IP address to 192.168.100.0, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	203	Interrupt code for Set Network Gateway
2	192	First byte of IP address
3	168	Second byte of IP address
4	100	Third byte of IP address
5	0	Fourth byte of IP address

### See Also

Use DHCP

Get Static Network Gateway

## 3.3.4. SET HTTP PORT

### Description

Sets the port to be used for HTTP communication (default is port 80).

### Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	204	Interrupt code for Set HTTP Port
2	Port_Byte0	First byte (MSB) of HTTP port value:
		Port_Byte0 = INTEGER (Port / 256)
3	Port_Byte1	Second byte (LSB) of HTTP port value:
		Port_byte1 = Port - (Port_Byte0 * 256)
4 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To set the HTTP port to 8080, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	204	Interrupt code for Set HTTP Port
2	31	Port_Byte0 = INTEGER (8080 / 256)
3	144	Port_byte1 = 8080 - (31 * 256)

### See Also

### Get HTTP Port

## 3.3.5. USE PASSWORD

### Description

Enables or disables the requirement to password protect the HTTP / Telnet communication. Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	205	Interrupt code for Use Password
2	PW_Mode	0 = password not required (default)
		1 = password required
3 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To enable the password requirement for Ethernet communication, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	205	Interrupt code for Use Password
2	1	Enable password requirement

### See Also

Set Password

Get Password Status

Get Password

### 3.3.6. SET PASSWORD

Sets the password to be used for Ethernet communication (when password security is enabled, maximum 20 characters.

### Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	206	Interrupt code for Set Password
2	PW_Length	Length (number of characters) of the password
3 to n	PW_Char	Series of ASCII character codes (1 per byte) for the Ethernet password
n + 1 to 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 to 63	Not significant	Any value

### Example

To set the password to Pass\_123, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	206	Interrupt code for Set Password
2	8	Length of password (8 characters)
3	80	ASCII character code for P
4	97	ASCII character code for a
5	115	ASCII character code for s
6	115	ASCII character code for s
7	95	ASCII character code for _
8	49	ASCII character code for 1
9	50	ASCII character code for 2
10	51	ASCII character code for 3

### See Also

Use Password

Reset Ethernet Configuration

© 2025 Mini-Circuits

### 3.3.7. USE DHCP

### Description

Enables or disables DHCP (dynamic host control protocol). With DHCP enabled, the attenuators Ethernet / IP configuration is assigned by the network and any user defined static IP settings are ignored. With DHCP disabled, the user defined static IP settings are used.

### Transmit Array

1			
	Byte	Data	Description
	0	250	Interrupt code for Set Ethernet Configuration
	1	207	Interrupt code for Use DHCP
	2	DHCP_Mode	0 = DCHP disabled (static IP settings in use)
			1 = DHCP enabled (default - dynamic IP in use)
	3 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To enable DHCP for Ethernet communication, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	207	Interrupt code for Use DHCP
2	1	Enable DHCP

### See Also

Use DHCP

Get DHCP Status

Get Dynamic Ethernet Configuration

## 3.3.8. GET STATIC IP ADDRESS

### Description

Gets the static IP address (configured by the user) to be used when DHCP (dynamic host control protocol) is disabled.

Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	201	Interrupt code for Get IP Address
2 - 63	Not significant	Any value

### **Returned Array**

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	IP_Byte0	First byte of IP address
2	IP_Byte1	Second byte of IP address
3	IP_Byte2	Third byte of IP address
4	IP_Byte3	Fourth byte of IP address
5 - 63	Not significant	Any value

### Example

The following returned array would indicate that a static IP address of 192.168.100.100 has been configured:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	192	First byte of IP address
2	168	Second byte of IP address
3	100	Third byte of IP address
4	100	Fourth byte of IP address

### See Also

### Use DHCP

Set Static IP Address

## 3.3.9. GET STATIC SUBNET MASK

### Description

Gets the subnet mask (configured by the user) to be used when DHCP (dynamic host control protocol) is disabled.

### Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	202	Interrupt code for Get Subnet Mask
2 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	IP_Byte0	First byte of subnet mask
2	IP_Byte1	Second byte of subnet mask
3	IP_Byte2	Third byte of subnet mask
4	IP_Byte3	Fourth byte of subnet mask
5 - 63	Not significant	Any value

### Example

The following returned array would indicate that a subnet mask of 255.255.255.0 has been configured:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	255	First byte of subnet mask
2	255	Second byte of subnet mask
3	255	Third byte of subnet mask
4	0	Fourth byte of subnet mask

### See Also

Use DHCP

Set Static Subnet Mask

## 3.3.10. GET STATIC NETWORK GATEWAY

### Description

Gets the static IP address (configured by the user) of the network gateway to be used when DHCP (dynamic host control protocol) is disabled.

### Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	203	Interrupt code for Get Network Gateway
2 - 63	Not significant	Any value

### **Returned Array**

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	IP_Byte0	First byte of IP address
2	IP_Byte1	Second byte of IP address
3	IP_Byte2	Third byte of IP address
4	IP_Byte3	Fourth byte of IP address
5 - 63	Not significant	Any value

### Example

The following returned array would indicate that a network gateway IP address of 192.168.100.0 has been configured:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	192	First byte of IP address
2	168	Second byte of IP address
3	100	Third byte of IP address
4	0	Fourth byte of IP address

### See Also

### Use DHCP

Set Static Network Gateway

## 3.3.11. GET HTTP PORT

### Description

Gets the port to be used for HTTP communication (default is port 80).

### Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	204	Interrupt code for Get HTTP Port
2 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	Port_Byte0	First byte (MSB) of HTTP port value:
2	Port_Byte1	Second byte (LSB) of HTTP port value:
		Port = (Port_Byte0 * 256) + Port_Byte1
3 - 63	Not significant	Any value

### Example

The following returned array would indicate that the HTTP port has been configured as 8080:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	31	
2	144	Port = (31 * 256) + 144
		= 8080

See Also

Set HTTP Port

## 3.3.12. GET PASSWORD STATUS

### Description

Checks whether the device has been configured to require a password for HTTP / Telnet communication.

### Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	205	Interrupt code for Get Password Status
2 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	251	Interrupt code for Set Ethernet Configuration
1	PW_Mode	0 = password not required (default)
		1 = password required
2 - 63	Not significant	Any value

### Example

The following returned array indicates that password protection is enabled:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	1	Password protection enabled

### See Also

Use Password

Set Password

Get Password

## 3.3.13. GET PASSWORD

### Description

Gets the password to be used for Ethernet communication (when password security is enabled, maximum 20 characters.

### Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	206	Interrupt code for Get Password
2 - 63	Not significant	Any value

### **Returned Array**

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	PW_Length	Length (number of characters) of the password
2 to n	PW_Char	Series of ASCII character codes (1 per byte) for the
		Ethernet password
n - 63	Not significant	Any value

### Example

The following returned array indicated that the password has been set to Pass\_123:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	8	Length of password (8 characters)
2	80	ASCII character code for P
3	97	ASCII character code for a
4	115	ASCII character code for s
5	115	ASCII character code for s
6	95	ASCII character code for _
7	49	ASCII character code for 1
8	50	ASCII character code for 2
9	51	ASCII character code for 3

### See Also

Use Password

Set Password

Get Password Status

© 2025 Mini-Circuits

## 3.3.14. GET DHCP STATUS

### Description

Checks whether DHCP (dynamic host control protocol) is enabled or disabled. With DHCP enabled, the attenuators Ethernet / IP configuration is assigned by the network and any user defined static IP settings are ignored. With DHCP disabled, the user defined static IP settings are used.

### Transmit Array

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	207	Interrupt code for Get DHCP Status
2 - 63	Not significant	Any value

### **Returned Array**

Byte	Data	Description
0	251	Interrupt code for Set Ethernet Configuration
1	DCHP_Mode	0 = DCHP disabled (static IP settings in use)
		1 = DHCP enabled (default - dynamic IP in use)
2 - 63	Not significant	Any value

### Example

The following returned array indicates that DHCP is enabled:

Byte	Data	Description
0	251	Interrupt code for Get Ethernet Configuration
1	1	DHCP enabled

### See Also

Use DHCP

Get Dynamic Ethernet Configuration

## 3.3.15. GET DYNAMIC ETHERNET CONFIGURATION

### Description

Returns the IP address, subnet mask and default gateway currently used by the device. If DHCP is enabled then these values are assigned by the network DHCP server. If DHCP is disabled then these values are the static configuration defined by the user.

### Transmit Array

Byte	Data	Description
0	253	Interrupt code for Get Dynamic Ethernet Configuration
1 - 63	Not significant	Any value

### Returned Array

		-
Byte	Data	Description
0	253	Interrupt code for Get Dynamic Ethernet Configuration
1	IP_Byte0	First byte of IP address
2	IP_Byte1	Second byte of IP address
3	IP_Byte2	Third byte of IP address
4	IP_Byte3	Fourth byte of IP address
5	SM_Byte0	First byte of subnet mask
6	SM_Byte1	Second byte of subnet mask
7	SM_Byte2	Third byte of subnet mask
8	SM_Byte3	Fourth byte of subnet mask
9	NG_Byte0	First byte of network gateway IP address
10	NG_Byte1	Second byte of network gateway IP address
11	NG_Byte2	Third byte of network gateway IP address
12	NG_Byte3	Fourth byte of network gateway IP address
13 - 63	Not significant	Any value

Example

The following returned array would indicate the below Ethernet configuration is active:

- IP Address: 192.168.100.100
- Subnet Mask: 255.255.255.0
- Network Gateway: 192.168.100.0

Byte	Data	Description
0	253	Interrupt code for Get Dynamic Ethernet Configuration
1	192	First byte of IP address
2	168	Second byte of IP address
3	100	Third byte of IP address
4	100	Fourth byte of IP address
5	255	First byte of subnet mask
6	255	Second byte of subnet mask
7	255	Third byte of subnet mask
8	0	Fourth byte of subnet mask
9	192	First byte of network gateway IP address
10	168	Second byte of network gateway IP address
11	100	Third byte of network gateway IP address
12	0	Fourth byte of network gateway IP address

See Also

Use DHCP

Get DHCP Status

## 3.3.16. GET MAC ADDRESS

### Description

Returns the MAC address of the device.

### Transmit Array

Byte	Data	Description
0	252	Interrupt code for Get MAC Address
1 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	252	Interrupt code for Get MAC Address
1	MAC_Byte0	First byte of MAC address
2	MAC_Byte1	Second byte of MAC address
3	MAC_Byte2	Third byte of MAC address
4	MAC_Byte3	Fourth byte of MAC address
5	MAC_Byte4	Fifth byte of MAC address
6	MAC_Byte5	Sixth byte of MAC address
7 - 63	Not significant	Any value

### Example

The following returned array would indicate a MAC address (in decimal notation) of 11:47:165:103:137:171:

Byte	Data	Description
0	252	Interrupt code for Get MAC Address
1	11	First byte of MAC address
2	47	Second byte of MAC address
3	165	Third byte of MAC address
4	103	Fourth byte of MAC address
5	137	Fifth byte of MAC address
6	171	Sixth byte of MAC address

See Also

Get Dynamic Ethernet Configuration

## 3.3.17. ENABLE / DISABLE ETHERNET

### Description

Enable or disable Ethernet communication. Disabling Ethernet control is recommended when not needed, in order to reduce current consumption.

### Transmit Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	208	Interrupt code for Enable / Disable Ethernet
2	Mode	0 = Ethernet disabled
		1 = Ethernet enabled
3 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1 - 63	Not significant	Any value

### Example

To enable Ethernet control, the transmit array is:

Byte	Data	Description
0	250	Interrupt code for Set Ethernet Configuration
1	208	Interrupt code for Enable / Disable Ethernet
2	1	Enable Ethernet control

## 3.3.18. RESET ETHERNET CONFIGURATION

### Description

Forces the device to reset and adopt the latest Ethernet configuration. Must be sent after any changes are made to the configuration.

### Transmit Array

Byte	Data	Description
0	101	Reset Ethernet configuration sequence
1	101	Reset Ethernet configuration sequence
2	102	Reset Ethernet configuration sequence
3	103	Reset Ethernet configuration sequence
4 - 63	Not significant	Any value

### Returned Array

Byte	Data	Description
0	101	Confirmation of reset Ethernet configuration sequence
1 - 63	Not significant	Any value

## 4. Ethernet Control API (RC Models Only)

Control of the device via Ethernet TCP / IP networks involves sending the SCPI commands / queries detailed below via HTTP or Telnet. SSH is also available as an option for secure communication with Mini-**Circuits'** latest generation of power sensors.

In addition, UDP is supported for discovering available systems on the network.

These protocols are widely supported and straightforward to implement in most programming environments. Any Internet browser can be used as a console / tester for HTTP control by typing the full URL directly into the address bar. Telnet and SSH are supported by a number of console applications, including PuTTY.

## 4.1. Supported Models

The list of models with Ethernet interfaces is summarized below along with the features / capabilities supported. The following sections provide further detail on each feature.

Model Name	SSH	Default	Ethernet Configuration	Default Link-Local
Moder Name	Supported	Ethernet State	Options	IP Supported
PWR-6RMS-RC	No	Enabled	Via USB only	Firmware A3 or later
PWR-6LRMS-RC	No	Enabled	Via USB only	Firmware A3 or later
PWR-8GHS-RC	No	Enabled	Via USB only	Firmware A4 or later
	No	Enabled	Via USB or Ethernet	Firmware A5 or later
FVVK-OF-RC			(firmware xx or later)	
PWR-8PW-RC	No	Disabled	Via USB or Ethernet	Yes
PWR-9PWHS-RC	Yes	Disabled	Via USB or Ethernet	Yes
PWR-9RMS-RC	Yes	Disabled	Via USB or Ethernet	Yes
PWR-18PWHS-RC	Yes	Disabled	Via USB or Ethernet	Yes
PWR-18RMS-RC	Yes	Disabled	Via USB or Ethernet	Yes
PWR-40PW-RC	Yes	Disabled	Via USB or Ethernet	Yes

## 4.2. Enabling Ethernet Control

The models listed above with a default Ethernet state listed as "disabled" ship with the Ethernet control circuitry turned off in order to reduce current consumption. The first connection for these models must therefore be by USB in order to enable the Ethernet controller. Once a USB connection has been established, the Ethernet interface can be enabled either using the GUI or API.

For models where the default Ethernet State is "enabled", both USB and Ethernet control are available from first use and there is no option disable the Ethernet interface.

## 4.3. Configuring Ethernet Settings

The device's Ethernet IP settings can be configured using the USB connection for all models. Some models also support configuration of the Ethernet IP settings whilst connected by Ethernet. If a connection cannot be established, it may indicate an invalid configuration was created (for example a static IP address which clashes with another device on the network). The Ethernet settings can always be overwritten by connecting to the device using the USB connection.

© 2025 Mini-Circuits

## 4.4. Default Ethernet Configuration

Mini-Circuits' products ship with DHCP enabled by default so in most cases the device should be assigned a dynamic IP address when connected to the network. The assigned IP can be identified from the network administrator, by using UDP to broadcast a query, or by using the USB connection. The latter 2 options can be accomplished using the Mini-Circuits GUI, or via a custom program.

Once a valid IP address has been assigned and identified it can be re-configured in multiple ways:

- 1. Using the Windows GUI when connected by USB
- 2. Using the API when connected by USB or Ethernet
- 3. Using Mini-Circuits' HTML configuration tool when connected by Ethernet

## 4.5. Default Link-Local / Auto IP Address

Where supported, a **default "link-local" auto IP address will be assumed when DHCP is enabled but the device** does not receive a valid response from a DHCP server. This could be the case on networks with no DHCP server or when the device is connected directly via an Ethernet cable to a PC instead of via a network.

The default static / link-local IP address for all Mini-Circuits devices with the relevant firmware is 169.254.10.10.

The default auto-IP features provide a method to implement a static IP configuration, without first relying on DHCP, or resorting to the USB connection. The process would be:

- 1. Connect the device directly to a PC using the Ethernet cable
- 2. No DHCP response will be received from the PC so the device will assume the default auto-IP
- 3. Connect to the device on 169.254.10.10
- 4. Disable DHCP, set the required static IP configuration and reset the device
- 5. Reconnect using the updated IP configuration

## 4.6. Direct Ethernet Cable Connection to PC

It may be necessary to set a compatible TCP / IP configuration on a PC in order to establish a direct connection by Ethernet cable between the device and PC rather than via a network. The values can be chosen arbitrarily as long as a valid and compatible range is applied to both PC and Mini-Circuits device. The key points are:

- 1. Set different IP addresses on the same subnet for the PC and device
- 2. Set another different IP address on the same subnet as the network gateway IP, using the same value on both PC and Mini-Circuits device
- 3. Set the same subnet mask on PC and device (ensuring the mask allows the above IP range)

An example of a working configuration is shown below, with the PC settings on the left and the static IP settings for the Mini-Circuits device on the right.

Statia Canfiguration

		<u>state comparation.</u>
<ul> <li>Ose the following IP address</li> </ul>		IP Address:
IP address:	192.168.100.1	
Subnet mask:	255 . 255 . 255 . 0	
Default gateway:	192.168.100.0	Subnet Mask:
Obtain DNS server address	automatically	255 255 255 0
Ose the following DNS serve	r addresses:	
Preferred DNS server:	8 . 8 . 8 . 8	Network Gateway:
Alternate DNS server:		192 168 100 0

## 4.7. Discovering Connected Devices Using UDP

Limited support of UDP is provided for the purpose of discovering Mini-Circuits devices of the same family which are connected to the network. Full control of those units is then accomplished using SSH, HTTP or Telnet, as detailed previously.

### Limitations

UDP is a simple transmission protocol that provides no method for error correction or guarantee of receipt. There are routing limitations with UDP broadcast queries which mean it is not usually possible to locate connected devices beyond the local subnet.

### UDP Ports

Mini-Circuits devices are configured to listen on UDP port 4950 and answer on UDP port 4951. Communication on these ports must be allowed through the computer's firewall in order to use UDP for device discovery.

### Transmission

The command MCL\_POWERSENSOR? should be sent as a broadcast query to the broadcast address of the local network using UDP protocol on port 4950. The broadcast address is worked out from a bitwise OR operation of **the host PC's IP address** and the bit-complement of its subnet mask.

### Receipt

All Mini-Circuits power sensors that receive the request will respond with the following information (each field separated by CrLf) on port 4951:

- Model Name
- Serial Number
- IP Address/Port
- Subnet Mask
- Network Gateway
- MAC Address

### Example

Sent Data:	MCL_POWERSENSOR?	
Received Data:	Model Name: PWR-8GHS-RC Serial Number: 11402120001 IP Address=192.168.9.101 Port: Subnet Mask=255.255.0.0 Network Gateway=192.168.9.0 Mac Address=D0-73-7F-82-D8-01	80
	Model Name: PWR-8GHS-RC Serial Number: 11402120002 IP Address=192.168.9.102 Port: Subnet Mask=255.255.0.0 Network Gateway=192.168.9.0 Mac Address=D0-73-7F-82-D8-02	80

## 4.8. SSH Communication

SSH communication is supported as standard on all Mini-Circuits' signal generators except SSG-6000RC & SSG-6001RC.

SSH allows secure communication with the device, using the configured SSH port (default is port 22) and password. The default username is ssh\_user.

SSH is widely supported and can be implemented in most programming environments. Alternatively, a client such as PuTTY can be used as a console to quickly establish an SSH connection and control the system.



## 4.9. HTTP Communication

HTTP Get / Post are supported. The basic format of the HTTP command:

### http://ADDRESS:PORT/PWD;COMMAND

Where:

- http:// is required
- ADDRESS = IP address (required)
- PORT = TCP/IP port (can be omitted if port 80 is used)
- PWD = Password (can be omitted if password security is not enabled)
- COMMAND = Command / query to send to the device

Example 1:

### http://192.168.100.100:800/PWD=123;:FREQ:1000

- The power sensor has IP address 192.168.100.100 and uses port 800
- Password security is enabled and set to "123"
- The command is to set the compensation frequency to 1000MHz

### Example 2:

### http://10.10.10/:POWER?

- The power sensor has IP address 10.10.10.10 and uses the default port 80
- Password security is disabled
- The query is to return the current power reading

## 4.10. Telnet Communication

Communication is started by creating a Telnet connection to the **device's** IP address. On successful connection the **"line feed" character will be returned**. If the system has a password enabled then this must be sent as the first command after connection.

Each command must be terminated with the carriage return and line-feed characters (\r\n). Responses will be similarly terminated. A basic example of the Telnet communication structure using the Windows Telnet Client is summarized below:

1) Set up Telnet connection to a power sensor with IP address 192.168.9.73

G:\Windows\system32\telnet.exe	
Welcome to Microsoft Telnet Client	A
Escape Character is 'CTRL+]'	
Microsoft Telnet> open 192.168.9.73	
	-

2) The "line feed" character is returned indicating the connection was successful:

🛃 Telnet 192.168.9.73	- • •
	<u>^</u>
	<b>*</b>

3) The password (if enabled) must be sent as the first command in the format "PWD=x;". A return value of "1" indicates success:

Teinet 192.168.9.73	
PWD=123	
	-

4) Any number of commands and queries can be sent as needed:



5) Use the control and "]" keys to end the session.

## 5. SCPI Commands for Power Sensor Control

This section describes a series of ASCII text commands based on SCPI (Standard Commands for Programmable Instruments) that provide an additional control approach for Mini-**Circuits'** RC series power sensors. These commands can be sent using any of the APIs detailed in this manual.

The SCPI commands / queries are case insensitive and sent as an ASCII text string (up to 63 characters). The response from the system is also in the form of an ASCII text string.

If an unrecognized command/query is received the sensor will return:

-99 Unrecognized Command. Model=[ModelName] SN=[SerialNumber]

## 5.1. SCPI - General Functions

These functions apply to Mini-Circuits' RC series power sensors.

Description	Command / Query
Get Model Name	:MN?
Get Serial Number	:SN?
Get Firmware	:FIRMWARE?
Get Temperature Units	:TEMP:FORMAT?
Set Temperature Units	:TEMP:FORMAT:[units]
Get Internal Temperature	:TEMP?
Get Compensation Frequency	:FREQ?
Set Compensation Frequency	:FREQ:[freq]

### 5.1.1. GET MODEL NAME

### :MN?

Return the Mini-Circuits model name.

Applies To

Mini-Circuits' RC series power sensors.

### Return Value

MN=[model]		
Value	Descriptior	
[model]	Model name	e of the connected device
Examples		
String to Sen	d	String Returned
:MN?		MN=PWR-18PWHS-RC
HTTP Impleme	entation:	http://10.10.10/:MN?

© 2025 Mini-Circuits

## 5.1.2. GET SERIAL NUMBER

### :SN?

Returns the serial number.

Applies To

Mini-Circuits' RC series power sensors.

Return Value

SN=[serial]		
Value	Description	1
[serial]	Serial numb	per of the connected device
Examples		
String to Se	nd	String Returned
· CND		CN_100001000E

String to Send	String Returned
:SN?	SN=12208010025

HTTP Implementation: http://10.10.10/:SN?

### 5.1.3. GET FIRMWARE

### :FIRMWARE?

Returns the internal firmware version.

Applies To

Mini-Circuits' RC series power sensors.

Return Value

Value	Description
[firmware]	The current firmware version, for example "B3".
Examples	

String to Send	String Returned
:FIRMWARE?	B3

HTTP Implementation: http://10.10.10/:FIRMWARE?

Mini-Circuits

## 5.1.4. GET TEMPERATURE UNITS

### :TEMP:FORMAT?

Returns the units for internal temperature readings.

Applies To

Mini-Circuits' RC series power sensors.

### Return String

Value	Description
F	Temperature measurements in degrees Fahrenheit
С	Temperature measurements in degrees Celsius

### Examples

String to Send	String Returned
:TEMP:FORMAT?	C

HTTP Implementation:

http://10.10.10.10/:TEMP:FORMAT?

### 5.1.5. SET TEMPERATURE UNITS

### :TEMP:FORMAT:[units]

Sets the units for internal temperature readings.

Applies To

Mini-Circuits' RC series power sensors.

### Parameters

Value	Description
F	Temperature readings in degrees Fahrenheit
С	Temperature readings in degrees Celsius

### **Return String**

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String to Send	String Returned
:TEMP:FORMAT:C	1

HTTP Implementation:

http://10.10.10/:TEMP:FORMAT:C

## 5.1.6. GET INTERNAL TEMPERATURE

### :TEMP?

Returns the internal temperature of the power sensor. Note: The reading provides an indication but is not calibrated.

Applies To

Mini-Circuits' RC series power sensors.

Return String

Variable	Description
[temperature]	Internal temperature reading
Examples	
String to Send	String Returned
:TEMP?	+25.50
HTTP Implementa	tion: http://10.10.10.10/:TEMP?

© 2025 Mini-Circuits

Mini-Circuits

## 5.1.7. GET COMPENSATION FREQUENCY

### :FREQ?

Returns the frequency currently set for calibrating the input power measurements.

Applies To

Mini-Circuits' RC series power sensors.

### Return String

Variable	Description	
[freq]	Compensation frequency in MHz	
Examples		
String to Se	nd String Returned	

:FREQ? 2500.000000 MHz

HTTP Implementation: http://10.10.10/:FREQ?

## 5.1.8. SET COMPENSATION FREQUENCY

## :FREQ:[freq]

Sets the compensation frequency for calibrating input power measurements. This parameter must be set to ensure measurement accuracy.

Note: PWR series power sensors do not have frequency selectivity.

Applies To

Mini-Circuits' RC series power sensors.

### Parameters

Variable	Description	
[freq]	Compensation frequency in MHz	
Return String		
Value	Description	
0 - Failed	Command failed	
1 - Succes	S Command completed successfully	
Examples		
String to Se	end String Returned	
:FREQ:2500	1	

HTTP Implementation:

http://10.10.10/:FREQ:2500

## 5.2. SCPI - Average Power Sensor Measurements

Description	Command / Query
Get Measurement Mode	:MODE?
Set Measurement Mode	:MODE:[speed]
Get Sample Time	:SAMPLETIME?
Set Sample Time	:SAMPLETIME:[time]
Read Average Power	:POWER?
Read Voltage	:VOLTAGE?

### 5.2.1. GET MEASUREMENT MODE

### :MODE?

Indicates the measurement mode of the power sensor; "low noise", "fast sampling" or "fastest sampling". The specifications for these modes are defined in the individual model datasheets. The default is "low noise" mode.

Applies To

- PWR-xGHS-RC Series (CW average power sensors with an Ethernet interface)
- PWR-6RMS-RC (true RMS power sensors with an Ethernet interface)
- PWR-6LRMS-RC (true RMS power sensors with an Ethernet interface)

### Return String

Value	Description
0	Low noise mode
1	Fast sampling mode
2	Fastest sampling mode

Examples

String to Send	String Returned
:MODE?	1

HTTP Implementation:

http://10.10.10.10/:MODE?

## 5.2.2. SET MEASUREMENT MODE

### :MODE:[speed]

Sets the measurement mode of the power sensor between "low noise", **"fast sampling" and "fastest sampling"** modes. The specifications for these modes are defined in the individual model datasheets. The default is "low noise" mode.

Applies To

- PWR-xGHS-RC Series (CW average power sensors with an Ethernet interface)
- PWR-6RMS-RC (true RMS power sensors with an Ethernet interface)
- PWR-6LRMS-RC (true RMS power sensors with an Ethernet interface)

### Parameters

Variable	Value	Description
[speed]	0	Low noise mode
	1	Fast sampling mode
	2	Fastest sampling mode

### Return String

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String to Send	String Returned
:MODE:1	1

HTTP Implementation:

http://10.10.10.10/:MODE:1

Mini-Circuits

## 5.2.3. GET SAMPLE TIME

### :SAMPLETIME?

Returns the sample period for power measurements, from 10  $\mu s$  to 1 s.

Applies To

- PWR-xP Series Peak & average power sensors
- PWR-18RMS-RC RMS power sensor

### Return String

Variable	Description
[time]	Sample time in microseconds (µS)
Examples	

String to Send	String Returned
SAMPLETIME?	10

HTTP Implementation:

http://10.10.10.10/:SAMPLETIME?

### 5.2.4. SET SAMPLE TIME

### :SAMPLETIME:[time]

Sets the sample period for power measurements, from 10  $\mu s$  to 1 s.

Applies To

- PWR-xP Series Peak & average power sensors
- PWR-18RMS-RC RMS power sensor

Parameters

Variable	Description
[time]	Sample time in microseconds (µS)

Return String

Value	Description
0 - Failed	Command failed
1 - Success	Command completed successfully

### Examples

String to Send	String Returned
:SAMPLETIME:10	1

HTTP Implementation:

http://10.10.10/:SAMPLETIME:10

## 5.2.5. READ AVERAGE POWER

### :POWER?

Returns the input power measurement in dBm. The compensation frequency should be set prior to reading power in order to achieve the specified accuracy.

Applies To

- PWR-xGHS-RC Series (CW average power sensors with an Ethernet interface)
- PWR-xRMS-RC Series (true RMS power sensors with an Ethernet interface)

### Return String

Variable	Description
	Input power measurement in dBm.
[power]	Note: a power value of -99.000 dBm indicates that the input signal level is below the sensor's
	useable range.

### Examples

String to Send	String Returned
:POWER?	-22.050 dBm

HTTP Implementation: http://10.10.10.10/:POWER?

See Also

Set Compensation Frequency

### 5.2.6. READ VOLTAGE

### :VOLTAGE?

Returns the raw voltage detected at the power sensor head. There is no calibration for temperature or frequency.

Applies To

- PWR-xGHS-RC Series (CW average power sensors with an Ethernet interface)
- PWR-xRMS-RC Series (true RMS power sensors with an Ethernet interface)

### Return String

iput voltage reading in mV
d String Returned
0.000105 Volt
(

HTTP Implementation:

http://10.10.10/:VOLTAGE?

## 5.3. SCPI – Measurement Averaging

Description	Command / Query
Get Averaging Mode	:AVG:STATE?
Set Averaging Mode	:AVG:STATE:[mode]
Get Average Count	:AVG:COUNT?
Set Average Count	:AVG:COUNT:[count]

## 5.3.1. GET AVERAGING MODE

### :AVG:STATE?

Indicates whether "averaging" mode is on or off (the default is averaging off).

Return String

Value	Description
0	Averaging mode disabled
1	Averaging mode enabled

### Examples

String to Send	String Returned
:AVG:STATE?	1

HTTP Implementation:

http://10.10.10/:AVG:STATE?

## 5.3.2. SET AVERAGING MODE

### :AVG:STATE:[mode]

Enables or disables the power sensor "averaging" mode.

### Parameters

Value	Description
0	Averaging mode disabled
1	Averaging mode enabled

**Return String** 

Value	Description
0	Command failed
1	Command completed successfully

Examples

String to Send	String Returned
:AVG:STATE:1	1

HTTP Implementation:

http://10.10.10/:AVG:STATE:1

© 2025 Mini-Circuits

## 5.3.3. GET AVERAGE COUNT

### :AVG:COUNT?

Returns the number of power readings (from 1 to 32) over which the measurement will be averaged when averaging mode is enabled.

### **Return String**

Variable	Description
[count]	The number of power readings over which to average the measurement

### Examples

String to Send	String Returned
:AVG:COUNT?	3

HTTP Implementation: http://10.10.10/:AVG:COUNT?

## 5.3.4. SET AVERAGE COUNT

### :AVG:COUNT:[count]

Sets the number of power readings (from 1 to 32) over which to average the measurement when averaging mode is enabled. The default value is 1 (average the reading over 1 measurement).

### Parameters

Variable	Description
[count]	The number of readings over which to average the power reading, from 1 to 32
Daturn Ctri	

### Return String

Value	Description
0	Command failed
1	Command completed successfully
Examples	6

String to Send	String Returned
:AVG:COUNT:10	1

HTTP Implementation: http://10.10.10.10/:AVG:COUNT:10
# 5.4. SCPI - Buffered Power Measurements

These functions allow a series of complete measurements to be taken and stored at **high speed to the device's** internal buffer. The buffered values can be recalled later for subsequent analysis. This method allows consecutive measurement sequences to be taken without additional USB or Ethernet communication delays.

### Applies To

• PWR-18RMS-RC

Description	Command / Query
Get Buffer Mode	BUFFEREDMODE?
Set Buffer Mode	BUFFEREDMODE:[mode]
Get Buffer Size	:BUFFERMODE:SIZE?
Set Buffer Size	:BUFFERMODE:SIZE:[size]
Read Buffered Power Measurements	:BUFFERMODE:BUFFER_[index]?

## 5.4.1. GET BUFFER MODE

### BUFFEREDMODE?

Check whether buffered power measurement mode is enabled or disabled. When enabled, a series of consecutive measurements is **saved at high speed to the device's internal buffer**, to support faster power measurements without USB / Ethernet communication delays.

Applies To

• PWR-18RMS-RC

### Return String

Value	Description
OFF	Buffer mode disabled
ON	Buffer mode enabled

### Examples

String to Send	String Returned
:BUFFEREDMODE?	1

HTTP Implementation: http://10.10.10/:BUFFEREDMODE?

## 5.4.2. SET BUFFER MODE

### BUFFEREDMODE:[mode]

Enable or disable buffered power measurements. When enabled, a series of consecutive measurements is **saved at high speed to the device's internal buffer**, to support faster power measurements without USB / Ethernet communication delays.

Enabling buffer mode initializes the buffer to an array of -99.00 values.

### Applies To

• PWR-18RMS-RC

### Parameters

OFF Buffer mode disabled	
ON Buffer mode enabled	

#### Return String

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String to Send	String Returned
:BUFFEREDMODE:ON	1

HTTP Implementation: http://10.10.10/:BUFFEREDMODE:ON

## 5.4.3. GET BUFFER SIZE

### :BUFFERMODE:SIZE?

Returns the size of the buffer to be used for buffered power measurements

Applies To

• PWR-18RMS-RC

### **Return String**

Variable	Description
[size]	Size of the buffer (1-100)

#### Examples

String to Send	String Returned
:BUFFERMODE:SIZE?	100

HTTP Implementation: http://10.10.10/:BUFFERMODE:SIZE?

### 5.4.4. SET BUFFER SIZE

### :BUFFERMODE:SIZE:[size]

Sets the size of the buffer to be used for buffered power measurements

### Applies To

• PWR-18RMS-RC

#### Parameters

Variable	Description
[size]	Size of the buffer (1-100)

#### **Return String**

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String to Send	String Returned
:BUFFERMODE:SIZE:100	1

HTTP Implementation: http://10.10.10.10/:BUFFERMODE:SIZE:100

## 5.4.5. READ BUFFERED POWER MEASUREMENTS

### :BUFFERMODE:BUFFER\_[index]?

Returns a packet of consecutive power measurements from the **sensor's internal buffer**. The number of measurements available is dictated by Set Buffer Size.

Each packet comprises up to 10 measurement values with 6 digits per value and no space or other separation characters between. An example response would be as below where the power measurement had stepped up from -10.85 dBm in 2 dB increments within the time frame:

-10.85 - 08.85 - 06.85 - 04.85 - 02.85 - 00.85 + 02.15 + 04.15 + 06.15 + 08.15

To ensure a consecutive sequence of measurements is retrieved, buffer mode can be disabled while the values are retrieved from the buffer. When buffer mode is enabled again the buffer will be initialized with an array of -99.00 values.

Applies To

• PWR-18RMS-RC

### Parameters

Variable	Value	Description
[index]	1_10	Return readings 1 to 10 from the buffer (the 10 oldest values)
	11_20	Return readings 11 to 20 from the buffer
	21_30	Return readings 21 to 30 from the buffer
	31_40	Return readings 31 to 40 from the buffer
	41_50	Return readings 41 to 50 from the buffer
	51_60	Return readings 51 to 60 from the buffer
	61_70	Return readings 61 to 70 from the buffer
	71_80	Return readings 71 to 80 from the buffer
	81_90	Return readings 81 to 90 from the buffer
	91_100	Return readings 91 to 100 from the buffer (the 10 most recent values)

### Return String

### [val\_0][val\_1][val\_2][val\_3][val\_4][val\_5][val\_6][val\_7][val\_8][val\_9]

Variable	Description
[val_n]	Series of discrete power measurements, presented in dBm using 6 digits per measurement (including polarity and decimal places).

#### Examples

String to Send	String Returned
:BUFFERMODE:BUFFER_1_10?	-10.85-08.85-06.85-04.85-02.85-00.85+02.15+04.15+06.15+08.15
:BUFFERMODE:BUFFER_11_20?	+10.15+12.15+14.15+16.15+18.15+20.15+22.15+24.15+26.15+28.15

HTTP Implementation:

http://10.10.10/:BUFFERMODE:BUFFER\_1\_10?

# 5.5. SCPI – Trigger Settings

Description	Command / Query
Get Trigger Mode	:TRIGGER:MODE?
Set Trigger Mode	:TRIGGER:MODE:[type]
Get External Trigger Type	:TRIGGER:EXTERNAL:[type]?
Set External Trigger Type	:TRIGGER:EXTERNAL:[type]
Get Internal Trigger Edge	:TRIGGER:INTERNAL:[type]?
Set Internal Trigger Edge	:TRIGGER:INTERNAL:[type]
Get Trigger Delay	:TRIGGER:DELAY?
Set Trigger Delay	:TRIGGER:DELAY:[time]
Get Trigger Timeout	:TRIGGER:TIMEOUT?
Set Trigger Timeout	:TRIGGER:TIMEOUT:[period]
Get Internal Trigger Level Threshold	:TRIGGER:LEVEL?
Set Internal Trigger Level Threshold	:TRIGGER:LEVEL:[power]
Get Internal Trigger Width Criteria	:TRIGGER:PULSEWIDTH:MODE?
Set Internal Trigger Width Criteria	:TRIGGER:PULSEWIDTH:MODE:[mode]
Get Internal Trigger Width Threshold	:TRIGGER:PULSEWIDTH:[threshold]:VAL?
Set Internal Trigger Width Threshold	:TRIGGER:PULSEWIDTH:[threshold]:VAL:[width]
Get Trigger Delay	:TRIGGER:DELAY?
Set Trigger Delay	:TRIGGER:DELAY:[time]
Get Trigger Timeout	:TRIGGER:TIMEOUT?
Set Trigger Timeout	:TRIGGER:TIMEOUT:[period]
Get Trigger or Video Out Function	:EXTOUT:SELECT?
Set Trigger or Video Out Function	:EXTOUT:SELECT:[type]
Get Trigger Output Mode	:TRIGGEROUT:MODE?
Set Trigger Output Mode	:TRIGGEROUT:MODE:[mode]

## 5.5.1. GET TRIGGER MODE

### :TRIGGER:MODE?

Checks which trigger setting is currently in use.

Note: For internal / external trigger mode, the power measurement will time-out if no trigger is detected within the specified timeout period, following a "read power" request. In the event of a timeout, the last power measurement will be returned from the internal buffer.

### Applies To

Sensor Types	Models	Firmware Requirement
Dook & Average D & DW/Madele	PWR-8P-RC; PWR-8PW-RC;	All versions
Peak & Average - P & Pvv Iviodels	PWR-40PW-RC	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Return String

Value	Description	
FREE	Free-running trigger - Power measurements are taken continuously	
	Internal trigger - Power sampling starts when a valid trigger event is detected in the RF input signal.	
INTERNAL	Not available on RMS models. PWR-8P-RC & PWR-8PW-RC respond to a 3dB variation in the RF signal. PWR-40PW-RC and all PWHS models can be configured to respond to either a rising or falling signal passing a specific level. Refer to	
EXTERNAL	External trigger - Power sampling starts in response to either the rising or falling edge of an external TTL trigger input. Refer to Get External Trigger Edge	

#### Examples

String to Send	String Returned
:TRIGGER:MODE?	FREE
:TRIGGER:MODE?	INTERNAL
:TRIGGER:MODE?	EXTERNAL

HTTP Implementation: http://10.10.10/:TRIGGER:MODE?

## 5.5.2. SET TRIGGER MODE

### :TRIGGER:MODE:[type]

### Sets the event which triggers the start of the power sensor's sample period.

Note: For internal / external trigger mode, the power measurement will time-out if no trigger is detected within the specified timeout period, following a "read power" request. In the event of a timeout, the last power measurement will be returned from the internal buffer.

### Applies To

Sensor Types	Models	Firmware Requirement
	PWR-8P-RC; PWR-8PW-RC;	All versions
Peak & Average - P & Pvv Iviodels	PWR-40PW-RC	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Parameters

Variable	Value	Description	
	FREE Free-running trigger - Power measurements are taken continuously		
[type] INTERNAL EXTERNAL		Internal trigger - Power sampling starts when a valid trigger event is detected in the RF input signal.	
	INTERNAL	Not available on RMS models. PWR-8P-RC & PWR-8PW-RC respond to a 3dB variation in the RF signal. PWR-40PW-RC and all PWHS models can be configured to respond to either a rising or falling signal passing a specific level. Refer to	
	EXTERNAL	External trigger - Power sampling starts in response to either the rising or falling edge of an external TTL trigger input. Refer to Get External Trigger Edge	

#### Return String

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:TRIGGER:MODE:FREE	1
:TRIGGER:MODE:INTERNAL	1
:TRIGGER:MODE:EXTERNAL	1

HTTP Implementation: http://10.10.10.10/:TRIGGER:MODE:FREE

## 5.5.3. GET EXTERNAL TRIGGER EDGE

## :TRIGGER:EXTERNAL:[type]?

Indicates whether power sampling will start on the rising or falling edge of an external trigger input signal when the power sensor is operating in external trigger mode.

Use :TRIGGER:MODE: EXTERNAL to set external trigger mode.

### Applies To

Sensor Types	Models	Firmware Requirement
	PWR-8P-RC; PWR-8PW-RC;	All versions
Peak & Average - P & Pvv lviodels	PWR-40PW-RC	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Parameters

Variable	Value	Description
[type]	ONFALL	Power sampling starts on the falling edge of an external trigger input signal
	ONRISE	Power sampling starts on the rising edge of an external trigger input signal

#### **Return String**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:TRIGGER:EXTERNAL:ONFALL?	0
:TRIGGER:EXTERNAL:ONRISE?	1

HTTP Implementation: http://10.10.10/:TRIGGER:EXTERNAL:ONFALL?

© 2025 Mini-Circuits

## 5.5.4. SET EXTERNAL TRIGGER EDGE

## :TRIGGER:EXTERNAL:[type]

Sets whether power sampling will start on the rising or falling edge of an external trigger input signal when the power sensor is operating in external trigger mode.

Use :TRIGGER:MODE: EXTERNAL to set external trigger mode.

### Applies To

Sensor Types	Models	Firmware Requirement	
	PWR-8P-RC; PWR-8PW-RC;	Allyeroiono	
Peak & Average - P & Pvv lviodels	PWR-40PW-RC	All versions	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions	
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions	

### Parameters

Variable	Value	Description
[type]	ONFALL	Power sampling starts on the falling edge of an external trigger input signal
	ONRISE	Power sampling starts on the rising edge of an external trigger input signal

#### **Return String**

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:TRIGGER:EXTERNAL:ONFALL	1
:TRIGGER:EXTERNAL:ONRISE	1

HTTP Implementation: http://10.10.10/:TRIGGER:EXTERNAL:ONFALL

## 5.5.5. GET INTERNAL TRIGGER EDGE

## :TRIGGER:INTERNAL:[type]?

Indicates whether power sampling will start on the rising or falling edge of an internal trigger input signal when the power sensor is operating in internal trigger mode.

Use :TRIGGER:MODE:INTERNAL to set internal trigger mode.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average - PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

### Parameters

Variable	Value	Description
[type]	ONFALL	Check whether internal trigger on falling edge is set
	ONRISE	Check whether internal trigger on rising edge is set

### Return String

Value	Description
0	Condition is not set
1	Condition is set

#### Examples

String to Send	String Returned
:TRIGGER:INTERNAL:ONFALL?	0
:TRIGGER:INTERNAL:ONRISE?	1

HTTP Implementation: http://10.10.10/:TRIGGER:INTERNAL:ONFALL?

## 5.5.6. SET INTERNAL TRIGGER EDGE

### :TRIGGER:INTERNAL:[type]

Sets whether power sampling will start on the rising or falling edge of an external trigger input signal when the power sensor is operating in internal trigger mode.

Note: Setting the rising edge will automatically set the trigger model to internal (:TRIGGER:MODE:INTERNAL).

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

### Parameters

Variable	Value	Description
[type]	ONFALL	Power sampling starts on the falling edge of an internal trigger input signal
	ONRISE	Power sampling starts on the rising edge of an internal trigger input signal

### **Return String**

Value	Description
0	Command failed
1	Command completed successfully
Example	S

### Examples

String to Send	String Returned
:TRIGGER:INTERNAL:ONFALL	1
:TRIGGER:INTERNAL:ONRISE	1

HTTP Implementation: http://10.10.10/:TRIGGER:INTERNAL:ONFALL

## 5.5.7. GET INTERNAL TRIGGER LEVEL THRESHOLD

### :TRIGGER:LEVEL?

Returns the input power threshold at which an internal trigger event is registered. Use :TRIGGER:MODE:INTERNAL to set internal trigger mode.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PW Model	PWR-40PW-RC	All versions
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

#### **Return Values**

Variable	Description
[power]	The input power level in dBm at which an internal trigger is registered, from -20 to +20.

#### Examples

String to Send	String Returned
:TRIGGER:LEVEL?	-10

HTTP Implementation: http://10.10.10/:TRIGGER:LEVEL?

### 5.5.8. SET INTERNAL TRIGGER LEVEL THRESHOLD

### :TRIGGER:LEVEL:[power]

Sets the input power threshold at which an internal trigger event is registered. Use **:TRIGGER:MODE:INTERNAL** to set internal trigger mode.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PW Model	PWR-40PW-RC	All versions
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

### Parameters

Variable	Description
[power]	The input power level in dBm at which an internal trigger is registered, from -20 to +20.

### **Return Values**

Value	Description
0 - Failed	Command failed
1 - Success	Command completed successfully

#### Examples

String to Send	String Returned
:TRIGGER:LEVEL:-10	1

HTTP Implementation:

http://10.10.10/:TRIGGER:LEVEL:-10

© 2025 Mini-Circuits

## 5.5.9. GET INTERNAL TRIGGER WIDTH CRITERIA

### :TRIGGER:PULSEWIDTH:MODE?

Queries the criteria.for the internal trigger on pulse width function. The sensor can be set to trigger on an RF pulse width greater than or less than a specified value.

Applies To

Sensor Types			Models	Firmware Requirement
Peak & Average – PWHS Models		HS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	Contact Mini-Circuits
Return String				
Variable	Value	Description		
	0	Disable the p	oulse width trigger criteria	
[mode]	1	Trigger on p	ulse widths greater than a minimum value	Ś
	2	Trigger on p	ulse widths less than a maximum value	
Examples	Examples			
String to Send Stri		Stri	ng Returned	
:TRIGGER:PULSEWIDTH:MODE? 1		:MODE? 1		

HTTP Implementation: http://10.10.10/:TRIGGER:PULSEWIDTH:MODE?

© 2025 Mini-Circuits

## 5.5.10. SET INTERNAL TRIGGER WIDTH CRITERIA

### :TRIGGER:PULSEWIDTH:MODE:[mode]

Sets or disables the criteria.for the internal trigger on pulse width function. The sensor can be set to trigger on an RF pulse width greater than or less than a specified value. Set the pulse width value using Set Internal Trigger Width Threshold. Use in conjunction with the trigger level threshold.

- :TRIGGER:MODE:INTERNAL
- :TRIGGER:LEVEL:-10
- :TRIGGER:PULSEWIDTH:MODE:1
- :TRIGGER:PULSEWIDTH:MIN:10

#### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	Contact Mini-Circuits

#### Parameters

Variable	Value	Description		
[mode]	0	Disable the pulse width trigger criteria		
	1	Trigger on pulse widths greater than a minimum value		
	2	Trigger on pulse widths less than a maximum value		

#### Return String

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String Returned
1
1
1

HTTP Implementation: http://10.10.10.10/:TRIGGER:PULSEWIDTH:MODE:1

## 5.5.11. GET INTERNAL TRIGGER WIDTH THRESHOLD

### :TRIGGER:PULSEWIDTH:[threshold]:VAL?

Queries the pulse width for the internal trigger on pulse width function. The sensor can be set to trigger on an RF pulse width greater than or less than a specified value.

Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	Contact Mini-Circuits

#### Parameters

Variable	Value	Description
[threshold]	MIN	Check the minimum pulse width criteria
	MAX	Check the maximum pulse width criteria

### **Return Values**

Value	Description
[width]	The pulse width criteria

### Examples

String to Send	String Returned
:TRIGGER:PULSEWIDTH:MIN?	10
:TRIGGER:PULSEWIDTH:MAX?	100

HTTP Implementation: http://10.10.10.10/:TRIGGER:PULSEWIDTH:MIN?

## 5.5.12. SET INTERNAL TRIGGER WIDTH THRESHOLD

### :TRIGGER:PULSEWIDTH:[threshold]:VAL:[width]

Sets the pulse width for the internal trigger on pulse width function. The sensor can be set to trigger on an RF pulse width greater than or less than a specified value. Enable the trigger width threshold criteria using Set Internal Trigger Width Criteria. Use in conjunction with the trigger level threshold.

- :TRIGGER:MODE:INTERNAL
- :TRIGGER:LEVEL:-10
- :TRIGGER:PULSEWIDTH:MODE:1
- :TRIGGER:PULSEWIDTH:MIN:10

#### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	Contact Mini-Circuits

Parameters

Variable		Description
[threshold]	MIN	Trigger on pulse widths greater than the specified value
	MAX	Trigger on pulse widths less than the specified value
[width]		The pulse width to match

#### **Return Values**

Value	Description
0 - Failed	Command failed
1 - Success	Command completed successfully

#### Examples

String to Send	String Returned
:TRIGGER:PULSEWIDTH:MIN:10	1
:TRIGGER:PULSEWIDTH:MAX:100	1

HTTP Implementation: http://10.10.10/:TRIGGER:PULSEWIDTH:MAX:100

## 5.5.13. GET TRIGGER DELAY

### :TRIGGER:DELAY?

Indicates the delay to be applied between detection of a trigger signal and the start of power sampling. Applies to internal and external trigger modes.

Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PW Model	PWR-40PW-RC	All versions
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

### Return String

Variable	Description
[time]	Delay time in microseconds ( $\mu$ S) between trigger detection and the start of power sampling

#### Examples

String to Send	String Returned
:TRIGGER:DELAY?	100

HTTP Implementation:

http://10.10.10/:TRIGGER:DELAY?

### 5.5.14. SET TRIGGER DELAY

### :TRIGGER:DELAY:[time]

Sets the delay between detection of a trigger signal and the start of power sampling. Applies to internal and external trigger modes.

Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PW Model	PWR-40PW-RC	All versions
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

#### Parameters

Variable	Description
[time]	Delay time in microseconds ( $\mu$ S) between trigger detection and the start of power sampling

Return String

Value	Description
0	Command failed
1	Command completed successfully
Example	S

String to Send	String Returned
:TRIGGER:DELAY:100	1

HTTP Implementation:

http://10.10.10/:TRIGGER:DELAY:0

© 2025 Mini-Circuits

## 5.5.15. GET TRIGGER TIMEOUT

### :TRIGGER:TIMEOUT?

Returns the period in ms after which the power measurement will timeout if no trigger signal is detected in internal / external trigger mode. In the event of a timeout, the last power measurement will be returned from the internal buffer.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – P & PW Models	PWR-8P-RC	A9 or later
	PWR-8PW-RC	A1 or later
Peak & Average - PVV Models	PWR-40PW-RC	A3 or later
Peak & Average - PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

#### **Return Values**

Variable	Description
[period]	The trigger timeout period in ms, from 1 to 5000. 500 ms is the default setting.

### Examples

String to Send	String Returned
:TRIGGER:TIMEOUT?	500

HTTP Implementation: http://10.10.10/:TRIGGER:TIMEOUT?

## 5.5.16. SET TRIGGER TIMEOUT

### :TRIGGER:TIMEOUT:[period]

Sets the period in ms after which the power measurement will timeout if no trigger signal is detected in internal / external trigger mode. In the event of a timeout, the last power measurement will be returned from the internal buffer.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – P & PW Models	PWR-8P-RC	A9 or later
	PWR-8PW-RC	A1 or later
Peak & Average - Pvv Models	PWR-40PW-RC	A3 or later
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

#### Parameters

Variable	Description
[period]	The trigger timeout period in ms, from 1 to 5000. 500 ms is the default setting.

#### **Return Values**

Value	Description	
0 - Failed	Command failed	
1 - Success Command completed successfully		
Examples		
String to Send	String Returned	

:TRIGGER:TIMEOUT:500	1	
HTTP Implementation:		http://10.10.10.10/:TRIGGER:TIMEOUT:500

© 2025 Mini-Circuits

## 5.5.17. GET TRIGGER OR VIDEO OUT FUNCTION

### :EXTOUT:SELECT?

Indicates whether the trigger output is set to a TTL trigger signal or video output corresponding to the modulation of the RF input.

Applies To

PWR-xP Series - Peak & average power sensors

Return String

TRIG Trigger output port will provide a TTL signal (logic high for ~5 µs) after completing a measurement of the second se	
	urement
VIDE0 Trigger output port will provide a video signal corresponding to the modulation of the RF	input

### Examples

String to Send	String Returned
:EXTOUT:SELECT?	TRIG

HTTP Implementation: http

http://10.10.10.10/:EXTOUT:TRIGGER?

## 5.5.18. SET TRIGGER OR VIDEO OUT FUNCTION

### :EXTOUT:SELECT:[mode]

Sets trigger output between a TTL trigger signal or a video output corresponding to the modulation of the RF input.

Applies To

PWR-xP Series - Peak & average power sensors

### Parameters

Variable	Value	Description	
[made]	TRIG	Trigger output port will provide a TTL signal (logic high for ~5 $\mu s$ ) after completing a measurement	
VIDE0 Trigger output port will provide a video signal corresponding to th RF input		Trigger output port will provide a video signal corresponding to the modulation of the RF input	

### Return String

0 - Failed Command failed	
1 - Success Command completed successfully	

### Examples

String to Send	String Returned
:EXTOUT:SELECT:TRIG	1

HTTP Implementation:

http://10.10.10.10/:EXTOUT:SELECT:TRIG

© 2025 Mini-Circuits

## 5.5.19. GET TRIGGER OUTPUT MODE

### :TRIGGEROUT:MODE?

Check whether the trigger output is set to provide a single or repeating trigger level. The sensor must be set in internal trigger mode with the trigger output port set to the trigger out function:

When the trigger input is set to external or free, the trigger output is always active for the full duration of the sample period.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

#### Return String

Variable	Value	Description	
	ONCE	Trigger Out is high for only the first full pulse period.	
[mode]	EACHPULSE	Trigger Out follows the RF pulse sequence; active (high) for "on" time, inactive (low) for "off" time; resting at OV when not sampling.	

### Examples

String to Send	String Returned
:TRIGGEROUT:MODE?	ONCE

HTTP Implementation: http://10.10.10/:TRIGGEROUT:MODE?

## 5.5.20. SET TRIGGER OUTPUT MODE

### :TRIGGEROUT:MODE:[mode]

Sets the trigger output between a single or repeating trigger level. The sensor must be set in internal trigger mode with the trigger output port set to the trigger out function:

:TRIGGER:MODE:INTERNAL

#### :EXTOUT:SELECT:TRIG

When the trigger input is set to external or free, the trigger output is always active for the full duration of the sample period.

#### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average - PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

#### Parameters

Variable	Value	Description	
	ONCE	Trigger Out is high for only the first full pulse period.	
[mode]	EACHPULSE	Trigger Out follows the RF pulse sequence; active (high) for "on" time, inactive (low) for "off" time; resting at OV when not sampling.	

#### Return String

:TRIGGEROUT:MODE:ONCE

Value	Description
0 - Failed	Command failed
1 - Success Command completed successfully	
Examples	
String to Send	String Returned

:TRIGGEROUT:MODE:EACHPULSE	1

1

HTTP Implementation: http://10.10.10/:TRIGGEROUT:MODE:ONCE

# 5.6. SCPI – Peak Power Sensor Measurements

Description	Command / Query
Get Sample Time	:SAMPLETIME?
Set Sample Time	:SAMPLETIME:[time]
Get Video Filter Bandwidth	:BWFILTER?
Set Video Filter Bandwidth	:BWFILTER:[bandwidth]
Read Peak & Average Power	: POWER?
Read Initial Power Array	:POWER_ARRAY?
Read Subsequent Power Arrays	:POWER_ARRAY_EP[package]?
Real Time Peak Power – Return Power	:RTPEAK?
Real Time Peak Power – Reset Register	:RTPEAK:MODE:0

## 5.6.1. GET SAMPLE TIME

### :SAMPLETIME?

Returns the sample period in microseconds. Refer to the model datasheets for the allowed range.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – P & PW Models	PWR-8P-RC; PWR-8PW-RC;	All versions
	PWR-40PW-RC	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Return String

Variable	Desc	ription
[time]	Sample time in microseconds (µs)	
Examples		
String to Se	end	String Returned
SAMPLETIM	Ξ?	10

HTTP Implementation: http://10.10.10.10/:SAMPLETIME?

## 5.6.2. SET SAMPLE TIME

## :SAMPLETIME:[time]

Sets the sample period in microseconds. Refer to the model datasheets for the allowed range.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – P & PW Models	PWR-8P-RC; PWR-8PW-RC;	All versions
	PWR-40PW-RC	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

Parameters

Variable	Description
[time]	Sample time in microseconds (µs)

Return String

Value	Description
0 - Failed	Command failed
1 - Success	Command completed successfully
	, , , , , , , , , , , , , , , , , , ,

### Examples

String to Send	String Returned
:SAMPLETIME:10	1

HTTP Implementation: http://10.10.10.10/:SAMPLETIME:10

## 5.6.3. GET VIDEO FILTER BANDWIDTH

### :BWFILTER?

Returns the video filter bandwidth.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PW Models	PWR-8PW-RC; PWR-40PW-RC	All versions
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### **Return Values**

Value	Description
:300KHz	Average mode / video filter set to 300 kHz
:1.5MHZ	Video filter set to 1.5 MHz
:5MHZ	Video filter set to 5 MHz
:30MHZ	Video filter turned off (~30 MHz maximum bandwidth)

### Examples

String to Send	String Returned
:BWFILTER?	:300KHZ

HTTP Implementation:

http://10.10.10/:BWFILTER?

## 5.6.4. SET VIDEO FILTER BANDWIDTH

## :BWFILTER:[bandwidth]

Sets the video filter bandwidth.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PW Models	PWR-8PW-RC; PWR-40PW-RC	All versions
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Parameters

Variable	Value	Description
	300KHz	Average mode / video filter set to 300 kHz
[bandud dth]	1.5MHZ	Video filter set to 1.5 MHz
[bandwidth]	5MHZ	Video filter set to 5 MHz
	30MHZ	Video filter turned off (~30 MHz maximum bandwidth)

### **Return Values**

Value	Description
0 - Failed	Command failed
1 - Success	Command completed successfully
Examples	

String to Send	String Returned
:BWFILTER:300KHZ	1 - Success

HTTP Implementation: http://10.10.10.10/:BWFILTER:300KHZ

## 5.6.5. READ PEAK & AVERAGE POWER

### :POWER?

Returns the peak and average power measurement in dBm (separated by a space character) for the complete sample period of the sensor. The compensation frequency must be set prior to reading power in order to achieve the specified accuracy.

Note: In the event of a trigger timeout (no valid trigger detected within the specified timeout period), the measurement cycle will end and the last buffered result will be returned from memory. Consider adding a timer in the automation program to monitor the response time to a measurement request and then discard the returned result if it is unchanged and the elapsed time is equal to the timeout period.

### Applies To

Sensor Types	Models	Firmware Requirement
Dook & Average D & DW/Madela	PWR-8P-RC; PWR-8PW-RC;	All versions
Peak & Average - P & Pvv lviodels	PWR-40PW-RC	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions

### Return String

[pea	k]	[avg]	
- C - C - C - C - C - C - C - C - C - C		L 01	

Variable	Description
[peak]	Peak power level (dBm) measured over the sample period
[avg]	Average power level (dBm) measurement over the sample period

### Examples

String to Send	String Returned
: POWER?	-2.050 -25.250

HTTP Implementation: http://

http://10.10.10/:POWER?

## 5.6.6. READ INITIAL POWER ARRAY (ETHERNET CONTROL)

### :POWER ARRAY?

Carries out a power measurement and stores the series of discrete measurements values into internal memory, grouped into packages of 160 measurements.

The query returns the number of packages (p), the total number of measurements (m) and the first 160 measured values. The compensation frequency must be set prior to reading power in order to achieve the specified accuracy.

The number of discrete measurements taken is variable but approximately equally spaced in time so that the number of measurements / total sample time = approximate time per measurement.

If p is greater than 1 (ie: more than 160 discrete measurement values were stored) then the Read Subsequent Power Arrays method should be used to iteratively return each subsequent package of 160 measurement values.

Once all packages have been obtained, the full array of discrete power measurement values can be used for calculated analysis of the measured input signal, including pulse width, crest factor, rise / fall time and duty cycle for example.

Note: In the event of a trigger timeout (no valid trigger detected within the specified timeout period), the measurement cycle will end and the last buffered result will be returned from memory. Consider adding a timer in the automation program to monitor the response time to a measurement request and then discard the returned result if it is unchanged and the elapsed time is equal to the timeout period.

### Applies To

The following sensors only when controlled using the Ethernet connection:

Sensor Types	Models	Firmware Requirement	
Dook & Average D & DW/Madela	PWR-8P-RC; PWR-8PW-RC;	Allyersions	
Peak & Average - P & Pvv lviodels	PWR-40PW-RC	All versions	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions	

For USB control refer to:

- Read Peak & Average Power Array (Windows)
- Read Initial Power Array (Linux)

### **Return String**

### [p] [m] [val0] [val1] [val2] ...[ val159]

Variable	Description
[p]	Total number of packages (including initial package) containing power measurement data
[m]	Total number of discrete measurements, contained in all <b>p</b> packages
[valn]	Series of discrete power measurements (dBm), each multiplied by 100 to give an integer value

#### Examples

The power measurement is split over 5 packages, containing 804 discrete values and the first 160 values are -60.25 dBm, -60.00 dBm, -60.50 dBm... -60.25 dBm:

String to Send	String Returned	
: POWER_ARRAY?	5 804 -6025 -6000 -60506025	
HTTP Implementation:	http://10.10.10.10/:POWER ARRAY?	

HTTP Implementation:

© 2025 Mini-Circuits

## 5.6.7. READ SUBSEQUENT POWER ARRAYS (ETHERNET CONTROL)

### :POWER\_ARRAY\_EP[n]?

Follows on from Read Initial Power Array which carries out a power measurement and stores the series of discrete measurements in internal memory, grouped in packages of 160 measurements. The initial query returns the number of packages (p), the total number of measurements (m) and the first 160 measured values.

If p is greater than 1 (ie: more than 160 discrete measurement values were stored) then this Read Subsequent Power Arrays query should be used to iteratively return each subsequent package of 160 measurement values.

Once all packages have been obtained, the full array of discrete power measurement values can be used for calculated analysis of the measured input signal, including pulse width, crest factor, rise / fall time and duty cycle for example.

### Applies To

The following sensors only when controlled using the Ethernet connection:

Sensor Types	Models	Firmware Requirement	
	PWR-8P-RC; PWR-8PW-RC;	Allyconoicene	
Peak & Average - P & Pvv Models	PWR-40PW-RC	All versions	
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions	

### For USB control refer to:

- Read Peak & Average Power Array (Windows)
- Read Initial Power Array (Linux)

#### Parameters

Variable	Description
[n]	The package index from 1 to m. The total number of packets (m) and the initial package (with index 0) is returned by the Read Initial Power Array query.

#### Return String

[val_0] [val_1] [val_2][val_159]		
Variable	Description	
[val_n]	Series of discrete, absolute power measurements (dBm), each multiplied by 100 to give an	
	integer value	

#### Examples

Read Initial Power Array indicated that the power measurement is split over 5 packages, containing 804 discrete values, and returned the first 160 values (package 0). The remaining 4 packages of data must therefore be requested. Packages 1 to 3 contain 160 data points each and the final package contains the final 4 data points.

String to Send	String Returned
:POWER_ARRAY?	5 804 -6025 -6000 -59755025
:POWER_ARRAY_EP1?	-5050 -5075 -50756000
:POWER_ARRAY_EP2?	-6025 -6000 -59755025
:POWER_ARRAY_EP3?	-5050 -5075 -50756000
:POWER_ARRAY_EP4?	-6025 -6050 -6075 -6075

© 2025 Mini-Circuits

## 5.6.8. REAL TIME PEAK POWER - RETURN POWER

### :RTPEAK?

Returns the peak power value from internal memory since the register was last reset. The sensor continuously samples and stores this value to internal memory at the best possible resolution to allow a long-term real-time peak power value to be obtained. The sample period set by the user is ignored for this function.

Variable	Description
[power]	Peak power level (dBm) since the real-time peak power register was last reset
Examples	

String to Send	String Returned
:RTPEAK?	-2.050

HTTP Implementation: http://10.10.10/:RTPEAK?

### 5.6.9. REAL TIME PEAK POWER - RESET REGISTER

### :RTPEAK:MODE:0

Reset the stored peak power value in internal memory to start a new measurement. The sensor continuously samples and stores this value to internal memory at the best possible resolution to allow a long-term real-time peak power value to be obtained.

### Examples

String to Send	String Returned
:RTPEAK:MODE:0	1

HTTP Implementation: http://10.10.10/:RTPEAK:MODE:0

# 5.7. SCPI – LCD Functions

## 5.7.1. GET LCD STATUS

### :DISPLAY:SCREEN?

Indicates whether or not the LCD is enabled.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Return String

Value	Description
0	LCD disabled
1	LCD enabled

### Examples

String to Send	String Returned
:DISPLAY:SCREEN?	1

HTTP Implementation: http://10.10.10/:DISPLAY:SCREEN?

## 5.7.2. SET LCD STATUS

## :DISPLAY:SCREEN:[mode]

Enable or disable the LCD.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### Parameters

Value	Description
OFF	Disable LCD
ON	Enable LCD

### Return String

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String to Send	String Returned
:DISPLAY:SCREEN:ON	1

HTTP Implementation: http://10.10.10.10/:DISPLAY:SCREEN:ON

## 5.7.3. GET LCD ORIENTATION

### :DISPLAY:ROTATE?

Returns the orientation of the LCD, either in-line with the label text on the unit or rotated 180°.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

### **Return String**

Value	Description
0	LCD disabled
1	LCD enabled
Examples	
String to	Send String Returned

:DISPLAY:SCREEN? 1

HTTP Implementation: http://10.10.10/:DISPLAY:SCREEN?

### 5.7.4. SET LCD ORIENTATION

### :DISPLAY:ROTATE:[mode]

Set the orientation of the LCD, either in-line with the label text on the unit or rotated 180°.

### Applies To

Sensor Types	Models	Firmware Requirement
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions
RMS – High Speed Models	PWR-9RMS-RC; PWR-18RMS-RC	All versions

#### Parameters

Value	Description
OFF	Normal orientation (LCD text will be the same orientation as the printed label text on the unit body)
ON	LCD text will be rotated 180° relative to the label text

#### **Return String**

Command failed	Value	Description
	0	Command failed
1 Command completed successfully	1	Command completed successfully

Examples

String to Send	String Returned
:DISPLAY:ROTATE:ON	1

HTTP Implementation:

http://10.10.10/:DISPLAY:ROTATE:ON

© 2025 Mini-Circuits

# 5.8. SCPI - Ethernet Configuration

The following functions provide a method to review and edit the Ethernet TCP / IP connection parameters. The Update Ethernet Settings command must be used to save settings and restart the controller. Refer to Ethernet Control API for further details on Ethernet control of the device.

## 5.8.1. GET CURRENT ETHERNET CONFIGURATION

### :ETHERNET:CONFIG:LISTEN?

Returns the IP configuration that is currently use, either the static IP entered by the user, or the server assigned dynamic IP configuration when DHCP is enabled.

Return String

### [ip];[mask];[gateway]

Variable	Description
[ip]	Active IP address of the device
[mask]	Subnet mask for the network
[gateway]	IP address of the network gateway

### Examples

String to Send	String Returned
:ETHERNET:CONFIG:LISTEN?	192.100.1.1;255.255.255.0;192.100.1.0

HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:LISTEN?

### 5.8.2. GET MAC ADDRESS

### :ETHERNET:CONFIG:MAC?

Returns the physical MAC (media access control) address of the device.

Return String

Variable	Description
[mac]	MAC address
Examples	

String to Send	String Returned
:ETHERNET:CONFIG:MAC?	D0-73-7F-82-D8-01

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:MAC?

© 2025 Mini-Circuits

## 5.8.3. GET DHCP STATUS

### :ETHERNET:CONFIG:DHCPENABLED?

Indicates whether DHCP (dynamic host control protocol) is currently enabled. When disabled, the device will attempt to connect using the user-entered static IP parameters.

### Return String

Value	Description
0	DHCP disabled (static IP settings will be used)
1	DHCP enabled (IP address will be requested from DHCP server on the network)

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:DHCPENABLED?	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:DHCPENABLED?

## 5.8.4. USE DHCP

### :ETHERNET:CONFIG:DHCPENABLED:[enabled]

Enables or disables DHCP (dynamic host control protocol). When disabled, the device will attempt to connect using the user-entered static IP parameters. By default, DHCP is enabled.

### Parameters

Value	Description
0	DHCP disabled (static IP settings will be used)
1	DHCP enabled (IP address will be requested from DHCP server on the network)

#### **Return String**

Value	Description
0	Command failed
1	Command completed successfully

### Examples

String to Send	String Returned
:ETHERNET:CONFIG:DHCPENABLED:1	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:DHCPENABLED:1
## 5.8.5. GET STATIC IP ADDRESS

### :ETHERNET:CONFIG:IP?

Returns the user-entered static IP address.

#### Return String

Variable	Description	
[ip]	String containing the static IP address	
Examples		
String to S	end String Returned	

:ETHERNET:CONFIG:IP? 192.100.1.1

HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:IP?

## 5.8.6. SET STATIC IP ADDRESS

## :ETHERNET:CONFIG:IP:[ip]

Sets the static IP address to be used when DHCP is disabled.

#### Parameters

Variable	Description	
[ip]	String containing the static IP address	
Return Strir	ng	
Value	Description	
0	Command failed	
1	Command completed successfully	

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:IP:192.100.1.1	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:IP:192.100.1.1

## 5.8.7. GET STATIC NETWORK GATEWAY

### :ETHERNET:CONFIG:NG?

Returns the user-entered network gateway IP address.

#### **Return String**

Variable	Description	1
[gateway]	String containing the IP address of the network gateway	
Examples		
String to Se	nd	String Returned
:ETHERNET:CONFIG:NG?		192.168.1.0

HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:NG?

## 5.8.8. SET STATIC NETWORK GATEWAY

### :ETHERNET:CONFIG:NG:[gateway]

Sets the IP address of the network gateway to be used when DHCP is disabled.

#### Parameters

Variable	Description
[gateway]	String containing IP address of the network gateway
Return Strinc	

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:NG:192.100.1.0	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:NG:192.168.100.1.0

## 5.8.9. GET STATIC SUBNET MASK

### :ETHERNET:CONFIG:SM?

Returns the subnet mask to be used for Ethernet communication when static IP settings are in use. DHCP must be disabled for this setting to apply, otherwise a dynamic IP address will be in use.

**Return String** 

Variable	Description	
[mask]	String containing the subnet mask	
Examples		
String to S	Send	String Returned
:ETHERNET	:CONFIG:SM?	255.255.255.0
HTTP Imple	ementation:	http://10.10.10.10/:ETHERNET:CONFIG:SM

## 5.8.10. SET STATIC SUBNET MASK

## :ETHERNET:CONFIG:SM:[mask]

Sets the subnet mask to be used when DHCP is disabled.

#### Parameters

Variable	Description
[mask]	String containing the subnet mask
Return Strir	ng

Value	Description	
0	Command failed	
1	Command completed successfully	

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:SM:255.255.255.0	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:SM:255.255.0

## 5.8.11. GET HTTP PORT

### :ETHERNET:CONFIG:HTPORT?

Returns the TCP/IP port in use for HTTP communication. The default is port 80.

#### Return String

Description	
TCP / IP port to be used for HTTP communication	
end	String Returned
CONFIG:HTPORT?	8080
	Description TCP / IP port to b end :CONFIG:HTPORT?

HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:HTPORT?

## 5.8.12. SET HTTP PORT & ENABLE / DISABLE HTTP

### :ETHERNET:CONFIG:HTPORT:[port]

Sets the TCP / IP port to be used for HTTP communication. The default is port 80. Set port 0 or 65535 to disable HTTP or any valid port to enable.

#### Parameters

Variable	Description
[port]	TCP / IP port to be used for HTTP communication

#### Return String

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:HTPORT:8080	1

HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:HTPORT:8080

## 5.8.13. GET TELNET PORT

### :ETHERNET:CONFIG:TELNETPORT?

Returns the TCP/IP port in use for Telnet communication. The default is port 23.

#### **Return String**

Variable	Description	
[port]	TCP / IP port to be use	ed for Telnet communication
Examples		
String to Send		String Returned
:ETHERNET:CONFIG:TELNETPORT?		

HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:TELNETPORT?

## 5.8.14. SET TELNET PORT & ENABLE / DISABLE TELNET

### :ETHERNET:CONFIG:TELNETPORT:[port]

Sets the TCP / IP port to be used for Telnet communication. The default is port 23. Set port 0 or 65535 to disable Telnet or any valid port to enable.

#### Parameters

Variable	Description
[port]	TCP / IP port to be used for Telnet communication

#### Return String

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:TELNETPORT:21	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:TELNETPORT:21

## 5.8.15. GET SSH PORT

### :ETHERNET:CONFIG:SSHPORT?

Returns the TCP/IP port in use for SSH communication. The default is port 22.

Refer to Supported Models.

#### Return String

Variable	Description	
[port]	TCP / IP port to b	e used for SSH communication
Examples		
String to S	end	String Returned
:ETHERNET:CONFIG:SSHPORT?		21
HTTP Implementation: http://10.10.10.10/:ETHERNET:CONFIG:SSH		

### 5.8.16. SET SSH PORT

### :ETHERNET:CONFIG:SSHPORT:[port]

Sets the TCP / IP port to be used for SSH communication. The default is port 22.

Refer to Supported Models.

#### Parameters

Variable	Description
[port]	TCP / IP port to be used for SSH communication

Return String

Value	Description
0	Command failed
1	Command completed successfully
Examples	
String to S	Send String Returned

1

:ETHERNET:CONFIG:SSHPORT:21

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:SSHPORT:21

## 5.8.17. SAVE SSH LOGIN NAME

## :ETHERNET:CONFIG:SSHLOGINNAME:[name]

Sets the login name to be used for SSH communication.

Refer to Supported Models.

#### Parameters

Variable	Description
[name]	The login name for SSH communication

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:SSHLOGINNAME:ssh_user	1
:ETHERNET:CONFIG:SSHLOGINNAME?	ssh_user

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:SSHLOGINNAME:ssh\_user

## 5.8.18. SET PASSWORD REQUIREMENT

## :ETHERNET:CONFIG:PWDENABLED:[enabled]

### :ETHERNET:CONFIG:PWDENABLED?

Enables or disables the password requirement for HTTP / Telnet (the password is always required for SSH).

Parameters

Value	Description
0	Password not required for Ethernet communication
1	Password required for Ethernet communication

#### Return String

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:PWDENABLED:1	1
:ETHERNET:CONFIG:PWDENABLED:0	1
:ETHERNET:CONFIG:PWDENABLED?	0

HTTP Implementation:

http://10.10.10/:ETHERNET:CONFIG:PWDENABLED:1

## 5.8.19. SET PASSWORD

## :ETHERNET:CONFIG:PWD:[pwd]

#### :ETHERNET:CONFIG:PWD?

Sets the password used for SSH / HTTP / Telnet communication. The password will only apply for HTTP / Telnet after enabling using Set Password Requirement.

#### Parameters

Variable	Description
[pwd]	Password for Ethernet communication (not case sensitive, 20 characters maximum)

Command Return Values

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:PWD:PASS-123	1
:ETHERNET:CONFIG:PWD?	PASS-123

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:PWD:PASS-123

© 2025 Mini-Circuits

## 5.8.20. ENABLE / DISABLE ETHERNET

## :ETHERNET:CONFIG:ETHERNETENABLED:[status]

### :ETHERNET:CONFIG:ETHERNETENABLED?

Enables or disables the Ethernet interface. Disabling the Ethernet interface prevents communication over a network and reduces the DC current consumption.

#### Applies To

Sensor Types	Models	Firmware Requirement	
Peak & Average – P & PW Models	PWR-8P-RC; PWR-8PW-RC;	All versions	
	PWR-40PW-RC		
Peak & Average – PWHS Models	PWR-9PWHS-RC; PWR-18PWHS-RC	All versions	

#### Parameters

Value	Description
0	Ethernet disabled (reduced current consumption)
1	Ethernet enabled

#### Command Return Values

Value	Description
0	Command failed
1	Command completed successfully

#### Examples

String to Send	String Returned
:ETHERNET:CONFIG:ETHERNETENABLED:1	1
:ETHERNET:CONFIG:ETHERNETENABLED:0	1
:ETHERNET:CONFIG:ETHERNETENABLED?	0

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:ETHERNETENABLED:1

## 5.8.21. UPDATE ETHERNET SETTINGS

### :ETHERNET:CONFIG:INIT

Resets the Ethernet controller and restarts with the latest saved settings. Any subsequent commands / queries to the device will need to be attempted using the new Ethernet configuration. If a connection cannot be established, it may indicate an invalid configuration was created (for example a static IP address which clashes with another device on the network). The Ethernet settings can always be overwritten by connecting to the system using the USB connection.

#### Return String

Value	Description
0	Command failed
1	Command completed successfully
Examples	

String to Send	String Returned
:ETHERNET:CONFIG:INIT	1

HTTP Implementation: http://10.10.10/:ETHERNET:CONFIG:INIT

# 6. Contact

## Mini-Circuits

13 Neptune Avenue Brooklyn, NY 11235 Phone: +1-718-934-4500 Email: sales@minicircuits.com Web: www.minicircuits.com

#### Important Notice

This document is owned by Mini-Circuits and is protected by copyright, trademark and other intellectual property laws.

The information herein is provided by Mini-Circuits as an accommodation to our customers and may be used only to promote and accompany the purchase of Mini-Circuits' parts. This guide may not be reproduced, modified, distributed, published, stored in an electronic database, or transmitted and the information contained herein may not be exploited in any form or by any means, without prior written permission from Mini-Circuits.

This guide is subject to change, qualifications, variations, adjustments or modifications without notice and may contain errors, omissions, inaccuracies, mistakes or deficiencies. Mini-Circuits assumes no responsibility for, and will have no liability on account of, any of the foregoing. Accordingly, this document should be used as a guideline only.

#### Trademarks

All trademarks cited within this guide are the property of their respective owners. Neither Mini-Circuits nor the Mini-Circuits products are affiliated with or endorsed or sponsored by the owners of the above referenced trademarks.

Mini-Circuits and the Mini-Circuits logo are registered trademarks of Scientific Components Corporation.