

# Mini-Circuits Portable Test Equipment Programming Manual



## Chapter 7 - Input/Output (IO) Control Boxes

## **Chapter 7 - Input/Output (IO) Control Boxes ..... 7-1**

### **7.1 - Operating in a Windows Environment ..... 7-3**

7.1.1 - Referencing the DLL Library.....	7-3
7.1.2 - Summary of DLL Functions .....	7-4
7.1.3 - Detailed Description of DLL Functions.....	7-5
7.1.3 (a) - Open Control Box Connection .....	7-5
7.1.3 (b) - Close Control Box Connection .....	7-6
7.1.3 (c) - Read Model Name of Control Box.....	7-7
7.1.3 (d) - Read Serial Number of Control Box .....	7-8
7.1.3 (e) - Get List of Connected Serial Numbers .....	7-9
7.1.3 (f) - Set Byte A As Output .....	7-10
7.1.3 (g) - Set Byte B As Output .....	7-11
7.1.3 (h) - Set Byte A As Input.....	7-12
7.1.3 (i) - Set Byte B As Input.....	7-13
7.1.3 (j) - Set Byte A.....	7-14
7.1.3 (k) - Set Byte B .....	7-15
7.1.3 (l) - Read Byte .....	7-16
7.1.3 (m) - Read Byte A.....	7-17
7.1.3 (n) - Read Byte B .....	7-18
7.1.3 (o) - Set TTL Bit .....	7-19
7.1.3 (p) - Set TTL Pulse .....	7-20
7.1.3 (q) - Get TTL Bit.....	7-21
7.1.3 (r) - Set SPI Pulse Width.....	7-22
7.1.3 (s) - Send SPI Data.....	7-23
7.1.3 (t) - Send SPI Data with Trigger Out .....	7-25
7.1.3 (u) - Set Individual Relay .....	7-26
7.1.3 (v) - Set All Relays .....	7-28
7.1.3 (w) - Read Relay States .....	7-30
7.1.3 (x) - Get Firmware.....	7-32

### **7.2 - Operating in a Linux Environment..... 7-33**

7.2.1 - Summary of Commands .....	7-33
7.2.2 - Detailed Description of Commands.....	7-34
7.2.2 (a) - Get Device Model Name .....	7-34
7.2.2 (b) - Get Device Serial Number.....	7-35
7.2.2 (c) - Get Status of Relays.....	7-36
7.2.2 (d) - Set Single Relay .....	7-38
7.2.2 (e) - Set All Relays .....	7-39
7.2.2 (f) - Set Single TTL Bit.....	7-41
7.2.2 (g) - Get Single TTL Bit .....	7-43
7.2.2 (h) - Set TTL Byte.....	7-45
7.2.2 (i) - Get TTL Byte .....	7-47
7.2.2 (j) - Set Byte A As Input.....	7-49
7.2.2 (k) - Set Byte B As Input .....	7-50
7.2.2 (l) - Set Byte A As Output.....	7-51
7.2.2 (m) - Set Byte B As Output.....	7-52
7.2.2 (n) - Send SPI Output .....	7-53
7.2.2 (o) - Send SPI Output with Trigger.....	7-55
7.2.2 (p) - Set SPI Pulse Width .....	7-57
7.2.2 (q) - Get Firmware .....	7-58

## 7.1 - Operating in a Windows Environment

### 7.1.1 - Referencing the DLL Library

The DLL file is installed in the host PC's system folders using the steps outlined in the [Introduction](#) to this manual. In order to use the DLL functionality, some programming environments will require the user to set a reference to the relevant DLL file, usually through a built in GUI in the programming environment.

Once this is done, the user just needs to instantiate a new instance of the USB\_IO object in order to use the control box functions. The details of this vary greatly between programming environments and languages but Mini-Circuits can provide detailed support on request. A new USB\_IO object would need to be initialized for every control box that the user wishes to control. In the following examples, MyPTE1 and MyPTE2 will be used as names of 2 declared control box objects.

#### Examples

##### Visual Basic

```
Public MyPTE1 As New MCL_USB_To_IO.USB_IO
    ' Initialize new control box object, assign to MyPTE1
Public MyPTE2 As New MCL_USB_To_IO.USB_IO
    ' Initialize new control box object, assign to MyPTE1
```

##### Visual C++

```
MCL_USB_To_IO::USB_IO ^MyPTE1 = gcnew MCL_USB_To_IO::USB_IO ();
    // Initialize new control box instance, assign to MyPTE1
MCL_USB_To_IO::USB_IO ^MyPTE2 = gcnew MCL_USB_To_IO::USB_IO ();
    // Initialize new control box instance, assign to MyPTE2
```

##### Visual C#

```
MCL_USB_To_IO.USB_IO MyPTE1 = new MCL_USB_To_IO.USB_IO();
    // Initialize new control box instance, assign to MyPTE1
MCL_USB_To_IO.USB_IO MyPTE2 = new MCL_USB_To_IO.USB_IO();
    // Initialize new control box instance, assign to MyPTE2
```

##### Matlab

```
MyPTE1 = actxserver('MCL_USB_To_IO.USB_IO')
    % Initialize new control box instance, assign to MyPTE1
MyPTE2 = actxserver('MCL_USB_To_IO.USB_IO')
    % Initialize new control box instance, assign to MyPTE2
```

### 7.1.2 - Summary of DLL Functions

The following functions are defined in both of the DLL files. Please see the following sections for a full description of their structure and implementation.

- a) Short **Connect** (Optional String **SN**)
- b) Void **Disconnect** ()
- c) Short **Read\_ModelName** (String **ModelName**)
- d) Short **Read\_SN** (String **SN**)
- e) Short **Get\_Available\_SN\_List** (String **SN\_List**)
- f) Short **Set\_ByteA\_As\_Output** ()
- g) Short **Set\_ByteB\_As\_Output** ()
- h) Short **Set\_ByteA\_As\_Input** ()
- i) Short **Set\_ByteB\_As\_Input** ()
- j) Short **Set\_ByteA** (Byte **Val**)
- k) Short **Set\_ByteB** (Byte **Val**)
- l) Short **ReadByte** (String **ByteName**, Byte **Ret\_ByteVal**)
- m) Short **ReadByteA** (Byte **Ret\_ByteVal**)
- n) Short **ReadByteB** (Byte **Ret\_ByteVal**)
- o) Short **Set\_TTLBit** (String **BitName**, Short **BitVal**)
- p) Short **Set\_TTLPulse** (String **BitName**, Short **ms**)
- q) Short **ReadBit** (String **BitRequest**, Byte **Ret\_BitVal**)
- r) Short **Set\_SPI\_PulseWidth** (Short **PulsWidth**)
- s) Short **SPI\_OUT** (String **ClockBit**, String **DataBit**, String **LEBit**, String **RegData**)
- t) Short **SPI\_OUT\_Trigg** (String **RegData**, Short **Trigger**)
- u) Short **Set\_Relay** (Short **RelayNo**, Short **On\_OFF**)
- v) Short **Set\_RelayByte** (Byte **val**)
- w) Short **Read\_Relays\_Byte** (Byte **RetVal**)
- x) Short **GetExtFirmware** (Short **A0**, Short **A1**, Short **A2**, String **Firmware**)

## 7.1.3 - Detailed Description of DLL Functions

### 7.1.3 (a) - Open Control Box Connection

#### Declaration

**Short Connect**(Optional String SN)

#### Description

This function is called to initialize the connection to a USB control box. If multiple control boxes are connected to the same computer, then the serial number should be included, otherwise this can be omitted. The connection process can take a few milliseconds so it is recommended that the connection be made once at the beginning of the routine and left open until the control box is no longer needed. The control box should be disconnected on completion of the program using the [Disconnect](#) function.

#### Parameters

Data Type	Variable	Description
String	SN	Optional. A string containing the serial number of the USB control box. Can be omitted if only one control box is connected but must be included otherwise.

#### Return Values

Data Type	Value	Description
Short	0	No connection was possible
	1	Connection successfully established
	2	Device already connected
	3	Requested serial number is not available

#### Examples

```

Visual Basic
    status = MyPTE1.Connect(SN)
Visual C++
    status = MyPTE1->Connect(SN);
Visual C#
    status = MyPTE1.Connect(SN);
Matlab
    status = MyPTE1.Connect(SN)
  
```

#### See Also

[Close Control Box Connection](#)  
[Get List of Connected Serial Numbers](#)

### 7.1.3 (b) - Close Control Box Connection

#### Declaration

```
Void Disconnect()
```

#### Description

This function is called to close the connection to the control box. It is strongly recommended that this function is used prior to ending the program. Failure to do so may result in a connection problem with the device. Should this occur, shut down the program and unplug the control box from the computer, then reconnect the control box before attempting to start again.

#### Parameters

Data Type	Variable	Description
None		

#### Return Values

Data Type	Value	Description
None		

#### Examples

##### Visual Basic

```
MyPTE1.Disconnect()
```

##### Visual C++

```
MyPTE1->Disconnect();
```

##### Visual C#

```
MyPTE1.Disconnect();
```

##### Matlab

```
MyPTE1.Disconnect
```

#### See Also

[Open Control Box Connection](#)

### 7.1.3 (c) - Read Model Name of Control Box

#### Declaration

```
Short Read_ModelName (String ModelName)
```

#### Description

This function is called to determine the Mini-Circuits part number of the connected control box.

#### Parameters

Data Type	Variable	Description
String	ModelName	Required. User defined variable which will be updated with the Mini-Circuits part number.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
If MyPTE1.Read_ModelName (ModelName) > 0 Then
    MsgBox ("The connected generator is " & ModelName)
    ' Display a message stating the model name
End If
```

##### Visual C++

```
if (MyPTE1->Read_ModelName (ModelName) > 0 )
{
    MessageBox::Show("The connected generator is " , ModelName);
    // Display a message stating the model name
}
```

##### Visual C#

```
if (MyPTE1.Read_ModelName(ref (ModelName)) > 0 )
{
    MessageBox.Show("The connected generator is ", ModelName);
    // Display a message stating the model name
}
```

##### Matlab

```
[status, ModelName]= MyPTE1.Read_ModelName (ModelName)
If status > 0 then
{
    msgbox('The connected generator is ', ModelName)
    % Display a message stating the model name
}
```

#### See Also

[Read Serial Number of Control Box](#)

### 7.1.3 (d) - Read Serial Number of Control Box

#### Declaration

```
Short Read_SN(String SN)
```

#### Description

This function is called to determine the Mini-Circuits serial number of the connected control box.

#### Parameters

Data Type	Variable	Description
String	SN	Required. User defined variable which will be updated with the device serial number.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
If MyPTE1.Read_SN(SN) > 0 Then
    MsgBox ("The connected generator is " & SN)
    'Display a message stating the serial number
End If
```

##### Visual C++

```
if (MyPTE1->Read_SN(SN) > 0 )
{
    MessageBox::Show("The connected generator is " + SN);
    // Display a message stating the serial number
}
```

##### Visual C#

```
if (MyPTE1.Read_SN(ref(SN)) > 0 )
{
    MessageBox.Show("The connected generator is " + SN);
    // Display a message stating the serial number
}
```

##### Matlab

```
[status, SN]= MyPTE1.Read_SN(SN)
If status > 0 then
{
    msgbox('The connected generator is ', SN)
    % Display a message stating the serial number
}
```

#### See Also

[Read Model Name of Control Box](#)



### 7.1.3 (e) - Get List of Connected Serial Numbers

#### Declaration

```
Short Get_Available_SN_List(String SN_List)
```

#### Description

This function takes a user defined variable and updates it with a list of serial numbers for all available (currently connected) control boxes.

#### Parameters

Data Type	Variable	Description
String	SN_List	Required. User defined variable which will be updated with a list of all connected serial numbers, separated by a single space character, for example "11110001 11110002 11110003".

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	1	Command completed successfully

#### Examples

##### Visual Basic

```
If MyPTE1.Get_Available_SN_List(SN_List) > 0 Then
    array_SN() = Split(SN_List, " ")
    ' Split the list into an array of serial numbers
    For i As Integer = 0 To array_SN.Length - 1
        ' Loop through the array and use each serial number
    Next
End If
```

##### Visual C++

```
if (MyPTE1 ->Get_Available_SN_List(SN_List) > 0)
{
    // split the List into array of SN's
}
```

##### Visual C#

```
if (MyPTE1.Get_Available_SN_List(ref(SN_List)) > 0)
{
    // split the List into array of SN's
}
```

##### Matlab

```
[status, SN_List]= MyPTE1.Get_Available_SN_List(SN_List)
If status > 0 then
{
    % split the List into array of SN's
}
```

#### See Also

[Read Serial Number of Control Box](#)

### 7.1.3 (f) - Set Byte A As Output

#### Declaration

```
Short Set_ByteA_As_Output()
```

#### Description

This function is applicable to USB-I/O-16D8R only. The function changes the mode of byte A so that it acts as an output, rather than an input. By default Byte A is an output.

#### Parameters

Data Type	Variable	Description

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
status = MyPTE1.Set_ByteA_As_Output()
```

##### Visual C++

```
status = MyPTE1->Set_ByteA_As_Output();
```

##### Visual C#

```
status = MyPTE1.Set_ByteA_As_Output();
```

##### Matlab

```
status = MyPTE1.Set_ByteA_As_Output()
```

#### See Also

[Set Byte A As Input](#)

[Set Byte A](#)

[Read Byte A](#)

### 7.1.3 (g) - Set Byte B As Output

#### Declaration

```
Short Set_ByteB_As_Output()
```

#### Description

This function is not available for USB-I/O-4D2R. The function changes the mode of byte B so that it acts as an output, rather than an input. By default Byte B is an output.

#### Parameters

Data Type	Variable	Description

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
status = MyPTE1.Set_ByteB_As_Output()
```

##### Visual C++

```
status = MyPTE1->Set_ByteB_As_Output();
```

##### Visual C#

```
status = MyPTE1.Set_ByteB_As_Output();
```

##### Matlab

```
status = MyPTE1.Set_ByteB_As_Output()
```

#### See Also

[Set Byte B As Input](#)

[Set Byte B](#)

[Read Byte B](#)

### 7.1.3 (h) - Set Byte A As Input

#### Declaration

```
Short Set_ByteA_As_Input()
```

#### Description

This function is applicable to USB-I/O-16D8R only. The function changes the mode of byte A so that it acts as an input, rather than an output. By default Byte A is an output.

#### Parameters

Data Type	Variable	Description

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
status = MyPTE1.Set_ByteA_As_Input()
```

##### Visual C++

```
status = MyPTE1->Set_ByteA_As_Input();
```

##### Visual C#

```
status = MyPTE1.Set_ByteA_As_Input();
```

##### Matlab

```
status = MyPTE1.Set_ByteA_As_Input()
```

#### See Also

[Set Byte A As Output](#)

[Set Byte A](#)

[Read Byte A](#)

### 7.1.3 (i) - Set Byte B As Input

#### Declaration

```
Short Set_ByteB_As_Input()
```

#### Description

This function is not available for USB-I/O-4D2R. The function changes the mode of byte B so that it acts as an input, rather than an output. By default Byte B is an output.

#### Parameters

Data Type	Variable	Description

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
status = MyPTE1.Set_ByteB_As_Input()
```

##### Visual C++

```
status = MyPTE1->Set_ByteB_As_Input();
```

##### Visual C#

```
status = MyPTE1.Set_ByteB_As_Input();
```

##### Matlab

```
status = MyPTE1.Set_ByteB_As_Input()
```

#### See Also

[Set Byte B As Output](#)

[Set Byte B](#)

[Read Byte B](#)

### 7.1.3 (j) - Set Byte A

#### Declaration

```
Short Set_ByteA(Byte Val)
```

#### Description

This function is applicable to USB-I/O-16D8R only. The function sets the state of output byte A so that each bit is logic “low” (0) or logic “high” (1). Byte A is made up of 8 output bits, A0 to A7.

Note: Byte A must be set to output mode rather than input mode in order to use this function (see [Set\\_ByteA\\_As\\_Output](#)).

#### Parameters

Data Type	Variable	Description
Byte	Val	Required. A byte indicating the state to which each bit should be set, with bit 7 as the MSB and bit 0 as the LSB. For example to set output bits A2, A4 and A5 to logic high, with all others to logic low: A7=0, A6=0, A5=1, A4=1, A3=0, A2=1, A1=0, A0=0 Val = 00110100 (binary) = 52 (decimal)

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
status = MyPTE1.Set_ByteA(Val)
```

##### Visual C++

```
status = MyPTE1->Set_ByteA(Val);
```

##### Visual C#

```
status = MyPTE1.Set_ByteA(Val);
```

##### Matlab

```
status = MyPTE1.Set_ByteA(Val)
```

#### See Also

[Set Byte A As Output](#)

[Set Byte A As Input](#)

[Read Byte A](#)

### 7.1.3 (k) - Set Byte B

#### Declaration

```
Short Set_ByteB(Byte Val)
```

#### Description

This function sets the state of output byte B so that each bit is logic “low” (0) or logic “high” (1). Byte B is made up of 8 output bits, B0 to B7.

#### Notes:

1. For models other than USB-I/O-4D2R, byte B must be set to output mode rather than input mode in order to use this function (see [Set\\_ByteB\\_As\\_Output](#))
2. For USB-I/O-4D2R, only bits B0 to B3 are available, bits B4 to B7 are "don't care" and can be any value

#### Parameters

Data Type	Variable	Description
Byte	Val	Required. A byte indicating the state to which each bit should be set, with bit 7 as the MSB and bit 0 as the LSB. For example to set output bits B2, B4 and B5 to logic high, with all others to logic low: B7=0, B6=0, B5=1, B4=1, B3=0, B2=1, B1=0, B0=0 Val = 00110100 (binary) = 52 (decimal)

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
status = MyPTE1.Set_ByteB(Val)
```

##### Visual C++

```
status = MyPTE1->Set_ByteB(Val);
```

##### Visual C#

```
status = MyPTE1.Set_ByteB(Val);
```

##### Matlab

```
status = MyPTE1.Set_ByteB(Val)
```

#### See Also

[Set Byte B As Output](#)

[Set Byte B As Input](#)

[Read Byte B](#)

### 7.1.3 (I) - Read Byte

#### Declaration

```
Short ReadByte (String ByteName, Byte Ret_ByteVal)
```

#### Description

This function is not available for USB-I/O-4D2R.

This function reads the state of the specified input (byte A or byte B). Each byte is made up of 8 input bits, 0 to 7, which could be at logic "low" (0) or logic "high" (1).

#### Parameters

Data Type	Variable	Description
String	ByteName	Required. The byte to read, either "A" or "B".
Byte	Ret_ByteVal	Required. A user defined variable which will be updated with the state of each bit the specified byte. Bit 7 is the MSB and bit 0 is the LSB. For example, if the function returns: Ret_ByteVal = 106 (decimal) = 01101010 (binary) Then: bit 7=0, bit 6=1, bit 5=1, bit 4=0, bit 3=1, bit 2=0, bit 1=1, bit 0=0

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.ReadByte("A", Ret_ByteVal)
```

##### Visual C++

```
Status = MyPTE1->ReadByte("A", Ret_ByteVal);
```

##### Visual C#

```
Status = MyPTE1.ReadByte("A", Ret_ByteVal);
```

##### Matlab

```
Status = MyPTE1.ReadByte('A', Ret_ByteVal)
```

#### See Also

[Set Byte A As Output](#)  
[Set Byte A As Input](#)  
[Set Byte A](#)  
[Read Byte A](#)  
[Read Byte B](#)



### 7.1.3 (m) - Read Byte A

#### Declaration

```
Short ReadByteA(Byte Ret_ByteVal)
```

#### Description

This function is not available for USB-I/O-4D2R.

This function reads the state of the byte A input. Byte A is made up of 8 input bits, A0 to A7, which could be at logic “low” (0) or logic “high” (1).

#### Parameters

Data Type	Variable	Description
Byte	Ret_ByteVal	Required. A user defined byte which will be updated with the state of each bit in byte A. Bit 7 is the MSB and bit 0 is the LSB. For example, if the function sets: Ret_ByteVal = 106 (decimal) = 01101010 (binary) Then: A7=0, A6=1, A5=1, A4=0, A3=1, A2=0, A1=1, A0=0

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.ReadByteA(Ret_ByteVal)
```

##### Visual C++

```
Status = MyPTE1->ReadByteA(Ret_ByteVal);
```

##### Visual C#

```
Status = MyPTE1.ReadByteA(Ret_ByteVal);
```

##### Matlab

```
Status = MyPTE1.ReadByteA(Ret_ByteVal)
```

#### See Also

[Set Byte A As Output](#)  
[Set Byte A As Input](#)  
[Set Byte A](#)  
[Read Byte](#)  
[Read Byte B](#)

### 7.1.3 (n) - Read Byte B

#### Declaration

```
Short ReadByteB(Byte Ret_ByteVal)
```

#### Description

This function is not available for USB-I/O-4D2R.

This function reads the state of the byte B input. Byte A is made up of 8 input bits, B0 to B7, which could be at logic “low” (0) or logic “high” (1).

#### Parameters

Data Type	Variable	Description
Byte	Ret_ByteVal	Required. A user defined byte which will be updated with the state of each bit in byte B. Bit 7 is the MSB and bit 0 is the LSB. For example, if the function sets: Ret_ByteVal = 106 (decimal) = 01101010 (binary) Then: A7=0, A6=1, A5=1, A4=0, A3=1, A2=0, A1=1, A0=0

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.ReadByteB(Ret_ByteVal)
```

##### Visual C++

```
Status = MyPTE1->ReadByteB(Ret_ByteVal);
```

##### Visual C#

```
Status = MyPTE1.ReadByteB(Ret_ByteVal);
```

##### Matlab

```
Status = MyPTE1.ReadByteB(Ret_ByteVal)
```

#### See Also

[Set Byte B As Output](#)  
[Set Byte B As Input](#)  
[Set Byte B](#)  
[Read Byte](#)  
[Read Byte A](#)

### 7.1.3 (o) - Set TTL Bit

#### Declaration

```
Short Set_TTLBit(String BitName, Short BitVal)
```

#### Description

This function sets the state of a single output bit specified by the user. Bits A0 to A7 and B0 to B7 can be set (model dependent). The value of each bit can be set to logic “low” (0) or logic “high” (1).

Note: The relevant byte must be set to output mode rather than input mode in order to use this function (see [Set\\_ByteA\\_As\\_Output](#) and [Set\\_ByteB\\_As\\_Output](#)).

#### Parameters

Data Type	Variable	Description
String	BitName	Required. A string to indicate which bit is to be set, from “A0” to “A7”, or “B0” to “B7” (model dependent).
Short	BitVal	Required. An integer indicating the state to which the bit should be set, 0 or 1.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.Set_TTLBit(BitName, BitVal)
```

##### Visual C++

```
Status = MyPTE1->Set_TTLBit(BitName, BitVal);
```

##### Visual C#

```
Status = MyPTE1.Set_TTLBit(BitName, BitVal);
```

##### Matlab

```
Status = MyPTE1.Set_TTLBit(BitName, BitVal)
```

#### See Also

[Set TTL Pulse](#)  
[Get TTL Bit](#)

### 7.1.3 (p) - Set TTL Pulse

#### Declaration

```
Short Set_TTLPulse(String BitName, Short ms)
```

#### Description

This function outputs a positive pulse from a single bit specified by the user. The specified bit will be set to logic high for a user specified time and then drop to logic low. Bits A0 to A7 and B0 to B7 can be pulsed (model dependent). If the selected bit was already at logic high it will remain so for the specified time and then drop to logic low.

Note: The relevant byte must be set to output mode rather than input mode in order to use this function (see [Set\\_ByteA\\_As\\_Output](#) and [Set\\_ByteB\\_As\\_Output](#)).

#### Parameters

Data Type	Variable	Description
String	BitName	Required. A string to indicate which bit is to be pulsed, from "A0" to "A7", or "B0" to "B7" (model dependent).
Short	ms	Required. The time in ms for which the specified bit should be held high.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.Set_TTLPulse(BitName, Ms)
```

##### Visual C++

```
Status = MyPTE1->Set_TTLPulse(BitName, Ms);
```

##### Visual C#

```
Status = MyPTE1.Set_TTLPulse(BitName, Ms);
```

##### Matlab

```
Status = MyPTE1.Set_TTLPulse(BitName, Ms)
```

#### See Also

[Set TTL Bit](#)

[Get TTL Bit](#)

### 7.1.3 (q) - Get TTL Bit

#### Declaration

```
Short ReadBit(String BitRequest, Byte Ret_BitVal)
```

#### Description

This function is not available for USB-I/O-4D2R. The function reads the state of a single bit specified by the user. Bits A0 to A7 and B0 to B7 can be requested (model dependent). The value of each bit could be logic “low” (0) or logic “high” (1).

#### Parameters

Data Type	Variable	Description
String	BitRequest	Required. A string to indicate which bit is to be read, from “A0” to “A7”, or “B0” to “B7”.
Byte	Ret_ByteVal	Required. A user defined byte which will be updated with the state of the requested bit.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.ReadBit(BitRequest, Ret_ByteVal)
```

##### Visual C++

```
Status = MyPTE1->ReadBit(BitRequest, Ret_ByteVal);
```

##### Visual C#

```
Status = MyPTE1.ReadBit(BitRequest, Ret_ByteVal);
```

##### Matlab

```
Status = MyPTE1.ReadBit(BitRequest, Ret_ByteVal)
```

#### See Also

[Set TTL Bit](#)  
[Set TTL Pulse](#)

### 7.1.3 (r) - Set SPI Pulse Width

#### Declaration

```
Short Set_SPI_PulseWidth(Short PulsWidth)
```

#### Description

This function sets the pulse width that will be used for the Clock , Data and LE (Latch Enable) connections when the control box is used for SPI (Serial Peripheral Interface) communication. The pulse width can be set as any integer value from 0 to 255 $\mu$ s although in practice the minimum pulse width will be approximately 0.08 $\mu$ s.

Note: The duty cycle remains constant at 50% so clock frequency will change as pulse width is varied.

#### Parameters

Data Type	Variable	Description
Short	PulsWidth	Required. An integer value from 0 to 255 to set the desired pulse width in $\mu$ s

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.Set_SPI_PulseWidth(PulseWidth)
```

##### Visual C++

```
Status = MyPTE1->Set_SPI_PulseWidth(PulseWidth);
```

##### Visual C#

```
Status = MyPTE1.Set_SPI_PulseWidth(PulseWidth);
```

##### Matlab

```
Status = MyPTE1.Set_SPI_PulseWidth(PulseWidth)
```

#### See Also

[Send SPI Data](#)

[Send SPI Data With Trigger Out](#)

### 7.1.3 (s) - Send SPI Data

#### Declaration

```
Short SPI_Out(String ClockBit, String DataBit, String LEBit, String
               _ RegData)
```

#### Description

This function sends SPI (Serial Peripheral Interface) data. The Clock bit, Data bit and LE (Latch Enable) bits to be used are defined by the user. The user specified binary data will be sent along with all required start, stop and parity bits (as required by the SPI communication protocol).

Note: The relevant byte must be set to output mode rather than input mode in order to use this function (see [Set\\_ByteA\\_As\\_Output](#) and [Set\\_ByteB\\_As\\_Output](#)).

#### Parameters

Data Type	Variable	Description
String	ClockBit	Required. A string to define which bit to use as the Clock bit. Bits "A0" to "A7" and "B0" to "B7" (model dependent) can be selected.
String	DataBit	Required. A string to define which bit to use as the Data bit. Bits "A0" to "A7" and "B0" to "B7" (model dependent) can be selected.
String	LEBit	Required. A string to define which bit to use as the LE bit. Bits "A0" to "A7" and "B0" to "B7" (model dependent) can be selected.
String	RegData	Required. A binary string of up to 48 characters representing the data to be sent, for example "0011010101".

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.SPI_OUT(ClockBit, DataBit, LEBit, RegData)
```

##### Visual C++

```
Status = MyPTE1->SPI_OUT(ClockBit, DataBit, LEBit, RegData);
```

##### Visual C#

```
Status = MyPTE1.SPI_OUT(ClockBit, DataBit, LEBit, RegData);
```

##### Matlab

```
Status = MyPTE1.SPI_OUT(ClockBit, DataBit, LEBit, RegData)
```

#### See Also

[Set SPI Pulse Width](#)

[Send SPI Data With Trigger Out](#)



### 7.1.3 (t) - Send SPI Data with Trigger Out

#### Declaration

```
Short SPI_Out_Trigg(String RegData, Short Trigger)
```

#### Description

This function sends SPI (Serial Peripheral Interface) data with a trigger bit that will rise and fall together with the LE (Latch Enable) bit. Bit B0 is used as the Clock bit, B1 as the Data bit, B2 as the LE bit and B3 as the trigger. The user specified data will be sent along with all required start, stop and parity bits (as required by the SPI communication protocol).

Note: The relevant byte must be set to output mode rather than input mode in order to use this function (see [Set\\_ByteA\\_As\\_Output](#) and [Set\\_ByteB\\_As\\_Output](#)).

#### Parameters

Data Type	Variable	Description
String	RegData	Required. A string of up to 48 characters representing the binary value of the data to be sent, for example "0011010101".
Short	Trigger	Required. An integer 1 to enable the trigger or 0 to disable.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.SPI_OUT_Trigg(RegData, Trigger)
```

##### Visual C++

```
Status = MyPTE1->SPI_OUT_Trigg(RegData, Trigger);
```

##### Visual C#

```
Status = MyPTE1.SPI_OUT_Trigg(RegData, Trigger);
```

##### Matlab

```
Status = MyPTE1.SPI_OUT_Trigg(RegData,Trigger)
```

#### See Also

[Set SPI Pulse Width](#)  
[Send SPI Data](#)

### 7.1.3 (u) - Set Individual Relay

#### Declaration

```
Short Set_Relay(Short RelayNo, Short On_Off)
```

#### Description

This function sets the state of an individual relay, either Com to NO (Common port connected to Normally Open port) or Com to NC (Common port connected to Normally Closed port).

In the case of USB-I/O-4D2R, Com to NO turns on the 24V outputs and Com to NC turns them off.

#### Parameters (All Models Except USB-I/O-4D2R)

Data Type	Variable	Description
Short	RelayNo	Required. An integer (0 to 7) to determine which relay to set.
Short	On_Off	Required. An integer value to set the state of the relay, 0 for Com to NC state or 1 for Com to NO state.

#### Parameters (USB-I/O-4D2R Only)

Data Type	Variable	Description
Short	RelayNo	Required. An integer value to determine which output to set, 0 for OUT1 or 1 for OUT2.
Short	On_Off	Required. An integer value to set the state of the relay, 0 to turn off the 24V output, or 1 to turn on the 24V output.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

#### Examples

##### Visual Basic

```
Status = MyPTE1.Set_Relay(RelayNo, On_Off)
```

##### Visual C++

```
Status = MyPTE1->Set_Relay(RelayNo, On_Off);
```

##### Visual C#

```
Status = MyPTE1.Set_Relay(RelayNo, On_Off);
```

##### Matlab

```
Status = MyPTE1.Set_Relay(RelayNo, On_Off)
```

#### See Also

[Set All Relays](#)

[Read Relay States](#)

### 7.1.3 (v) - Set All Relays

#### Declaration

```
Short Set_RelayByte(Byte Val)
```

#### Description

This function sets the state of all relays at once. Each relay can be set to either Com to NO (Common port connected to Normally Open port) or Com to NC (Common port connected to Normally Closed port).

In the case of USB-I/O-4D2R, Com to NO turns on the 24V outputs and Com to NC turns them off.

#### Parameters (All Models except USB-I/O-4D2R)

Data Type	Variable	Description
Byte	Val	Required. A byte indicating the state to which each relay should be set. Each bit indicates the state to which a specific relay should be set, from bit 0 (LSB) for relay 0 to bit 7 (MSB) for relay 7. Each bit can be 0 for Com to NC state or 1 for Com to NO state. For example to set output relay 0, 3 and 5 to "Com to NO", with all others as "Com to NC": Relay7=0, Relay6=0, Relay5=1, Relay4=0, Relay3=1, Relay2=0, Relay1=0, Relay0=1 Val = 00101001 (binary) = 41 (decimal)

#### Parameters (USB-I/O-4D2R Only)

Data Type	Variable	Description
Byte	Val	Required. A byte indicating the state to which each relay should be set. Bit 0 corresponds to OUT1 and bit 1 to OUT2, all other bits can be any value ("don't care" bits). Each bit can be 1 to turn on the output or 0 to turn off the output. For example, to turn on OUT1 and turn off OUT2: Val = 00000001 (binary) = 1 (decimal)

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

## Examples

### Visual Basic

```
Status = MyPTE1.Set_RelayByte (Val)
```

### Visual C++

```
Status = MyPTE1->Set_RelayByte (Val) ;
```

### Visual C#

```
Status = MyPTE1.Set_RelayByte (Val) ;
```

### Matlab

```
Status = MyPTE1.Set_RelayByte (Val)
```

## See Also

[Set Individual Relay](#)

[Read Relay States](#)

### 7.1.3 (w) - Read Relay States

#### Declaration

```
Short Read_Relays_Byte(Byte RetVal)
```

#### Description

This function reads the state of all 8 relays simultaneously to determine whether they are in the Com to NO (Common port connected to Normally Open port) state or Com to NC (Common port connected to Normally Closed port) state.

In the case of USB-I/O-4D2R, the function will determine whether the 24V outputs, OUT1 and OUT2, are on or off.

#### Parameters (All Models Except USB-I/O-4D2R)

Data Type	Variable	Description
Byte	RetVal	Required. A user defined byte which will be updated with the state of each relay should be set. Each bit indicates the state of a single relay, from bit 0 (LSB) for relay 0 to bit 7 (MSB) for relay 7. Each bit can be 0 for Com to NC state or 1 for Com to NO state. For example: RetVal = 25 (decimal) = 00110010 (decimal) Therefore, relays 1, 4 and 5 are in the "Com to NO" state, with all others in the "Com to NC" state.

#### Parameters (USB-I/O-4D2R Only)

Data Type	Variable	Description
Byte	RetVal	Required. A user defined byte which will be updated with the state of each relay should be set. Bit 0 corresponds to OUT1 and bit 1 to OUT2, all other bits will be 0. Each bit will be 0 if the 24V output is disconnected or 1 if the 24V output is connected. RetVal = 2 (decimal) = 00000010 (decimal) Therefore, OUT1 is off and OUT2 is on.

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	Non zero	Command completed successfully

## Examples

### Visual Basic

```
Status = MyPTE1.Read_Relays_Byte(RetVal)
```

### Visual C++

```
Status = MyPTE1->Read_Relays_Byte(RetVal);
```

### Visual C#

```
Status = MyPTE1.Read_Relays_Byte(RetVal);
```

### Matlab

```
Status = MyPTE1.Read_Relays_Byte(RetVal)
```

## See Also

[Set Individual Relay](#)

[Set All Relays](#)

### 7.1.3 (x) - Get Firmware

#### Declaration

```
Short GetExtFirmware(Short A0, Short A1, Short A2, String Firmware)
```

#### Description

This function returns the internal firmware version of the control box along with three reserved variables (for factory use).

#### Parameters

Data Type	Variable	Description
Short	A0	Required. User defined variable for factory use only.
Short	A1	Required. User defined variable for factory use only.
Short	A2	Required. User defined variable for factory use only.
String	Firmware	Required. User defined variable which will be updated with the current firmware version, for example "B3".

#### Return Values

Data Type	Value	Description
Short	0	Command failed
Short	1	Command completed successfully

#### Examples

##### Visual Basic

```
If MyPTE1.GetExtFirmware(A0, A1, A2, Firmware) > 0 Then
    MsgBox ("Firmware version is " & Firmware)
End If
```

##### Visual C++

```
if (MyPTE1->GetExtFirmware(A0, A1, A2, Firmware) > 0 )
{
    MessageBox::Show("Firmware version is " + Firmware);
}
```

##### Visual C#

```
if (MyPTE1.GetExtFirmware(ref(A0, A1, A2, Firmware)) > 0 )
{
    MessageBox.Show("Firmware version is " + Firmware);
}
```

##### Matlab

```
[status, A0, A1, A2, Firmware]=MyPTE1.GetExtFirmware(A0, A1, A2, Firmware)
If status > 0 then
{
    msgbox('Firmware version is ', Firmware)
}
```



## 7.2 - Operating in a Linux Environment

To open a connection to Mini-Circuits' input/output control boxes, the Vendor ID and Product ID are required:

- Mini-Circuits Vendor ID: 0x20CE
- Switch Matrix Product ID: 0x21

Communication with the control box is carried out by way of USB Interrupt. The transmitted and received buffer sizes are 64 Bytes each:

- Transmit Array = [Byte 0][Byte1][Byte2]...[Byte 63]
- Returned Array = [Byte 0][Byte1][Byte2]...[Byte 63]

In most cases, the full 64 byte buffer size is not needed so any unused bytes become "don't care" bytes; they can take on any value without affecting the operation of the control box.

A worked example is included in [Appendix C](#) of this document. The example uses the libhid and libusb libraries to interface with the control box as a USB HID (Human Interface Device).

### 7.2.1 - Summary of Commands

The commands that can be sent to the control box are summarized in the table below and detailed on the following pages.

#	Description	Command Code (Byte 0)	Comments
a	<a href="#">Get Device Model Name</a>	40	
b	<a href="#">Get Device Serial Number</a>	41	
c	<a href="#">Get Status of Relays</a>	35	
d	<a href="#">Set Single Relay</a>	34	
e	<a href="#">Set All Relays</a>	33	
f	<a href="#">Set Single TTL Bit</a>	32	
g	<a href="#">Get TTL Bit</a>	30	
h	<a href="#">Set TTL Byte</a>	31	
i	<a href="#">Get TTL Byte</a>	28 29	Byte A Byte B
j	<a href="#">Set Byte A As Input</a>	24	
k	<a href="#">Set Byte B As Input</a>	26	
l	<a href="#">Set Byte A As Output</a>	25	
m	<a href="#">Set Byte B As Output</a>	27	
n	<a href="#">Send SPI Output</a>	36	
o	<a href="#">Send SPI Output With Trigger</a>	37	
p	<a href="#">Set SPI Pulse Width</a>	8	
q	<a href="#">Get Firmware</a>	99	

## 7.2.2 - Detailed Description of Commands

### 7.2.2 (a) - Get Device Model Name

#### Description

This function determines the Mini-Circuits part number of the control box.

#### Transmit Array

Send code 40 in BYTE0 of the transmit array. BYTE1 through to BYTE63 are don't care bytes and can be any value.

Byte	Byte 0
Description	Code
Value	40

#### Returned Array

The model name is represented as a series of ASCII characters in the returned array, starting from BYTE1. The final ASCII character is contained in the byte immediately preceding the first zero value byte. All subsequent bytes up to BYTE63 are "don't care" bytes and could be any value.

Byte	Byte 0	Byte 1	Byte 2	...	Byte (N-1)	Byte N
Description	Code	First Char	Second Char	...	Last Char	End Marker
Value	40	ASCII	ASCII	...	ASCII	0

#### Example

The following array would be returned for Mini-Circuits' USB-IO-4D2R control box. See Appendix A for conversions between decimal, binary and ASCII characters.

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	Char 1	Char 2	Char 3	Char 4	Char 5	Char 6
Value	40	85	83	42	45	73	79
ASCII Character	N/A	U	S	B	-	I	O

Byte	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	Byte 12
Description	Char 7	Char 8	Char 9	Char 10	Char 11	End Marker
Value	45	52	68	50	82	0
ASCII Character	-	4	D	2	R	N/A

#### See Also

[Get Device Serial Number](#)

## 7.2.2 (b) - Get Device Serial Number

### Description

This function determines the serial number of the connected control box.

### Transmit Array

Send code 41 in BYTE0 of the transmit array. BYTE1 through to BYTE63 are “don’t care” bytes and can be any value.

Byte	Byte 0
Description	Code
Value	41

### Returned Array

The serial number is represented as a series of ASCII characters in the returned array, starting from BYTE1. The final ASCII character is contained in the byte immediately preceding the first zero value byte. All subsequent bytes up to BYTE63 are “don’t care” bytes and could be any value.

Byte	Byte 0	Byte 1	Byte 2	...	Byte (N-1)	Byte N
Description	Code	First Char	Second Char	...	Last Char	End Marker
Value	41	ASCII	ASCII	...	ASCII	0

### Example

The following example indicates that the current control box has serial number 11301210001. See Appendix A for conversions between decimal, binary and ASCII characters.

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	Char 1	Char 2	Char 3	Char 4	Char 5	Char 6
Value	41	49	49	51	48	49	50
ASCII Character	N/A	1	1	3	0	1	2

Byte	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	Byte 12
Description	Char 7	Char 8	Char 9	Char 10	Char 11	End Marker
Value	49	48	48	48	49	0
ASCII Character	1	0	0	0	1	N/A

### See Also

[Get Device Model Name](#)

## 7.2.2 (c) - Get Status of Relays

### Description

This function returns the states of all relays at once. Each relay could be set to either Com to NO (Common port connected to Normally Open port) or Com to NC (Common port connected to Normally Closed port).

### Transmit Array

Send code 35 in BYTE0 of the transmit array. BYTE1 through to BYTE63 are “don’t care” bytes and can be any value.

Byte	Byte 0
Description	Code
Value	35

### Returned Array

Each bit in BYTE1 of the returned array represents the state of an individual relay, with bit 0 (LSB) representing relay 0 and bit 7 (MSB) representing relay 7. Each bit could be 1 for “Com to NO” or 0 for “Com to NC”.

In the case of USB-I/O-4D2R, only bit 0 (LSB) and bit 1 of BYTE1 apply, with bit 0 representing OUT1 and bit 1 representing OUT2. Each bit could be 1 to indicate the 24V output is on or 0 indicate it is off.

BYTE2 through to BYTE63 are “don’t care” bytes and can be any value.

Byte	Byte 0	Byte 1
Description	Code	State
Value	35	0 to 255

### Example

Byte	Byte 0	Byte 1
Description	Code	State
Value	33	7

The state of 7 in the above returned array can be interpreted as a binary number and broken down as below:

Bit	Bit 7 (MSB)	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 (LSB)
Description	Relay 7 State	Relay 6 State	Relay 5 State	Relay 4 State	Relay 3 State	Relay 2 State	Relay 1 State	Relay 0 State
Value	0	0	0	0	1	0	1	1

This indicates relays 0, 1 and 3 are in the “Com to NO” state, with all other relays in the “Com to NC” state.

### See Also

[Set Single Relay](#)  
[Set All Relays](#)

## 7.2.2 (d) - Set Single Relay

### Description

This function sets the state of an individual relay, either Com to NO (Common port connected to Normally Open port) or Com to NC (Common port connected to Normally Closed port).

### Transmit Array

Send code 34 in BYTE0 of the transmit array and the relay number (0 to 7) in BYTE1. BYTE2 sets the state of the specified relay, 1 for "Com to NO" or 0 for "Com to NC".

In the case of USB-I/O-4D2R, BYTE1 determines which of the 2 outputs to control, 0 for OUT1 or 1 for OUT2. BYTE2 sets the state of the specified output, 1 to turn on the 24V output or 0 to turn it off.

BYTE3 through to BYTE63 are "don't care" bytes and can be any value.

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Relay	State
Value	34	0 to 7	0 or 1

### Returned Array

Byte	Byte 0
Description	Code
Value	34

### Example

The following transmit array would set relay 3 of USB-I/O-16D8R into the "Com to NO" state:

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Relay	State
Value	34	3	1

The following transmit array would set OUT2 of USB-I/O-4D2R so that the 24V output is connected:

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Relay	State
Value	34	1	1

### See Also

[Get Status of Relays](#)  
[Set All Relays](#)

## 7.2.2 (e) - Set All Relays

### Description

This function sets the state of all relays at once. Each relay can be set to either Com to NO (Common port connected to Normally Open port) or Com to NC (Common port connected to Normally Closed port).

### Transmit Array

Send code 33 in BYTE0 of the transmit array. Each bit in BYTE1 represents the required state of an individual relay, with bit 0 (LSB) representing relay 0 and bit 7 (MSB) representing relay 7. Each bit can be 1 for "Com to NO" or 0 for "Com to NC".

In the case of USB-I/O-4D2R, only bit 0 (LSB) and bit 1 of BYTE1 apply, with bit 0 representing OUT1 and bit 1 representing OUT2. Each bit can be set to 1 to turn on the 24V output or 0 to turn it off.

BYTE2 through to BYTE63 are "don't care" bytes and can be any value.

Byte	Byte 0	Byte 1
Description	Code	State
Value	33	0 to 255

### Returned Array

Byte	Byte 0
Description	Code
Value	33

### Example

To set relays 0, 1 and 3 into the "Com to NO" state, with all other relays in the "Com to NC" state, the following byte would be sent for BYTE1:

Bit	Bit 7 (MSB)	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 (LSB)
Description	Relay 7 State	Relay 6 State	Relay 5 State	Relay 4 State	Relay 3 State	Relay 2 State	Relay 1 State	Relay 0 State
Value	0	0	0	0	1	0	1	1

The byte to send in BYTE1 is therefore 00001011 binary which equates to a decimal value of 7. The complete transmit array would be:

Byte	Byte 0	Byte 1
Description	Code	State
Value	33	7

**See Also**

[Get Status of Relays](#)

[Set Single Relay](#)



## 7.2.2 (f) - Set Single TTL Bit

### Description

This function sets the state of a single output bit specified by the user. Bits A0 to A7 and B0 to B7 can be set (model dependent). The value of each bit can be set to logic “low” (0) or logic “high” (1).

Note: The relevant byte must be set to output mode rather than input mode in order to use this function.

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 32
- BYTE1
  - ASCII character code to indicate which output byte is to be used; the code is 65 for byte A or 66 for byte B
- BYTE2
  - An integer value to indicate which bit within the byte is to be set, from 0 for bit 0 (LSB) to 7 for bit 7 (MSB)
- BYTE3
  - The state of the specified bit, either 0 (logic low) or 1 (logic high)
- BYTE4 to BYTE63
  - Can be any value (“don’t care” bytes)

For USB-I/O-4D2R, only bits 0 to 3 of Byte B are available.

Byte	Byte 0	Byte 1	Byte 2	Byte 3
Description	Code	Byte	Bit	State
Value	32	65 or 66	0 to 7	0 or 1

### Returned Array

Byte	Byte 0
Description	Code
Value	32

### Example

To set bit “B3” (bit 3 of byte B) to logic high, the following transmit array would be sent:

Byte	Byte 0	Byte 1	Byte 2	Byte 3
Description	Code	Byte	Bit	State
Value	32	66	3	1

**See Also**

[Get Single TTL Bit](#)

[Set TTL Byte](#)

## 7.2.2 (g) - Get Single TTL Bit

### Description

This function gets the state of a single TTL input bit from digital byte A or byte B, as specified by the user. Bits A0 to A7 and B0 to B7 are available. The value of each bit could be logic “low” (0) or logic “high” (1).

This function is not available for USB-I/O-4D2R.

Note: The relevant byte must be set to input mode rather than output mode in order to use this function.

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 30
- BYTE1
  - ASCII character code to indicate which input byte is to required; the code is 65 for byte A or 66 for byte B
- BYTE2
  - An integer value to indicate which bit within the byte is to be set, from 0 for bit 0 (LSB) to 7 for bit 7 (MSB)
- BYTE3 to BYTE63
  - Can be any value (“don’t care” bytes)

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Byte	Bit
Value	30	65 or 66	0 to 7

### Returned Array

The returned array contains the TTL logic value (0 or 1) of the requested bit in BYTE1.

Byte	Byte 0	Byte1
Description	Code	Value
Value	30	0 or 1

### Example

To read bit “B3” (bit 3 of byte B), the following transmit array would be sent:

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Byte	Bit
Value	32	66	3

The following array would be returned to indicate the input was at logic high:

Byte	Byte 0	Byte1
Description	Code	Value
Value	30	1

### See Also

[Set Single TTL Bit](#)

[Set TTL Byte](#)

## 7.2.2 (h) - Set TTL Byte

### Description

This function sets the state of output byte A or byte B so that each bit is logic “low” (0) or logic “high” (1).

Note: The relevant byte must be set to output mode rather than input mode in order to use this function.

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 31
- BYTE1
  - ASCII character code to indicate which output byte is to be used; the code is 65 for byte A or 66 for byte B
- BYTE2
  - The output state for the TTL byte
- BYTE3 to BYTE63
  - Can be any value (“don’t care” bytes)

For USB-I/O-4D2R, only bits 0 to 3 of Byte B are available.

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Byte	State
Value	31	65 or 66	0 to 255

### Returned Array

Byte	Byte 0
Description	Code
Value	31

### Example

To set byte A to the below state (1 indicating logic high and 0 indicating) logic low:

Bit	Bit 7 (MSB)	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 (LSB)
Description	State	State	State	State	State	State	State	State
Value	0	0	0	0	1	0	1	1

The binary value is 00001011 which equates to a decimal value of 11. The transmit array would therefore be:

Byte	Byte 0	Byte 1	Byte 2
Description	Code	Byte	State
Value	11	65	11

### See Also

[Get TTL Byte](#)

[Set Single TTL Bit](#)

## 7.2.2 (i) - Get TTL Byte

### Description

This function reads the state of digital input byte A or byte B. Each bit within the byte could be logic “low” (0) or logic “high” (1).

#### Notes:

1. This function is not available for USB-I/O-4D2R
2. The relevant byte must be set to input mode rather than output mode in order to use this function

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 28 for Byte A or 29 for Byte B
- BYTE1 to BYTE63
  - Can be any value (“don’t care” bytes)

Byte	Byte 0
Description	Code
Value	28 or 29

### Returned Array

The returned array repeats code 28 or 29 in BYTE0 and contains a numeric value representing the state of the required byte in BYTE1. BYTE2 to BYTE63 could be any value (“don’t care” bytes).

The value in BYTE1 of the returned array should be interpreted as a binary number, with each bit corresponding to a digital input bit within the byte, from 0 for bit 0 (LSB) to 7 for bit 7 (MSB).

Byte	Byte 0	Byte 1
Description	Code	Value
Value	28 or 29	Binary

### Example

Send the following array to read the input state of byte A:

Byte	Byte 0
Description	Code
Value	28

The following returned array indicates the input state of byte A is 11:

Byte	Byte 0	Byte 1
Description	Code	State
Value	28	11

To determine the state of each individual input bit of byte A, the decimal value 11 should be interpreted as a binary number (00001011). Each bit in the binary number confirms whether the corresponding input bit is at logic low (0) or logic high (1):

Bit	Bit 7 (MSB)	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 (LSB)
Description	State	State	State	State	State	State	State	State
Value	0	0	0	0	1	0	1	1

### See Also

[Set TTL Byte](#)

[Get Single TTL Bit](#)



## 7.2.2 (j) - Set Byte A As Input

### Description

This function changes the mode of byte A so that it acts as an input, rather than an output. By default Byte A is an output.

This command is available for USB-I/O-16D8R only.

### Transmit Array

Send code 24 in BYTE0 of the transmit array. BYTE1 to BYTE63 can be any value ("don't care" bytes).

Byte	Byte 0
Description	Code
Value	24

### Returned Array

Byte	Byte 0
Description	Code
Value	24

### See Also

[Set Byte B As Input](#)  
[Set Byte A As Output](#)  
[Set Byte B As Output](#)

## 7.2.2 (k) - Set Byte B As Input

### Description

This function changes the mode of byte B so that it acts as an input, rather than an output. By default Byte B is an output.

This command is not available for USB-I/O-4D2R.

### Transmit Array

Send code 26 in BYTE0 of the transmit array. BYTE1 to BYTE63 can be any value ("don't care" bytes).

Byte	Byte 0
Description	Code
Value	26

### Returned Array

Byte	Byte 0
Description	Code
Value	26

### See Also

[Set Byte A As Input](#)  
[Set Byte A As Output](#)  
[Set Byte B As Output](#)

## 7.2.2 (I) - Set Byte A As Output

### Description

This function changes the mode of byte A so that it acts as an output, rather than an input. By default Byte A is an output.

This command is not available for USB-I/O-4D2R.

### Transmit Array

Send code 25 in BYTE0 of the transmit array. BYTE1 to BYTE63 can be any value ("don't care" bytes).

Byte	Byte 0
Description	Code
Value	25

### Returned Array

Byte	Byte 0
Description	Code
Value	25

### See Also

[Set Byte A As Input](#)  
[Set Byte B As Input](#)  
[Set Byte B As Output](#)

## 7.2.2 (m) - Set Byte B As Output

### Description

This function changes the mode of byte B so that it acts as an output, rather than an input. By default Byte B is an output.

This command is not available for USB-I/O-4D2R.

### Transmit Array

Send code 27 in BYTE0 of the transmit array. BYTE1 to BYTE63 can be any value ("don't care" bytes).

Byte	Byte 0
Description	Code
Value	27

### Returned Array

Byte	Byte 0
Description	Code
Value	27

### See Also

[Set Byte A As Input](#)  
[Set Byte B As Input](#)  
[Set Byte A As Output](#)

## 7.2.2 (n) - Send SPI Output

### Description

This function sends SPI (Serial Peripheral Interface) data. The Clock bit, Data bit and LE (Latch Enable) bits to be used are defined by the user. The user specified binary data will be sent along with all required start, stop and parity bits (as required by the SPI communication protocol).

#### Notes:

1. For USB-I/O-4D2R, only bits 0 to 3 of Byte B are available
2. The relevant byte must be set to output mode rather than input mode in order to use this function.

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 36
- BYTE1
  - ASCII character code to indicate which output byte is to be used for the Clock; the code is 65 for byte A or 66 for byte B
- BYTE2
  - An integer value to indicate which bit within the byte is to be used for the Clock, from 0 for bit 0 (LSB) to 7 for bit 7 (MSB)
- BYTE3
  - ASCII character code to indicate which output byte is to be used for the Data; the code is 65 for byte A or 66 for byte B
- BYTE4
  - An integer value to indicate which bit within the byte is to be used for the Data, from 0 for bit 0 (LSB) to 7 for bit 7 (MSB)
- BYTE5
  - ASCII character code to indicate which output byte is to be used for the LE (Latch Enable); the code is 65 for byte A or 66 for byte B
- BYTE6
  - An integer value to indicate which bit within the byte is to be used for the LE, from 0 for bit 0 (LSB) to 7 for bit 7 (MSB)
- BYTE7
  - The number of data bits to be sent (N), not including the parity, start or stop bits.
  - Maximum value for N is 48
- BYTE8 to BYTE[N+7]
  - Each byte represents one SPI data bit to send with value 0 or 1
- BYTE[N+8] to BYTE63
  - Can be any value ("don't care" bytes)

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	Clock Byte	Clock Bit	Data Byte	Data Bit	LE Byte	LE Bit
Value	36	65 or 66	0 to 7	65 or 66	0 to 7	65 or 66	0 to 7

Byte	Byte 7	Byte 8	...	Byte [N+7]
Description	No. Data Bits (N)	Data Bit 1	...	Data Bit N
Value	1 to 48	0 or 1	...	0 or 1

### Returned Array

Byte	Byte 0
Description	Code
Value	36

### Example

Use the following transmit array to send SPI data "10010" using B0 as Clock, B1 as Data and B2 as LE:

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	Clock Byte	Clock Bit	Data Byte	Data Bit	LE Byte	LE Bit
Value	36	66	0	66	1	66	2

Byte	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	Byte 12
Description	No. Data Bits (N)	Data Bit 1	Data Bit 2	Data Bit 3	Data Bit 4	Data Bit 5
Value	5	1	0	0	1	0

### See Also

[Send SPI Output With Trigger](#)  
[Set SPI Pulse Width](#)

## 7.2.2 (o) - Send SPI Output with Trigger

### Description

This function sends SPI (Serial Peripheral Interface) data with a trigger bit that will rise and fall together with the LE (Latch Enable) bit. Bit B0 is used as the Clock bit, B1 as the Data bit, B2 as the LE bit and B3 as the trigger. The user specified data will be sent along with all required start, stop and parity bits (as required by the SPI communication protocol).

Note: Byte B must be set to output mode rather than input mode in order to use this function.

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 37
- BYTE1
  - The number of data bits to be sent (N), not including the parity, start or stop bits.
  - Maximum value for N is 48
- BYTE2
  - Enable the trigger (1) or disable the trigger (0)
- BYTE3 to BYTE[N+2]
  - Each byte represents one SPI data bit to send with value 0 or 1
- BYTE[N+3] to BYTE63
  - Can be any value ("don't care" bytes)

Byte	Byte 0	Byte 1	Byte 2	Byte 3	...	Byte [N+7]
Description	Code	No. Data Bits (N)	Trigger	Data Bit 1	...	Data Bit N
Value	37	1 to 48	0 or 1	0 or 1	...	0 or 1

### Returned Array

Byte	Byte 0
Description	Code
Value	37

### Example

Use the following transmit array to send SPI data “10010111” with the trigger enabled:

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	No. Data Bits (N)	Trigger	Data Bit 1	Data Bit 2	Data Bit 3	Data Bit 4
Value	37	8	1	1	0	0	1

Byte	Byte 7	Byte 0	Byte 1	Byte 2
Description	Data Bit 5	Data Bit 6	Data Bit 7	Data Bit 8
Value	0	1	1	1

### See Also

[Send SPI Output](#)  
[Set SPI Pulse Width](#)



## 7.2.2 (p) - Set SPI Pulse Width

### Description

This function sets the pulse width that will be used for the Clock, Data and LE (Latch Enable) connections when the control box is used for SPI (Serial Peripheral Interface) communication. The pulse width can be set as any integer value from 0 to 255 $\mu$ s although in practice the minimum pulse width will be approximately 0.08 $\mu$ s. The default value is 10 $\mu$ s.

Note: The duty cycle remains constant at 50% so clock frequency will change as pulse width is varied.

### Transmit Array

The transmit array is made up of the following bytes:

- BYTE0
  - Code 8
- BYTE1
  - Pulse width in micro-seconds, from 0 to 255
- BYTE2 to BYTE63
  - Can be any value ("don't care" bytes)

Byte	Byte 0	Byte 1
Description	Code	Byte
Value	8	0 to 255

### Returned Array

Byte	Byte 0
Description	Code
Value	8

### Example

To set the pulse width to 5 $\mu$ s, send:

Byte	Byte 0	Byte 1
Description	Code	Byte
Value	8	5

### See Also

[Send SPI Output](#)  
[Send SPI Output With Trigger](#)

## 7.2.2 (q) - Get Firmware

### Description

This function returns the internal firmware version of the control box.

### Transmit Array

Send code 99 in BYTE0 of the transmit array (BYTE1 through BYTE63 can be any value).

Byte	Byte 0
Description	Code
Value	99

### Returned Array

The firmware version will be returned in BYTE5 and BYTE6 as ASCII character codes representing the letter and number of the firmware. BYTE1 through to BYTE4 contain internal Mini-Circuits reference codes and BYTE7 through to BYTE63 are “don’t care” bytes and could be any value.

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	Reserved	Reserved	Reserved	Reserved	Firmware Letter	Firmware Number
Value	99	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII

### Example

The following return array would indicate that the current firmware version is C3:

Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Description	Code	Reserved	Reserved	Reserved	Reserved	Firmware Letter	Firmware Number
Value	99	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII
ASCII Character	N/A	7	4	S	W	C	3